



SUNNY BOY SMART ENERGY 3.8-US / 4.8-US / 5.8-US / 7.7-US / 9.6-US / 11.5-US

Table of Contents

1	Information on this Document.....	6
1.1	Validity.....	6
1.2	Target Group	7
1.3	Content and Structure of this Document.....	7
1.4	Levels of Warning Messages.....	7
1.5	Symbols in the Document.....	8
1.6	Typographies in the document.....	8
1.7	Designations in the Document.....	8
1.8	Additional Information.....	8
2	Safety	9
2.1	Intended Use.....	9
2.2	IMPORTANT SAFETY INSTRUCTIONS	10
3	Scope of Delivery.....	15
3.1	Scope of Delivery for SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50	15
3.2	Scope of Delivery for SBSE9.6-US-50 / SBSE11.5-US-50.....	16
4	Product overview	17
4.1	Device function of Sunny Boy Smart Energy.....	17
4.2	Product Description.....	18
4.3	Symbols on the Product.....	18
4.4	Interfaces and Functions.....	20
4.4.1	User Interface	20
4.4.2	Device Key (DEV KEY)	20
4.4.3	Diagnostic function.....	20
4.4.4	Increased self-consumption.....	20
4.4.5	Energy Monitoring	20
4.4.6	Peak load shaving.....	21
4.4.7	Arc-Fault Circuit Interrupter (AFCI)	21
4.4.8	Modbus	21
4.4.9	Grid Management Services	21
4.4.10	Rapid Shutdown Equipment	22
4.4.11	SMA Backup Secure.....	23
4.4.12	SMA Dynamic Power Control	23
4.4.13	SMA ShadeFix	23
4.4.14	SMA Smart Connected.....	23
4.4.15	SMA Speedwire.....	23
4.4.16	Protective Battery Charging.....	24
4.4.17	Wi-Fi	24
4.4.18	Wi-Fi connection to SMA 360° app and SMA Energy app	24
4.5	LED Signals.....	24
5	Mounting	25
5.1	Requirements for Mounting	25
5.1.1	Requirements for the Mounting Location	25
5.1.2	Permitted and prohibited mounting positions	26
5.1.3	Dimensions for mounting SBSE-3.8-US-50 / SBSE-4.8-US-50 / SBSE-5.8-US-50 / SBSE-7.7-US-50.....	27
5.1.4	Mounting Dimensions for SBSE9.6-US-50 / SBSE11.5-US-50	28
5.1.5	Recommended clearances for mounting	28
5.2	Mounting the Inverter	29
5.3	Spacer Installation	31

6	Electrical Connection.....	32
6.1	Requirements for the electrical connection.....	32
6.1.1	Equipotential Bonding.....	32
6.1.2	Overvoltage category.....	32
6.1.3	Common Grid Configurations.....	32
6.1.4	Requirements for the PV modules per input.....	33
6.1.5	Cable Requirements.....	34
6.1.5.1	Requirements for the AC Grounding Conductor.....	34
6.1.5.2	Requirements on the AC conductors.....	34
6.1.5.3	Requirements for the PV Grounding Conductors.....	34
6.1.5.4	Requirements for the PV cables.....	35
6.1.5.5	Requirements for the power cable for secure power supply operation.....	35
6.1.5.6	Requirements for signal cables for backup operation, MFR and rapid shutdown initiator.....	35
6.1.5.7	Network cable requirements.....	36
6.1.5.8	Cable specifications for RS485 connection of the energy meter.....	36
6.1.5.9	Battery Communication Cable Requirements.....	36
6.1.5.10	Requirements for the Battery Power Cables.....	37
6.1.5.11	Requirements for the grounding cable for additional protective grounding.....	37
6.2	Overview of the Connection Area.....	37
6.2.1	View from Below.....	37
6.2.2	Interior View.....	38
6.3	Electrical connection procedure.....	39
6.4	Connecting the Utility Grid.....	39
6.5	Connect the utility grid along with power and signal cables for backup operation.....	41
6.6	Connecting the Network Cable for Local Network and Energy Meter.....	44
6.7	Connection to RS485 terminal.....	46
6.7.1	Pin assignment of the RS485 terminal block.....	46
6.7.2	Connecting the energy meter via RS485.....	46
6.8	Connecting the Data Cable of the Battery.....	48
6.9	Connection to the Multifunction Relay.....	49
6.9.1	Pin assignment MFR.....	49
6.9.2	Connect signal source to MFR.....	49
6.10	Connecting a Rapid Shutdown Initiator.....	51
6.10.1	Connection of Several Inverters to a Rapid Shutdown Initiator.....	51
6.10.2	Connecting a Rapid Shutdown Initiator to the Digital Input GSI.....	52
6.11	Mounting the WLAN Antenna.....	55
6.12	Connecting the PV Array.....	55
6.13	Connecting the power cable of the battery.....	57
6.14	Connecting additional protective grounding.....	58
7	Commissioning.....	59
7.1	Commissioning Procedure of System with the SMA 360° App.....	59
7.2	Switching the Inverter On.....	60
7.3	Configuring the System with the SMA 360° App.....	62
7.4	Settings for Grid Support Functions in 208 V Grids.....	63
7.5	Checking the Secure Power Supply Operation.....	64
8	Operation.....	65
8.1	Operation notes.....	65
8.2	Establishing a Connection to the User Interface.....	65
8.2.1	Connection in the local network.....	65
8.2.1.1	Access addresses for the product in the local network.....	65
8.2.1.2	Establishing a Connection via Ethernet in the local network.....	66

8.2.1.3	Establishing a Connection via WLAN in the Local Network.....	66
8.2.2	Direct connection via Wi-Fi.....	67
8.2.2.1	Connection options for Wi-Fi direct connection	67
8.2.2.2	Access information for direct Wi-Fi connection	67
8.2.2.3	Establishing a direct Wi-Fi connection with the 360° app.....	67
8.2.2.4	Establishing a direct Wi-Fi connection with WPS	68
8.2.2.5	Establishing direct Wi-Fi connection with Wi-Fi network search.....	68
8.3	WPS function.....	68
8.3.1	Connection options with WPS.....	68
8.3.2	Activating WPS for automatic connection	69
8.3.3	Activating WPS for direct connection to a smart device	69
8.4	Design of the User Interface.....	69
8.5	Access rights to the user interface.....	70
8.6	Changing parameters.....	70
8.7	Arc-Fault Circuit Interrupter (AFCI).....	71
8.8	Rapid shutdown function	71
8.9	Setting backup operation.....	72
8.10	Setting of SMA ShadeFix.....	72
8.11	Control of external devices via Modbus	72
8.12	Digital output (MFR)	72
8.12.1	Use of the digital output (MFR)	72
8.12.2	Configure the digital output (MFR)	73
8.13	Energy management	74
8.13.1	Predefined energy management profiles.....	74
8.13.2	Used energy management profiles.....	74
8.13.3	Creating a new energy management profile	75
8.13.4	Changing an energy management profile	75
8.13.5	Deactivating the energy management.....	76
8.13.6	Activating the energy management	76
8.13.7	Setting options for peak load shaving	77
8.13.8	Backup Configuration	77
8.14	Backup file.....	78
8.14.1	Function and content of the backup file.....	78
8.14.2	Creating a Backup File	78
8.14.3	Upload backup file	78
8.15	Firmware Update.....	79
8.15.1	Automatically Updating the Firmware	79
8.15.2	Carry out a manual firmware update	79
8.15.3	Performing the Firmware Update via SMA 360° App	80
8.16	Device Administration.....	80
8.16.1	Register Devices	80
8.16.2	Delete devices	81
8.17	Restart the inverter via the user interface.....	81
8.18	Resetting the product to default setting	81
8.19	Deleting the Admin Account	82
8.20	Generating the I-V Characteristic Curve.....	82
8.21	Enabling Speedwire Encryption.....	82
8.22	Country standard	83
8.23	Overview of Grid Types.....	84
9	Disconnecting the Inverter from Voltage Sources.....	84
9.1	Remove enclosure lid.....	84
9.2	Check that the inverter is de-energized	86

10	Cleaning.....	88
11	Troubleshooting	88
11.1	Event messages.....	88
11.2	Create Diagnostics Data	113
11.3	Calculating the insulation resistance	113
11.4	Checking the PV System for Ground Faults.....	114
11.5	Manual restart after electric arc	115
12	Decommissioning	116
12.1	Disconnecting the Terminals from the Inverter	116
12.2	Disassembling the Inverter.....	116
13	Replacing the Product.....	117
14	Disposal	117
15	Technical Data	117
15.1	General Data	117
15.2	DC input of PV	118
15.3	Battery DC input	119
15.4	AC Output	120
15.5	Digital output (multifunction relay).....	122
15.6	Communication	122
15.7	Data Storage Capacity	122
15.8	Efficiency	123
15.9	Protective Devices	123
15.10	Climatic Conditions.....	123
15.11	Equipment.....	124
16	Compliance Information.....	124
17	Contact	124

Legal Provisions

The information contained in these documents is the property of SMA Solar Technology AG. No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, be it electronic, mechanical, photographic, magnetic or otherwise, without the prior written permission of SMA Solar Technology AG. Internal reproduction used solely for the purpose of product evaluation or other proper use is allowed and does not require prior approval.

SMA Solar Technology AG makes no representations or warranties, express or implied, with respect to this documentation or any of the equipment and/or software it may describe, including (with no limitation) any implied warranties of utility, merchantability, or fitness for any particular purpose. All such representations or warranties are expressly disclaimed. Neither SMA Solar Technology AG nor its distributors or dealers shall be liable for any indirect, incidental, or consequential damages under any circumstances.

The exclusion of implied warranties may not apply in all cases under some statutes, and thus the above exclusion may not apply.

Passwords managed by this SMA product are always stored encrypted.

Specifications are subject to change without notice. Every attempt has been made to make this document complete, accurate and up-to-date. Readers are cautioned, however, that product improvements and field usage experience may cause SMA Solar Technology AG to make changes to these specifications without advance notice or per contract provisions. SMA Solar Technology AG shall not be responsible for any damages, including indirect, incidental or consequential damages, caused by reliance on the material presented, including, but not limited to, omissions, typographical errors, arithmetical errors or listing errors in the content material.

SMA Warranty

You can download the current warranty conditions from the Internet at www.SMA-Solar.com.

Software licenses

The licenses for the installed software modules (open source) can be found in the user interface of the product.

Trademarks

All trademarks are recognized, even if not explicitly identified as such. Missing designations do not mean that a product or brand is not a registered trademark.

SMA Solar Technology AG

Sonnenallee 1

34266 Niestetal

Germany

Tel. +49 561 9522-0

Fax +49 561 9522-100

www.SMA.de

E-mail: info@SMA.de

Status: Tuesday, May 20, 2025

Copyright © 2025 SMA Solar Technology AG. All rights reserved.

1 Information on this Document

1.1 Validity

This document is valid for:

- SBSE3.8-US-50 (Sunny Boy Smart Energy 3.8-US)

- SBSE4.8-US-50 (Sunny Boy Smart Energy 4.8-US)
- SBSE5.8-US-50 (Sunny Boy Smart Energy 5.8-US)
- SBSE7.7-US-50 (Sunny Boy Smart Energy 7.7-US)
- SBSE9.6-US-50 (Sunny Boy Smart Energy 9.6-US)
- SBSE11.5-US-50 (Sunny Boy Smart Energy 11.5-US)

1.2 Target Group

This document is intended for qualified persons and end users. Only qualified persons are allowed to perform the activities marked in this document with a warning symbol and the caption "Qualified person". Tasks that do not require any particular qualification are not marked and can also be performed by end users. Qualified persons must have the following skills:

- Knowledge of how to safely disconnect SMA inverters
- Knowledge of how an inverter works and is operated
- Knowledge of how batteries work and are operated
- Training to deal with risks associated with installing, repairing, and using electrical devices, inverters, and batteries
- Training in the installation and commissioning of electrical devices and installations
- Knowledge of all applicable laws, regulations, standards, and directives
- Knowledge of and compliance with this document and all safety information
- Knowledge of and compliance with the documents of the battery manufacturer with all safety information

1.3 Content and Structure of this Document

This document describes the mounting, installation, commissioning, configuration, operation, troubleshooting and decommissioning of the product.

The latest version of this document and additional information about the product can be found in PDF format and as an eManual at www.SMA-Solar.com. You can also call up the eManual via the user interface of the product.

Illustrations in this document are reduced to the essential information and may deviate from the real product.

1.4 Levels of Warning Messages

The following levels of warning messages may occur when handling the product.

DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.






CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation which, if not avoided, can result in property damage.

1.5 Symbols in the Document

Symbol	Explanation
	Information that is important for a specific topic or goal, but is not safety-relevant
	Indicates a requirement for meeting a specific goal
	Required result
	Example
 QUALIFIED PERSON	Sections describing activities to be performed by qualified persons only

1.6 Typographies in the document


Typography	Use	Example
bold	<ul style="list-style-type: none"> Messages Terminals Elements on a user interface Elements to be selected Elements to be entered 	<ul style="list-style-type: none"> Connect the insulated conductors to the terminals X703:1 to X703:6. Enter 10 in the field Minutes.
>	<ul style="list-style-type: none"> Connects several elements to be selected 	<ul style="list-style-type: none"> Go to Settings > Date.
[Button] [Key]	<ul style="list-style-type: none"> Button or key to be selected or pressed 	<ul style="list-style-type: none"> Select [Enter].
#	<ul style="list-style-type: none"> Placeholder for variable components (e.g., parameter names) 	<ul style="list-style-type: none"> Parameter WCtlHz.Hz#




1.7 Designations in the Document

Complete designation	Designation in this document
SMA Home Energy Solution	System
Sunny Boy Smart Energy	Inverter, hybrid inverter
SMA Energy Meter-US	Energy meter

1.8 Additional Information

The following table provides some important additional information. Additional documents and language versions are available in the Downloads section of the Sunny Boy Smart Energy product page at www.SMA-Solar.com.

Title and information content	Type of information	QR code
"SunSpec Certified Rapid Shutdown Devices" Overview of approved SMA inverters with SunSpec Certified Rapid Shutdown Devices	Technical Information	

Title and information content	Type of information	QR code
"Approved Batteries and Information on Battery Communication Connection" Overview of approved batteries	Technical Information	
TechTip Sunny Boy Smart Energy (US): PV Only Installation Installation and electrical connection of the inverter	Video	
TechTip: Commissioning the Sunny Boy Smart Energy (US) with the SMA 360° App Commissioning the inverter with the commissioning wizard of the SMA 360° app	Video	

2 Safety

2.1 Intended Use

The Sunny Boy Smart Energy is a single-phase, transformerless hybrid inverter with 3 PV inputs (SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50) or with 4 PV inputs (SBSE9.6-US-50 / SBSE11.5-US-50) and a battery connection. The inverter feeds the direct current from the PV modules into the connected battery or converts it to grid-compliant alternating current and then feeds it into the utility grid. The Sunny Boy Smart Energy also converts the direct current supplied by the battery into grid-compliant alternating current. In a system with additional PV inverters, the Sunny Boy Smart Energy can convert the alternating current generated by the PV inverters into direct current and feed it into the battery.

The Sunny Boy Smart Energy has a manual secure power supply function, SMA Backup Secure. When needed, in the event of a power outage, the Sunny Boy Smart Energy can continue to supply selected loads with electricity from the battery and the PV system by means of a socket connected to the inverter.

The product must only be used as stationary equipment.

The product is suitable for indoor and outdoor use.

The product may only be operated with PV modules and cables that are approved in accordance with the electrical standards applicable on-site and the *National Electrical Code*® ANSI/NFPA 70.

No galvanic isolation

The product is not equipped with a transformer and therefore has no galvanic isolation.

- Do not operate grounded PV modules or batteries together with the product. If grounded PV modules or batteries are connected to the product, then an event will occur. The event will be displayed, along with the associated message, in the event list on the user interface of the product.
- Only ground the mounting frames of the PV modules.
- Only ground the enclosure of the battery.
- The neutral conductor of the AC output is not bonded to ground within the product.
- The neutral conductor of the AC output for backup operation can be grounded depending on the configuration.

PV modules with a high capacity to ground must only be used if the coupling capacity of all PV modules does not exceed 1.54 μF (SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50) or 2.30 μF (SBSE9.6-US-50 / SBSE11.5-US-50) (for information on determining the coupling capacitance, see technical information "Leading Leakage Currents" at www.SMA-Solar.com).

To protect the PV system against excessive reverse currents under fault conditions, a DC-side overcurrent protective device must be connected in accordance with the *National Electrical Code*® to prevent any short-circuit currents that exceed the ampacity of the DC electric circuit or the maximum series fuse rating of the PV modules. Typically, string fuses are used if more than two strings are connected in parallel.

The product may only be operated in connection with a lithium-ion battery approved by SMA Solar Technology AG. An updated list of batteries approved by SMA Solar Technology AG can be found in the system manual at www.SMA-Solar.com.

The inverter/battery combination must be certified in accordance with UL 9540.

The communication interface of the battery used must be compatible with the product. The entire battery voltage range must be completely within the permissible input voltage range of the product. The maximum permissible DC input voltage of the product must not be exceeded.

The product is not suitable for supplying life-sustaining medical devices. A power outage must not lead to personal injury.

All components must remain within their permitted operating ranges and their installation requirements at all times.

The product may only be operated with one of the energy meters approved by SMA Solar Technology AG. The following energy meters are allowed to be used when operating this product:

- SMA Energy Meter-US

Use SMA products only in accordance with the information provided in the enclosed documentation and with the locally applicable laws, regulations, standards and directives. Any other application may cause personal injury or property damage.

The documentation must be strictly followed. Deviations from the described actions and the use of materials, tools, and aids other than those specified by SMA Solar Technology AG are expressly forbidden.

Alterations to the SMA products, e.g., changes or modifications, are only permitted with the express written permission of SMA Solar Technology AG. Unauthorized alterations as well as failure to observe the documentation will void guarantee and warranty claims and in most cases terminate the operating license. SMA Solar Technology AG shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The documentation supplied is an integral part of SMA products. Keep the documentation in a convenient, dry place for future reference and observe all instructions contained therein.

This document does not replace any regional, state, provincial, federal or national laws, regulations or standards that apply to the installation, electrical safety and use of the product. SMA Solar Technology AG assumes no responsibility for the compliance or non-compliance with such laws or codes in connection with the installation of the product.

The type label must remain permanently attached to the product.

2.2 IMPORTANT SAFETY INSTRUCTIONS

Keep the manual for future reference.

This section contains safety information that must be observed at all times when working.

The product has been designed and tested in accordance with international safety requirements. As with all electrical or electronical devices, some residual risks remain despite careful construction. To prevent personal injury and property damage and to ensure long-term operation of the product, read this section carefully and observe all safety information at all times.

⚠ DANGER**Danger to life due to electric shock when live components or DC cables are touched**

The DC cables connected to a battery or a PV module may be live. Touching live DC cables results in death or serious injury due to electric shock.

- Disconnect the product and battery from voltage sources and make sure it cannot be reconnected before working on the device.
- Wait five minutes before working on the inverter.
- Observe all safety information of the battery manufacturer.
- Do not touch non-insulated parts or cables.
- Do not pull the DC conductors under load out of the terminal blocks.
- Wear suitable personal protective equipment for all work on the product.

⚠ DANGER**Danger to life due to electric shock from touching an ungrounded PV module or array frame**

Touching ungrounded PV modules or array frames results in death or lethal injuries due to electric shock.

- Connect and ground the frame of the PV modules, the array frame and the electrically conductive surfaces so that there is continuous conduction. Observe the applicable local regulations.

⚠ DANGER**Danger to life due to electric shock when touching live system components in case of a ground fault**

If a ground fault occurs, parts of the system may still be live. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Disconnect the product and battery from voltage sources and make sure it cannot be reconnected before working on the device.
- Only touch the cables of the PV modules on their insulation.
- Do not touch any parts of the substructure or frame of the PV array.
- Do not connect PV strings with ground faults to the inverter.
- Ensure that no voltage is present and wait 5 minutes before touching any parts of the PV system or the product.

⚠ DANGER**Danger to life due to electric shock in case of overvoltages and if surge protection is missing**

Overvoltages (e.g., in the event of a flash of lightning) can be further conducted into the building and to other connected devices in the same network via the network cables or other data cables if there is no surge protection. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Ensure that all devices in the same network and the battery are integrated into the existing surge protection.
- When laying the network cables or other data cables outdoors, it must be ensured that a suitable surge protection device is provided at the transition point of the cable from the product or the battery outdoors to the inside of a building.
- The Ethernet interface of the product is classified as "TNV-1" and offers protection against overvoltages of up to 1.5 kV.

⚠ WARNING**Danger to life due to fire and deflagration**

In rare cases, an explosive gas mixture can be generated inside the product under fault conditions. In this state, switching operations can cause a fire and, in very rare cases, a deflagration inside the product. Death or lethal injuries due to the spread of a fire can result.

- In the event of a fault, do not perform any direct actions on the product.
- In the event of a fault, ensure that unauthorized persons have no access to the product.
- In the event of a fault, disconnect the PV module from the inverter via an external disconnection device. If there is no disconnecting device present, wait until no more DC power is applied to the inverter.
- In the event of a fault, disconnect the battery from the product via an external disconnection service. Do not operate the DC load-break switch on the product.
- In the event of a fault, disconnect the AC circuit breaker, or keep it disconnected in case it has already tripped, and secure it against reconnection.

⚠ WARNING**Risk of injury due to toxic substances, gases and dusts**

In rare cases, damages to electronic components can result in the formation of toxic substances, gases or dusts inside the product. Touching toxic substances and inhaling toxic gases and dusts can cause skin irritation, burns or poisoning, trouble breathing and nausea.

- Only perform work on the product (e.g., troubleshooting, repair work) when wearing personal protective equipment for handling of hazardous substances (e.g., safety gloves, eye and face protection, respiratory protection).
- Ensure that unauthorized persons have no access to the product.

⚠ WARNING**Danger to life due to fire or explosion when batteries are fully discharged**

A fire may occur due to incorrect charging of fully discharged batteries. This can result in death or serious injury.

- Before commissioning the system, verify that the battery is not fully discharged.
- Do not commission the system if the battery is fully discharged.
- If the battery is fully discharged, contact the battery manufacturer for further proceedings.
- Only charge fully discharged batteries as instructed by the battery manufacturer.

⚠ WARNING**Danger to life due to burns caused by electric arcs through short-circuit currents**

Short-circuit currents in the battery can cause heat build-up and electric arcs. Heat build-up and electric arcs may result in lethal injuries due to burns.

- Disconnect the battery from all voltages sources prior to performing any work on the battery.
- Observe all safety information of the battery manufacturer.

⚠ WARNING**Danger to life due to electric shock from destruction of the measuring device due to overvoltage**

Overvoltage can damage a measuring device and result in voltage being present in the enclosure of the measuring device. Touching the live enclosure of the measuring device results in death or lethal injuries due to electric shock.

- Only use measuring devices with a measurement ranges designed for the maximum AC and DC voltage of the inverter.
- Only use measuring devices with measurement ranges designed for the maximum DC voltage of the battery.

⚠ CAUTION**Risk of burns due to hot inverter enclosure parts**

Some parts of the inverter enclosure can get hot during operation. Touching hot enclosure parts can result in burn injuries.

- During operation, do not touch any parts other than the enclosure lid of the inverter.
- Wait until the inverter has cooled down before touching the enclosure.

⚠ CAUTION**Risk of fire**

- To reduce the risk of fire, connect only to a circuit provided with a branch-circuit overcurrent protective device with a maximum rating of 50 A (SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50) or 60 A (SBSE9.6-US-50 / SBSE11.5-US-50) in accordance with the *National Electrical Code*® ANSI/NFPA 70 or the *Canadian Electrical Code*® CSA C22.1.

NOTICE**Damage to the product due to sand, dust and moisture ingress**

Sand, dust and moisture penetration can damage the product and impair its functionality.

- Only open the product if the humidity is within the thresholds and the environment is free of sand and dust.
- Do not open the product during a dust storm or precipitation.
- Close the product in case of interruption of work or after finishing work.
- Only operate the product when it is closed.
- Close tightly all enclosure openings.
- Only use listed rain-tight or liquid-tight conduit fittings to attach the conduits to the product.

NOTICE**Damage to the enclosure seal in subfreezing conditions**

If you open the product when temperatures are below freezing, the enclosure seals can be damaged. Moisture can penetrate the product and damage it.

- Only open the product if the ambient temperature is not below -5 °C (23 °F).
- If a layer of ice has formed on the enclosure seal when temperatures are below freezing, remove it prior to opening the product (e.g. by melting the ice with warm air).
- If the product must be opened in freezing conditions, make sure that the DC load-break switch is free of ice.

NOTICE**Damage to the inverter due to electrostatic discharge**

Touching electronic components can cause damage to or destroy the inverter through electrostatic discharge.

- Ground yourself before touching any component.

i DHCP Server is recommended

The DHCP server automatically assigns the appropriate network settings to your nodes in the local network. A manual network configuration is therefore not necessary. In a local network, the Internet router is usually the DHCP server. If the IP addresses in the local network are to be assigned dynamically, DHCP must be activated in the Internet router (see the Internet router manual). In order to receive the same IP address by the internet router after a restart, set the MAC address binding.

In networks where no DHCP server is active, proper IP addresses must be assigned from the free address pool of the network segment to all network participants to be integrated during commissioning.

i Communication disturbances in the local network

The IP address range 192.168.12.0 to 192.168.12.255 is occupied for communication amongst SMA products and for direct access to SMA products.

Communication problems might occur if this IP address range is used in the local network.

- Do not use the IP address range 192.168.12.0 to 192.168.12.255 in the local network.

i Electrical installations (for North America)

All installations must conform with the laws, regulations, codes and standards applicable in the jurisdiction of installation (e.g. *National Electrical Code*® ANSI/NFPA 70).

- Before connecting the product to the utility grid, contact your local grid operator. The electrical connection of the product must be carried out by qualified persons only.
- Ensure that the cables or conductors used for electrical connection are not damaged.

3 Scope of Delivery

3.1 Scope of Delivery for SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50

Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.




Figure 1: Components included in scope of delivery

Position	Quantity	Designation
A	1	Inverter
B	1	Mounting bracket
C	1	Left side cover
D	1	Right side cover
E	1	2-pole connector for the signal cable of the backup operation
F	1	4-pole connector for connecting the energy meter per RS485
G	1	3-pole connector for connecting the multifunctional relay
H	1	Sealing plug for the first enclosure opening from the left
I	1	Ferrite for the AC connection
J	1	Cable tie for securing the ferrite

Position	Quantity	Designation
K	1	Screw and washer assembly M5x12 for additional protective grounding
L	1	Documentation package consists of: <ul style="list-style-type: none"> • Safety information booklet • Quick reference guide poster with illustrated instructions for initial installation and commissioning • Sheet with a password label contains the following information: <ul style="list-style-type: none"> - PIC (Product Identification Code) identification key for registering the system in Sunny Portal - RID (Registration Identifier) registration ID for registering the system in Sunny Portal - Wi-Fi password WPA2-PSK (WiFi Protected Access 2 - Preshared Key) for direct connection to the product via Wi-Fi - Device Key (DEV KEY) for resetting the administrator password

3.2 Scope of Delivery for SBSE9.6-US-50 / SBSE11.5-US-50

Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.




Figure 2: Components included in scope of delivery

Position	Quantity	Designation
A	1	Inverter

Position	Quantity	Designation
B	1	Mounting bracket
C	1	Left side cover
D	1	Right side cover
E	1	Spacer
F	1	2-pole connector for the signal cable of the backup operation
G	1	4-pole connector for connecting the energy meter per RS485
H	1	3-pole connector for connecting the multifunctional relay
I	1	Sealing plug for the first enclosure opening from the left
J	1	Ferrite for the AC connection
K	1	Cable tie for securing the ferrite
L	1	Screw and washer assembly M5x12 for additional protective grounding
M	1	Documentation package consists of: <ul style="list-style-type: none"> • Safety information booklet • Quick reference guide poster with illustrated instructions for initial installation and commissioning • Sheet with a password label contains the following information: <ul style="list-style-type: none"> – PIC (Product Identification Code) identification key for registering the system in Sunny Portal – RID (Registration Identifier) registration ID for registering the system in Sunny Portal – Wi-Fi password WPA2-PSK (WiFi Protected Access 2 - Preshared Key) for direct connection to the product via Wi-Fi – Device Key (DEV KEY) for resetting the administrator password

4 Product overview

4.1 Device function of Sunny Boy Smart Energy

In systems with multiple inverters, you have the option of using and configuring the Sunny Boy Smart Energy either as a System Manager or as a subordinate device.

When using the Sunny Boy Smart Energy, you can use up to 6 devices (e.g. 1 Sunny Boy Smart Energy as System Manager, 2 Sunny Boy Smart Energy as subordinate devices, 2 PV inverters and 1 energy meter) in one system. Note that there may be a maximum of 3 Sunny Boy Smart Energy in the system.

To configure the device function, use the commissioning wizard in the SMA 360° app.

Inverter as System Manager

If you configure the inverter as System Manager, the inverter in conjunction with an energy meter takes over the control at the point of interconnection. As a System Manager, the inverter acts as a main device and is able to control (open-loop or closed-loop) subordinate devices. The System Manager also monitors the system and communicates with Sunny Portal powered by ennexOS.

Subordinate device

If you configure the inverter as a subordinate device, there is no independent closed-loop control or open-loop control at the point of interconnection. The subordinate inverter receives specifications from a main device (e.g. inverter as System Manager) and implements them.

4.2 Product Description



















Figure 3: Design of the product

Position	Designation
A	DC load-break switch
B	SMA Easy Lock enclosure lock
C	LEDs The LEDs indicate the operating state of the product.
D	A label with a QR code to be scanned using the SMA apps
E	Type label The type label clearly identifies the product. The type label must remain permanently attached to the product. You will find the following information on the type label: <ul style="list-style-type: none">• Device type (Model)• Serial number (Serial No. or S/N)• Date of manufacture• Device-specific characteristics

4.3 Symbols on the Product

Symbol	Explanation
	Beware of a danger zone This symbol indicates that the product must be additionally grounded if additional grounding or equipotential bonding is required at the installation site.

Symbol	Explanation
	Beware of electrical voltage The product operates at high voltages.
	Beware of hot surface The product can get hot during operation.
	Observe the documentations Observe all documentations supplied with the product.
	Danger to life due to high voltages in the inverter; observe a waiting time of 5 minutes. High voltages that can cause lethal electric shocks are present in the live components of the inverter. Before carrying out any work on the inverter, always de-energize the inverter as described in this document and secure it against reconnection.
	Operation LED Indicates whether the product is in operation.
	Error Together with the red LED, this symbol indicates an error. Observe the documentation.
	Data transmission Together with the blue LED, this symbol indicates the status of the network connection.
	Equipment Grounding Terminal This symbol indicates the position for the connection of an equipment grounding conductor.
	Grounding This symbol indicates the position for the connection of an additional equipment grounding conductor.
	The product has no galvanic isolation.
	WEEE designation Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.
	UL 62109-1 is the standard applied by Underwriters Laboratories to the product to certify that the product meets the requirements of the <i>National Electrical Code</i> ® and the IEEE 1547 standard.
	UL 62109-1 and CAN/CSA-C22.2 No. 62109-1:16 are the standards applied by Underwriters Laboratories to the product to certify that it meets the requirements of the <i>National Electrical Code</i> ®, the <i>Canadian Electrical Code</i> ® and IEEE 1547.

Symbol	Explanation
	The product complies with the requirements of the applicable Mexican standards.
	The product complies with the requirements of the applicable Canadian standards.

4.4 Interfaces and Functions

4.4.1 User Interface

The product is equipped as standard with an integrated webserver, which provides a user interface for configuring and monitoring the product.

Once the connection has been established to the smart device, use a device (e.g. smartphone, tablet or laptop) to connect to the product's user interface using a web browser.

Also see:

- [Access rights to the user interface](#) ⇒ page 70

4.4.2 Device Key (DEV KEY)

If you have forgotten the administrator password for the product, you can reset the administrator account with the device key and assign a new password. The device key can be used to prove the identity of the product in digital communication. The Device Key is provided on a sheet with a password label supplied with the product. Keep the device key safe in case you forget the administrator password.

4.4.3 Diagnostic function

The inverter has a diagnostic function for measuring the current/voltage characteristic curve (I-V characteristic curve) of the PV modules connected to DC inputs. The characteristic curve shows deviations and changes from the ideal curve. By this, problems in the PV modules can be detected at an early stage.

Also see:

- [Generating the I-V Characteristic Curve](#) ⇒ page 82

4.4.4 Increased self-consumption

With increased self-consumption, the highest possible proportion of the energy of a generator (e.g., a PV system) is consumed and stored at the place where it is generated. With increased self-consumption, power output at the point of interconnection is reduced when the energy can be consumed or stored at the place where it is generated. The power draw at the point of interconnection is reduced since a large proportion of the self-generated energy is being used.

The SMA Home Storage Solution supports the increased self-consumption through intermediate storage of energy from generators. In addition to the inverter, an energy meter and a battery are required for operation.

4.4.5 Energy Monitoring

The inverter supports the display of balances relating to PV generation in Sunny Portal powered by ennexOS or in the SMA Energy app. If the inverter is used together with the SMA Energy Meter-US, further and more detailed balances are shown.

4.4.6 Peak load shaving

With the "Peak Load Shaving" function, you can optimize the behavior of the inverter with respect to the power exchange at the point of interconnection. This is mostly useful when a higher supply of energy would lead to a higher electricity cost. With peak load shaving, the inverter controls - depending on its output and, in systems with a battery, on the available battery capacity - to previously defined grid exchange capacities. Power peaks and additional costs can thus be avoided.

You can configure maximum values for the power drawn at the point of interconnection. When the loads require additional energy, the battery is discharged and the maximum value is kept constant at the grid-connection point. This is based on the prerequisite that the battery is sufficiently charged.

In addition to the inverter, an energy meter and a battery are required for operation.

4.4.7 Arc-Fault Circuit Interrupter (AFCI)

The inverter is equipped with an integrated photovoltaic (PV) arc-fault circuit interrupter as required for PV systems by *National Electrical Code*® ANSI/NFPA 70 (NEC). The inverters' arc-fault circuit interrupter (AFCI) functionality is certified to Standard UL 1699B Edition 1 (August 2018), Photovoltaic (PV) DC Arc-Fault Circuit Protection, which defines requirements for PV arc-fault protection devices intended for use in solar photovoltaic electrical energy systems as described in NEC 690.11.

The arc-fault circuit interrupter (AFCI) is activated as standard and is set so that the current flow is interrupted after each electric arc and restarts automatically. If 5 electric arcs are detected within 24 hours, the inverter interrupts feed-in operation permanently and a manual restart must be carried out. If the installation conditions permit this, you can change the default setting.

The arc-fault circuit interrupter (AFCI) can detect electric arcs in the PV modules and the module wiring of connected strings. The arc-fault circuit interrupter ensures that the inverter ceases operations and interrupts any electric arcs as soon as they are detected. This involves halting the flow of current.

The arc-fault circuit interrupter (AFCI) has proved extremely reliable, meaning that the inverter dependably detects and interrupts electric arcs that actually occur in the PV electric circuit and is generally not susceptible to false tripping. AFCI incidents output by the inverter should be regarded as reliable indicators of actual errors in the PV electric circuit displayed and should be investigated immediately and thoroughly by qualified persons to localize and rectify errors in the PV electric circuit.

Also see:

- [Arc-Fault Circuit Interrupter \(AFCI\) ⇒ page 71](#)
- [Manual restart after electric arc ⇒ page 115](#)

4.4.8 Modbus

The inverter is equipped with a Modbus interface. The Modbus interface is deactivated by default and must be configured as needed.

The Modbus interface of the supported SMA products is designed for industrial use – via SCADA systems, for example – and has the following tasks:

- Remote query of measured values
- Remote setting of operating parameters
- Setpoint specifications for system control
- Controlling the battery

4.4.9 Grid Management Services

The inverter is a grid support interactive inverter.

The inverter was tested in accordance with UL 1741 SB / IEEE 1547-2018 (10/2022) to be compliant with the source requirements documents of the states available at the time of the test.

For connecting the inverter to the utility grid, no additional grid monitoring equipment is necessary.

4.4.10 Rapid Shutdown Equipment

The inverter is listed as PV Rapid Shutdown Equipment (PVRSE) according to UL 1741.

All PV inputs and AC outputs of this product meet the photovoltaic rapid shutdown requirements for controlled conductors located outside the PV array.

A complete PV Rapid Shutdown System (PVRSS) consists of the PV or hybrid inverter, the PV module switches, and a rapid shutdown initiator. The AC fuse of the inverter or an external rapid shutdown initiator can be used as a rapid shutdown initiator. If the DC load-break switch of the inverter is used, only 1 inverter is switched off and not the entire system. The rapid shutdown initiator initiates a rapid shutdown. The PV Rapid Shutdown System must limit the DC conductors to < 30 V within 30 seconds.

NOTICE - The inverter's Rapid Shutdown function can be initiated if the inverter is disconnected from the AC grid voltage, depending on the configuration, by either opening the main PV system AC disconnect or activating the rapid shutdown initiator. The AC circuit breaker that serves as the rapid shutdown initiator must be readily accessible and clearly marked in accordance with *National Electrical Code*®. The Rapid Shutdown status of the PV system will be indicated by the On/Off (Closed/Open) position of this AC disconnect. The Off (Open) position indicates that a rapid shutdown has been initiated.

If PV array disconnect switches compliant with the SunSpec communication signal for Rapid Shutdown systems are installed, the inverter can transmit a SunSpec-compliant "permission to operate" signal to them via its DC input conductors. When a rapid shutdown is initiated, the inverter will stop transmitting the SunSpec signal. When the SunSpec signal is not being received, the PV array disconnect switches are responsible for reducing line voltages within the PV array in accordance with *National Electrical Code*®. For rapid shutdown via the SunSpec communication signal to function properly, ensure all PV modules connected to the inverter are equipped with SunSpec-compliant PV module switches. For reliable discharge of the DC connection conductors, it is necessary for the sum of the standby voltages of all PV array disconnect switches of a string to be > 3.6 V and < 30 V. Typically, this is the case starting with approximately 6 PV modules. In addition, the recommended total length of all DC lines of a string should not exceed 160 m (520 ft). The total length defines the length of the entire string wiring including the connection cable of the PV module switch in the string (measured from the positive DC terminal to the negative DC terminal of the inverter).

The rapid shutdown system can also be equipped with PV module switches, which initiate the rapid shutdown in response to an AC power outage or by other means. In such cases, it is essential that the PV system rapid shutdown initiator triggers a simultaneous rapid shutdown of the PV modules whenever the inverter is disconnected from the grid voltage.

The PV array disconnect switches must disconnect the PV array from the inverter within a maximum of 15 seconds after Rapid Shutdown initiation.

The inverter is capable of grid support operation where in case of a loss of AC voltage, the inverter remains connected to the utility grid for a defined ride-through time and waits for voltage recovery. If the grid voltage is not restored within the defined times, the inverter disconnects from the utility grid. Depending on the configuration of the rapid shutdown initiator, a rapid shutdown is also triggered.

The Rapid Shutdown function is enabled by default. The Rapid Shutdown function should only be enabled when approved PV module switches have been installed within the PV module or between the PV module and the inverter. The Rapid Shutdown function can be configured during or after inverter commissioning via the user interface, the SMA 360° app, or Sunny Portal powered by ennexOS by selecting the operating mode appropriate for the PV module switches. If the Rapid Shutdown function is enabled but PV module switches are not installed, the inverter will be unable to discharge the connected DC input conductors during a rapid shutdown. As a result, the inverter can be damaged.

WARNING - THIS PV RAPID SHUTDOWN EQUIPMENT DOES NOT PERFORM ALL OF THE FUNCTIONS OF A COMPLETE PV RAPID SHUTDOWN SYSTEM. THIS PV RAPID SHUTDOWN EQUIPMENT MUST BE INSTALLED WITH OTHER EQUIPMENT TO FORM A COMPLETE PV RAPID SHUTDOWN SYSTEM THAT MEETS THE REQUIREMENTS OF NEC (NFPA 70) FOR CONTROLLED CONDUCTORS OUTSIDE THE ARRAY. OTHER

EQUIPMENT INSTALLED IN OR ON THIS PV SYSTEM MAY ADVERSELY AFFECT THE OPERATION OF THE PV RAPID SHUTDOWN SYSTEM. IT IS THE RESPONSIBILITY OF THE INSTALLER TO ENSURE THAT THE COMPLETED PV SYSTEM MEETS THE RAPID SHUT DOWN FUNCTIONAL REQUIREMENTS. THIS EQUIPMENT MUST BE INSTALLED ACCORDING TO THE MANUFACTURER'S INSTALLATION MANUAL.

Also see:

- [Connecting a Rapid Shutdown Initiator to the Digital Input GSI ⇒ page 52](#)

4.4.11 SMA Backup Secure

The manual secure power supply operation SMA Backup Secure ensures that, when needed, for example in case of a power outage, the inverter can continue to supply electric current to selected loads via the inverter. The loads are connected via a socket to the inverter and can be supplied with electric current from the battery or the PV system. SMA Backup Secure is started manually, if needed, via a switch connected to the inverter.

SMA Backup Secure can only be used if SMA Backup Start is installed in the inverter. SMA Backup Start is equipped with a battery that can be charged to start the system as soon as energy is present in the PV system or the system battery.

4.4.12 SMA Dynamic Power Control

SMA Dynamic Power Control is a pre-installed software that allows a System Manager to control the active and reactive power of up to 5 inverters (including the System Manager).

4.4.13 SMA ShadeFix

The inverter is equipped with the shade management system SMA ShadeFix. SMA ShadeFix uses an intelligent MPP tracking system to determine the operating point with the highest output during shading conditions. With SMA ShadeFix, inverters use the best possible energy supply from the PV modules at all times to increase yields in shaded systems.

The time interval of SMA ShadeFix is usually 6 minutes. This means that the inverter determines the optimum operating point every 6 minutes. Depending on the PV system or shading situation, it may be useful to adjust the time interval.

Also see:

- [Setting of SMA ShadeFix ⇒ page 72](#)

4.4.14 SMA Smart Connected

SMA Smart Connected is the free monitoring of the inverter via the SMA Sunny Portal. Thanks to SMA Smart Connected, the operator and qualified person will be informed automatically and proactively about inverter events that occur.

SMA Smart Connected is activated during registration in Sunny Portal. In order to use SMA Smart Connected, it is necessary that the inverter is permanently connected to Sunny Portal and the data of the operator and qualified person is stored in Sunny Portal and up-to-date.

4.4.15 SMA Speedwire

The inverter is equipped with SMA Speedwire as standard. SMA Speedwire is a type of communication based on the Ethernet standard. SMA Speedwire is designed for a data transfer rate of 100 Mbps and enables optimum communication between Speedwire devices within systems.

The inverter supports the encrypted system communication with SMA Speedwire Encrypted Communication. In order to be able to use the Speedwire encryption in the system, all Speedwire devices, except for the energy meter (e.g. SMA Energy Meter) must support the function SMA Speedwire Encrypted Communication.

Also see:

- [Enabling Speedwire Encryption ⇒ page 82](#)

4.4.16 Protective Battery Charging

If the battery is not charged for a long time, there is a risk of deep discharge. To prevent damage to the battery due to deep discharge, the inverter charges the battery from the utility grid for approx. 10 to 15 minutes when the SOC (State of Charge) is very low.

4.4.17 Wi-Fi

The inverter is equipped with a WLAN interface as standard. The inverter is delivered with the WLAN interface activated as standard. If you do not want to use WLAN, you can deactivate the WLAN interface.

In addition, the inverter has a WPS function. The WPS function is for automatically connecting the inverter to a network (e.g., via router) and establishing a direct connection between the inverter and a smart end device.

4.4.18 Wi-Fi connection to SMA 360° app and SMA Energy app

There is a QR code on the inverter as standard. Scanning the QR Code on the product using the SMA 360° app enables Wi-Fi access and automatically connects to the user interface.

Commissioning of the system can be started and carried out by scanning the QR code with the SMA 360° app. Subsequently, the SMA Energy App can be used for energy monitoring of the system.

Also see:

- [Direct connection via Wi-Fi ⇒ page 67](#)

4.5 LED Signals

The LEDs indicate the operating state of the inverter.

LED signal	Explanation
Green LED and red LED flash simultaneously (2 s on and 2 s off)	No country data set set Operation of the inverter is stopped because no country data set is set. The inverter automatically starts operation as soon as the configuration has been carried out (e.g., using the commissioning wizard or via a System Manager).
The green LED is flashing (2 s on and 2 s off)	Waiting for feed-in conditions The conditions for feed-in operation are not yet met. As soon as the conditions are met, the inverter will start feed-in operation.
The green LED is flashing (1.5 s on and 0.5 s off)	The inverter is in backup operation.
The green LED is glowing	Operation The inverter is in operation.
The green LED is off	No DC voltage is present.
The red LED is glowing	Error Inverter operation has been stopped. In addition, a specific event message and the associated event number are displayed on the user interface of the inverter or System Manager (see Section 11.1, page 88).

LED signal	Explanation
Red LED is flashing (0.25 s on, 0.25 s off, 0.25 s on, 1.25 s off)	<p>Warning</p> <p>Communication with the System Manager failed. The inverter continues to operate with restricted function (e.g., with set fallback level).</p> <p>In addition, a specific event message and the associated event number are displayed on the user interface of the inverter or System Manager (see Section 11.1, page 88).</p>
The blue LED is flashing slowly (2 s on and 2 s off)	<p>Communication connection is being established.</p> <p>The inverter is establishing a connection with a local network or is establishing a direct connection to a smart device (e.g., smartphone, tablet, or laptop).</p>
The blue LED is flashing fast (0.25 s on and 0.25 s off)	A System Manager is requesting identification of the inverter.
The blue LED is glowing	There is an active connection with a local network or there is a direct connection with a smart device (e.g., smartphone, tablet or laptop).
Blue LED is off	There is no active connection.
All 3 LEDs are on	Inverter update or booting procedure.

5 Mounting

5.1 Requirements for Mounting

5.1.1 Requirements for the Mounting Location

WARNING

Danger to life due to fire or explosion

Despite careful construction, electrical devices can cause fires. This can result in death or serious injury.

- Do not mount the product in areas containing highly flammable materials or gases.
- Do not mount the product in potentially explosive atmospheres.

- ☐ The mounting location must be suitable for the weight and dimensions of the product.
- ☐ A solid support surface must be available (e.g., concrete or masonry, free-standing constructions). When mounted on drywall or similar materials, the inverter emits audible vibrations during operation which could be perceived as annoying.
- ☐ Drywall must have a minimum thickness of 25 mm (1 in). This means that double-layer drywall must be used or the drywall must be additionally reinforced (e.g., with plywood, OSB, or chipboard).
- ☐ The installation site can be exposed to direct solar irradiation. There is, however, the possibility that the product reduces its power output to avoid overheating due to high temperatures.
- ☐ The installation site should be freely and safely accessible at all times without the need for any auxiliary equipment (such as scaffolding or lifting platforms). Non-fulfillment of these criteria may restrict servicing.
- ☐ The DC load-break switch of the product must always be freely accessible.
- ☐ All ambient conditions must be met.

- The ambient temperature should be -25°C to $+45^{\circ}\text{C}$ (-13°F to $+113^{\circ}\text{F}$) to ensure optimal operation.

Also see:

- [Mounting the Inverter \$\Rightarrow\$ page 29](#)

5.1.2 Permitted and prohibited mounting positions

- The product may only be mounted in a permitted position. This will ensure that no moisture can penetrate the product.
- The product should be mounted such that the LED signals can be read off without difficulty.




Figure 4: Permitted and prohibited mounting positions

Also see:

- [Mounting the Inverter \$\Rightarrow\$ page 29](#)

5.1.3 Dimensions for mounting SBSE-3.8-US-50 / SBSE-4.8-US-50 / SBSE-5.8-US-50 / SBSE-7.7-US-50




Figure 5: Position of the anchoring points (dimensions in mm (in))

Also see:

- [Mounting the Inverter ⇒ page 29](#)

5.1.4 Mounting Dimensions for SBSE9.6-US-50 / SBSE11.5-US-50




Figure 6: Position of the anchoring points (dimensions in mm (in))

5.1.5 Recommended clearances for mounting

To guarantee optimal operation and adequate heat dissipation for the inverter, the following requirements for clearances should be observed. This will prevent the inverter power output from being reduced due to excessive temperatures. However, smaller distances are permissible without causing any risk to safety or service life of the product.

i Prescribed clearances in accordance with the **National Electrical Code®**

Under certain conditions, the *National Electrical Code®* specifies greater clearances.

- Make sure that the prescribed clearances are met, according to the *National Electrical Code®*.
- ☐ Recommended distances to walls, other devices and objects should be maintained.
- ☐ If multiple products are mounted in areas with high ambient temperatures, increase the clearances between the products and ensure sufficient fresh-air supply.




Figure 7: Recommended clearances (dimensions in mm (in))

Also see:

- [Mounting the Inverter](#) ⇒ page 29

5.2 Mounting the Inverter

⚠ QUALIFIED PERSON

Additionally required material (not included in the scope of delivery):

- ☐ 2 or 4 screws (depending on support surface) suitable for both the support surface and the inverter's weight
- ☐ 2 or 4 washers suitable for the screws
- ☐ 2 or 4 screw anchors (depending on support surface) suitable for the support surface and the screws

⚠ CAUTION

Risk of injury due to weight of product


Injuries may result if the product is lifted incorrectly or dropped while being transported or mounted.

- Transport and lift the product carefully. Take the weight of the product into account.
- Wear suitable personal protective equipment for all work on the product.

Procedure:


1. Align the mounting bracket horizontally and mark the position of the drill holes. Use either the 2 holes in the center of the wall mounting bracket, or 1 hole each on the left and right. All 4 holes have to be utilized when mounting to drywall.
2. Set the mounting bracket aside and drill the marked holes.

3. Insert screw anchors into the drill holes if the support surface requires them.
4. Tighten the mounting bracket horizontally with screws and washers. Ensure the mounting bracket is correctly aligned.




☑ The mounting bracket is installed correctly.


5. Do not place the inverter vertically under any circumstances.
6. Pick up the inverter at the top and bottom of the enclosure and place it at a 45° angle over the upper 2 rivets in the upper guide rails of the mounting bracket.



7. Carefully rotate the bottom of the inverter toward the support surface and place it at a 90° angle to the base.



8. Engage the top and bottom rivets in the corresponding recesses.



9. Make sure that the inverter is securely attached by carefully moving the enclosure back and forth.

Also see:


- Recommended clearances for mounting ⇒ page 28
- Dimensions for mounting SBSE-3.8-US-50 / SBSE-4.8-US-50 / SBSE-5.8-US-50 / SBSE-7.7-US-50 ⇒ page 27
- Permitted and prohibited mounting positions ⇒ page 26
- Requirements for the Mounting Location ⇒ page 25

5.3 Spacer Installation


For the **SBSE9.6-US-50** and **SBSE11.5-US-50** products, an additional spacer must be installed.

Procedure:

1. Attach the spacer from the scope of delivery to the enclosure. The spacer audibly snaps into place.



2. Adjust the spacer by turning it to the left or right so that the inverter is attached vertically to the support surface.



3. Make sure that the inverter is securely attached by carefully moving the enclosure back and forth.

6 Electrical Connection

6.1 Requirements for the electrical connection

6.1.1 Equipotential Bonding

If components are used in the PV system that require equipotential bonding (e.g., mounting racks, module frames), these must be connected to a central equipotential panel provided for this purpose.

Observe the installation guidelines and regulations applicable in your country. The enclosure of the inverter is not suitable as equipotential bonding. Incorrect implementation of equipotential bonding can lead to an inverter defect that is not covered under warranty.

6.1.2 Overvoltage category

The inverter can be used in grids of overvoltage category III or lower in accordance with UL 62109-1. That means that the product can be permanently connected to the grid-connection point of a building.

6.1.3 Common Grid Configurations

The connection procedure varies depending on the grid configuration. The following table provides an overview of common grid configurations, which conductors have to be connected to the inverter to comply with the grid configuration and which country data set can be set. The inverter is designed to connect to a utility grid with either a 240 V split-phase system or a 208 V wye-connection system as standard. The grid configuration is set separately from the country data set. For an overview of these and other grid types, please refer to the technical information "INVERTERS & UTILITY GRID CONFIGURATION" in the download area at www.SMA-Solar.com.

For 208 V grids, note the settings for the grid support functions (see Section 7.4, page 63).

Compatible grid configuration	Conductors to be connected	Configurable country data sets
240 V split-phase system	L1, L2 and N	<ul style="list-style-type: none"> • [CA] CSA C22.3 No.9:20 • [Offgrid] SMA stand-alone mode 50 Hz PV inverter • [Offgrid] SMA stand-alone mode 60 Hz PV inverter • [US] CA-R21 IEEE1547:2018 Cat.B III: Used when the requirements of California Rule 21 must be met. • [US] UL1741/SB Cat B-III Storage: Supports the requirements of large-scale PV power plants and distribution networks in accordance with California Rule 21 and Hawaii Rule 14H. Used if the utility company does not specify a specific country data set and there is a battery in the system. • [US] UL1741/SB Cat.B-II: Supports voltage ride through (VRT) from DER for all large-scale PV power plants. • [US] UL1741/SB Cat.B-II Storage: Supports voltage ride through (VRT) from DER for all large-scale PV power plants with battery. • [US] UL1741/SB Cat.B-III: Supports the requirements of large-scale PV power plants and distribution networks in accordance with California Rule 21 and Hawaii Rule 14H. Used if the utility company does not specify a specific country data set.
208 V wye connection	L1, L2 and N	
208 V delta connection	L1 and L2	
240 V delta connection	L1 and L2	

6.1.4 Requirements for the PV modules per input

- ☐ All PV modules should be of the same type.
- ☐ All PV modules should be aligned and tilted identically. Otherwise the yields may be reduced.
- ☐ If 2 strings are connected to one input, the same number of PV modules wired in series must be connected to each string.
- ☐ On the coldest day based on statistical records, the open-circuit voltage of the PV array must never exceed the maximum input voltage of the inverter.
- ☐ The maximum input current per string must be observed and must not exceed the through-fault current of the DC connectors in the installation.
- ☐ The thresholds for the input voltage and the input current of the inverter must be adhered to.
- ☐ If rapid shutdown modules are used, at least one string must consist of at least 6 PV modules. This achieves the required standby voltage of 3.6 V.

Also see:

- [Connecting the PV Array ⇒ page 55](#)

6.1.5 Cable Requirements

6.1.5.1 Requirements for the AC Grounding Conductor

For the grounding conductor (PE) of the connection to the utility grid, the following requirements apply that are different from the requirements for the other conductors.

- ☐ Conductor type: copper wire
- ☐ Permissible temperature: at least 90°C (194°F)
- ☐ The grounding conductor must be solid or stranded wire.
- ☐ Maximum cable length within the inverter: 180 mm (7.1 in)
- ☐ Conductor cross-section: 16 mm² (6 AWG)
- ☐ Insulation stripping length: 18 mm (0.7 in)
- ☐ The conductors with regards to their ampacity, rated temperatures, operating conditions and power loss must be made in accordance with the local standards and the *National Electrical Code*® ANSI/NFPA 70. If the manufacturer (SMA Solar Technology AG) requires a higher conductor cross-section than the standard, the range of the manufacturer must be observed.

Also see:

- [Requirements on the AC conductors ⇒ page 34](#)

6.1.5.2 Requirements on the AC conductors

The following requirements apply only to the N and L1 and L2 conductors. For grounding conductor, note that the requirements are different.

- ☐ Conductor type: copper wire
- ☐ Permissible temperature: at least 90°C (194°F)
- ☐ The conductors must be solid or stranded wire.
- ☐ Maximum cable length within the inverter: 180 mm (7.1 in)
- ☐ Conductor cross-section for **SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50**: 1.5 mm² to 16 mm² (16 AWG to 4 AWG)
- ☐ Conductor cross-section for **SBSE9.6-US-50 / SBSE11.5-US-50**: 6 mm² to 16 mm² (10 AWG to 4 AWG)
- ☐ Insulation stripping length: 18 mm (0.7 in)
- ☐ The conductors with regards to their ampacity, rated temperatures, operating conditions and power loss must be made in accordance with the local standards and the *National Electrical Code*® ANSI/NFPA 70. If the manufacturer (SMA Solar Technology AG) requires a higher conductor cross-section than the standard, the range of the manufacturer must be observed.

Also see:

- [Requirements for the AC Grounding Conductor ⇒ page 34](#)
- [Connect the utility grid along with power and signal cables for backup operation ⇒ page 41](#)

6.1.5.3 Requirements for the PV Grounding Conductors

For the equipment grounding conductor (PE) of the PV modules, the following requirements apply that are different from the requirements for the other conductors.

- ☐ Conductor type: copper wire
- ☐ Permissible temperature: at least 90°C (194°F)
- ☐ The grounding conductor must be solid or stranded wire.
- ☐ Maximum cable length within the inverter: 180 mm (7.1 in)
- ☐ Conductor cross-section: 6 mm² to 16 mm² (10 AWG to 6 AWG)

- ☐ Insulation stripping length: 8 mm to 10 mm (0.3 in to 0.4 in)
- ☐ The conductors with regards to their ampacity, rated temperatures, operating conditions and power loss must be made in accordance with the local standards and the *National Electrical Code*® ANSI/NFPA 70.

Also see:

- [Connecting the PV Array ⇒ page 55](#)
- [Requirements for the PV cables ⇒ page 35](#)

6.1.5.4 Requirements for the PV cables

The following requirements apply only to the PV+ and PV- conductors. For grounding conductor, note that the requirements are different.

- ☐ The cables must be made of copper.
- ☐ Maximum cable length within the inverter: 180 mm
- ☐ Conductor cross-section: 2.5 mm² to 10 mm² (14 AWG to 8 AWG)
- ☐ Cable diameter: 5 mm to 8 mm (0.2 in to 0.3 in)
- ☐ Nominal voltage: at least 600 V
- ☐ Insulation stripping length: 12 mm (0.5 in)

Also see:

- [Connecting the PV Array ⇒ page 55](#)
- [Requirements for the PV Grounding Conductors ⇒ page 34](#)

6.1.5.5 Requirements for the power cable for secure power supply operation

- ☐ All electrical installations must be carried out in accordance with the applicable electrical standards on site and the *National Electrical Code*® ANSI/NFPA 70.
- ☐ Conductor type: copper wire
- ☐ Permissible temperature: at least 90°C (194°F)
- ☐ The conductors must be solid or stranded wire.
- ☐ Maximum cable length within the inverter: 180 mm (7.1 in)
- ☐ Conductor cross-section when using solid or stranded wire without bootlace ferrules: 1.5 mm² to 6 mm² (6 AWG to 10 AWG)
- ☐ Conductor cross-section when using bootlace ferrules: 1.5 mm² to 6 mm² (16 AWG to 14 AWG)
- ☐ Insulation stripping length: 10 mm to 12 mm (0.39 in to 0.47 in)
- ☐ Maximum length of conductors: 10 m (33 ft)

Also see:

- [Connect the utility grid along with power and signal cables for backup operation ⇒ page 41](#)

6.1.5.6 Requirements for signal cables for backup operation, MFR and rapid shutdown initiator

The cable length and quality affect the quality of the signal. Observe the following cable requirements:

- ☐ Conductor type: copper wire
- ☐ Permissible temperature: at least 90°C (194°F)
- ☐ The conductors must be solid or stranded wire.
- ☐ Maximum cable length within the inverter: 260 mm (10.3 in)
- ☐ Conductor cross-section: 0.8 mm² to 1.5 mm² (18 AWG to 16 AWG)

- ☐ Insulation stripping length: 6 mm (0.24 in)
- ☐ Nominal voltage: at least 600 V
- ☐ Maximum length of conductors: 30 m (98 ft)
- ☐ The cable type and cable-laying method must be appropriate for the application and location.

Also see:

- [Connect the utility grid along with power and signal cables for backup operation ⇒ page 41](#)

6.1.5.7 Network cable requirements

The cable length and quality affect the quality of the signal. Observe the following cable requirements:

- ☐ Cable type: 100BaseTx
- ☐ Cable category: minimum CAT5e
- ☐ Plug type: RJ45 of Cat5e or higher
- ☐ Shielding: SF/UTP, S/UTP, SF/FTP or S/FTP
- ☐ Number of insulated conductor pairs and insulated conductor cross-section: at least 2 x 2 x 0.22 mm² (2 x 2 x 24 AWG)
- ☐ Maximum cable length within the inverter: 260 mm (10.3 in)
- ☐ Maximum cable length between two nodes when using patch cables: 50 m (164 ft)
- ☐ Maximum cable length between two nodes when using installation cables: 100 m (328 ft)
- ☐ UV-resistant if installed outdoors.

Also see:

- [Connecting the Network Cable for Local Network and Energy Meter ⇒ page 44](#)

6.1.5.8 Cable specifications for RS485 connection of the energy meter

- ☐ Maximum cable length within the inverter: 260 mm (10.3 in)
- ☐ Cross-section: at least 2 x 2 x 0.22 mm² (2 x 2 x 24 AWG)
- ☐ Shielding: yes
- ☐ Twisted pair conductors
- ☐ UV-resistant if installed outdoors.
- ☐ Sheath stripping length: 50 mm (2 in)
- ☐ Insulation stripping length: 6 mm (0.24 in)
- ☐ Maximum cable length: 10 m (33 ft)

Also see:

- [Connecting the energy meter via RS485 ⇒ page 46](#)

6.1.5.9 Battery Communication Cable Requirements

The cable length and quality affect the quality of the signal. Observe the following cable requirements:

- ☐ Cable type: 100BaseTx
- ☐ Cable category: minimum CAT5e
- ☐ Plug type: RJ45 of Cat5e or higher
- ☐ Shielding: SF/UTP, S/UTP, SF/FTP or S/FTP
- ☐ Maximum cable length within the inverter: 260 mm (10.3 in)
- ☐ Number of insulated conductor pairs and insulated conductor cross-section: at least 2 x 2 x 0.34 mm² (2 x 2 x 22 AWG)

- ☐ Maximum cable length between inverter and battery when using patch and installation cables: 10 m (33 ft)
- ☐ UV-resistant for outdoor installation.

6.1.5.10 Requirements for the Battery Power Cables

- ☐ The cables must be made of copper.
- ☐ Maximum cable length within the inverter: 180 mm (7.1 in)
- ☐ Conductor cross-section: 6 mm² to 10 mm² (10 AWG to 8 AWG)
- ☐ Insulation stripping length: 12 mm (0.47 in)
- ☐ Cables can be used with or without bootlace ferrules
- ☐ Maximum permissible cable length between the inverter and the battery: 10 m (33 ft)
- ☐ The cables must be rated for a minimum voltage of 600 V.

Also see:

- [Connecting the power cable of the battery ⇒ page 57](#)

6.1.5.11 Requirements for the grounding cable for additional protective grounding


- ☐ The conductor must be solid or stranded or finely stranded wire. If finely stranded wire is used, the conductor must be double-crimped with a ring terminal lug. Make sure that no insulated conductor is visible when pulling or bending. This will ensure sufficient strain relief by means of the ring terminal lug.
- ☐ Cable cross-section: 10 mm² (6 AWG)
- ☐ The cables with regards to their ampacity, rated temperatures, operating conditions and power loss must be made in accordance with the local standards and the *National Electrical Code*® ANSI/NFPA 70.

Also see:

- [Connecting additional protective grounding ⇒ page 58](#)

6.2 Overview of the Connection Area

6.2.1 View from Below



Position	Designation
A	Enclosure opening for connecting the PV modules to input A and B
B	Enclosure opening for connecting the PV modules to input C and, depending on the power class, to input D

Position	Designation
C	Enclosure opening for battery connection
D	Enclosure opening for connecting the battery communication cable and for the rapid shut-down initiator
E	Enclosure opening for connecting an energy meter via RS485 and connection to the multi-function relay
F	Enclosure opening for connecting network cables
G	Enclosure opening for connecting to the utility grid and cables for backup operation

6.2.2 Interior View




Figure 8: Connection Area of the Inverter

Position	Designation
A	PVA, PVB, PVC and, depending on the power class, PVD terminals for connecting the PV modules
B	Connection terminals BAT+ and BAT - for battery power cables
C	Network connector BATTERY for connecting the battery communication
D	Slot E-METER for connecting an energy meter per RS485
E	Slot SPS for the signal cable of the backup operation
F	MFR slot for connection to the multifunction relay
G	Terminal block GSI for fast-stop switch connection
H	Network ports LAN-1 and LAN-2 , e.g., for connecting energy meter, router, battery communication system, communication system for other PV inverters, or other Ethernet-capable devices
I	Connection terminals AC for AC cables
J	SPS terminals for the power cable of the backup operation

Position	Designation
K	Busbar for grounding the AC connection
L	Communication assembly
M	Busbar for grounding the DC connection
N	Wi-Fi antenna socket

6.3 Electrical connection procedure

This section describes the procedure for the electrical connection of the product. It provides an overview of the steps, which must be performed in the prescribed sequence.

Procedure	See
1. Ensure that the requirements for the electrical connection are fulfilled.	Section 6.1, page 32
2. Remove the lid.	Section 9.1, page 84
3. Disconnect the inverter from voltage sources.	
4. Optional: Install SMA Backup Start	Install SMA Backup Start
5. Connect the AC conductors.	Optionally together with cables for backup operation: (see Section 6.5, page 41)
6. Connect the network cables.	
7. Optional: Connect the energy meter via RS485	Section 6.7.2, page 46
8. Optional: Connect the battery communication cable.	
9. Optional: Connect signal source to MFR	Section 6.9, page 49
10. Optional: Connecting a Rapid Shutdown Initiator to the Digital Input GSI	Section 6.10, page 51
11. Connect the PV modules.	
12. Optional: Connect the battery power cable.	

6.4 Connecting the Utility Grid

QUALIFIED PERSON

If the inverter is connected together with a product for backup operation (e.g. SMA Backup Start), the cables for backup operation should be connected together with the utility grid (see Section 6.5, page 41).

Requirements:

- ☐ The cables for connection to the utility grid must be preassembled.


Additionally required material (not included in the scope of delivery):

- ☐ 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- ☐ Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit


- 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)

Procedure:


1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Remove the filler plug from the first enclosure opening from the right.
3. If necessary, enlarge the 1st enclosure opening from the right to use a 27 mm (1 in) cable conduit. Utilize a hole punch to do this. Ensure that no shavings remain in the enclosure after expansion.
4. Insert the conduit fitting in the first enclosure opening from the right and tighten with the counter nut from the inside.




5. Run the AC conductors simultaneously through the conduit into the inverter and attach the conduit to the conduit fitting.
6. Run L1, L2 and N for the AC connection through the ferrite.




7. Secure the ferrite with a cable tie.



8. Connect the grounding conductor for the AC connection to the busbar ⊕ according to the label, as short as possible without the conductor being under tension. To do so, insert the conductor into the busbar against the stop and tighten the screw (PZ2, minimum torque 2.5 Nm).



9. Attach L1, L2, and N of the AC connection to the **AC** terminals according to the labels. To do so, stick a flathead screwdriver (4 mm (0.16 in)) into the top opening of the terminal and insert the cable into the lower opening against the stop. Then remove the screwdriver.



10. Tug lightly to ensure that all conductors are secured in the terminals.
 11. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- Requirements for the AC Grounding Conductor ⇒ page 34
- Requirements on the AC conductors ⇒ page 34
- Common Grid Configurations ⇒ page 32

6.5 Connect the utility grid along with power and signal cables for backup operation

⚠ QUALIFIED PERSON

If there are multiple inverters in the system but emergency power consumers are only connected to one of them, the emergency power consumers should be connected to the inverter configured as the System Manager.

Requirements:

- ☐ The AC cables for connecting to the utility grid, power and signal cables for backup operation must be pre-assembled (see Section 6.1.5, page 34).


Additionally required material (not included in the scope of delivery):

- ☐ For SMA Backup Secure (secure power supply operation): 1 standard commercial socket
- ☐ For SMA Backup Secure (secure power supply operation): 1 standard commercial switch
- ☐ 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- ☐ Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- ☐ 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)


Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Remove the filler plug from the first enclosure opening from the right.


3. Insert the conduit fitting in the first enclosure opening from the right and tighten with the counter nut from the inside.




4. Run the AC conductors including the signal cable and power cable for backup operation through the cable conduit into the inverter and fasten the cable conduit to the conduit fitting.




5. Run L1, L2 and N for the AC connection through the ferrite.
6. Secure the ferrite with a cable tie.




7. Connect the grounding conductor for the AC connection to the busbar \oplus according to the label, as short as possible without the conductor being under tension. To do so, insert the conductor into the busbar against the stop and tighten the screw (PZ2, minimum torque 2.5 Nm).




8. Attach L1, L2, and N of the AC connection to the **AC** terminals according to the labels. To do so, stick a flathead screwdriver (4 mm (0.16 in)) into the top opening of the terminal and insert the cable into the lower opening against the stop. Then remove the screwdriver.




9. Connect the conductors N and L of the power cable for the backup operation to the **SPS** connection terminals according to the labels.




10. Connect the grounding conductor for the AC connection to the busbar \oplus according to the label, as short as possible without the conductor being under tension. To do so, insert the conductor into the busbar against the stop and tighten the screw (PZ2, minimum torque 2.5 Nm).




11. Attach the conductors for the secure power supply operation switch to the 2-pole connector.



12. Plug the connector into the **SPS** slot. The connector must snap audibly into place.



13. **With SMA Backup Secure:** Ensure that the cable bridge for grounding the **N** conductor is installed.



14. Tug lightly to ensure that all conductors are secured in the terminals.
 15. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

6.6 Connecting the Network Cable for Local Network and Energy Meter

⚠ QUALIFIED PERSON

The following action describes how you can connect the inverter to the local network and additionally to an energy meter. If there are several inverters in the system, the energy meter should be connected to the inverter that is to be configured as the System Manager.

⚠ DANGER

Danger to life due to electric shock in case of overvoltages and if surge protection is missing

Overvoltages (e.g., in the event of a flash of lightning) can be further conducted into the building and to other connected devices in the same network via the network cables or other data cables if there is no surge protection. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Ensure that all devices in the same network and the battery are integrated into the existing surge protection.
- When laying the network cables or other data cables outdoors, it must be ensured that a suitable surge protection device is provided at the transition point of the cable from the product or the battery outdoors to the inside of a building.
- The Ethernet interface of the product is classified as "TNV-1" and offers protection against overvoltages of up to 1.5 kV.


Additionally required material (not included in the scope of delivery):

- ☐ Where required: Field-assembly RJ45 connector.
- ☐ 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- ☐ Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- ☐ 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)


Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. When using a self-assembly network cable, assemble the RJ45 connectors and connect them to the network cable (see connector documentation).
3. Remove the filler plug from the enclosure opening for connecting the network cable and the fast-stop switch.


4. Insert the conduit fitting into the opening and tighten from the inside using the counter nut.



5. Run the network cable through the conduit into the inverter.
6. Attach the conduit to the conduit fitting.



7. Plug the network cable into the **LAN-1** or **LAN-2** network port. Ensure that the network cable cannot touch the AC cables.




8. Tug lightly to ensure that the network cable is secure.
9. If the inverter is installed outdoors, install overvoltage protection for all components in the network.
10. If you would like to integrate the inverter into a local network, connect the other end of a network cable to the local network (e.g., via a router).
11. If you want to connect the inverter to an energy meter, connect the other end of the second network cable to the energy meter.
12. If you want to connect the inverter directly to another inverter, connect the other end of the second network cable to the other inverter.
13. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- [Network cable requirements](#) ⇒ page 36

6.7 Connection to RS485 terminal

6.7.1 Pin assignment of the RS485 terminal block

Terminal block	Clamping position	Assignment
	2	Data+ (D+)
	3	Not assigned
	5	Ground (GND)
	7	Data- (D-)

Also see:

- [Connecting the energy meter via RS485](#) ⇒ page 46

6.7.2 Connecting the energy meter via RS485

⚠ QUALIFIED PERSON

SMA Solar Technology AG recommends connecting the energy meter via network cable. If the energy meter is connected via RS485, the system cannot be commissioned with the 360° app exclusively – the inverter user interface must also be used.


If there are multiple inverters in the system, the SMA Energy Meter must be connected to the inverter that will be configured as System Manager.

Additionally required material (not included in the scope of delivery):

- ☐ 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- ☐ Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- ☐ 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)


Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Strip the RS485 communication cable.
3. Trim the cable shield to a length of 15 mm (0.59 in) and fold it over the cable sheath.




4. Strip the insulation off the wires.
5. If necessary, trim unused insulated conductors flush with the cable sheath or fold it over the cable sheath.
6. Remove the filler plug from the third enclosure opening from the left.


7. Insert the conduit fitting into the opening and tighten from the inside using the counter nut.




8. Guide the communication cable through the conduit into the inverter.
9. Attach the conduit to the conduit fitting.



10. Unlock the terminal points of the 4-pole terminal block.




11. Connect the conductors of the RS485 communication cable to the 4-pole terminal block. To this end, insert the conductors into the terminal points and unlock the terminal points by pressing the lever down. Observe the terminal block assignment.



12. Ensure that the conductors are plugged into the terminal points tightly by pulling slightly on the conductors.

13. Insert the 4-pole terminal strip into the jack **E-METER** connector.



14. Connect the RS485 cable to the energy meter (see energy meter manual).

15. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- Cable specifications for RS485 connection of the energy meter ⇒ page 36
- Pin assignment of the RS485 terminal block ⇒ page 46

6.8 Connecting the Data Cable of the Battery

⚠ QUALIFIED PERSON

For details on approved batteries and a circuitry overview of the battery communication connection, refer to the technical information available "Approved Batteries and Information on Battery Communication Connection" at www.SMA-Solar.com


If there are several inverters and only one battery in the system, the battery should be connected to the inverter that is to be configured as the System Manager.

Additionally required material (not included in the scope of delivery):

- Where required: Field-assembly RJ45 connector.
- Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)


Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. When using a self-assembly network cable, assemble the RJ45 connectors and connect them to the network cable (see connector documentation).
3. Remove the filler plug from the middle enclosure opening.
4. Insert the conduit fitting into the opening and tighten from the inside using the counter nut.




5. Run the network cable through the conduit into the inverter.

6. Attach the conduit to the conduit fitting.



7. Plug the network cable into the **BATTERY** network connector.




- 8. Tug lightly to ensure that the network cable is secure.
- 9. Connect the network cable to the battery (see battery manual).
- 10. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- [Network cable requirements](#) ⇒ page 36

6.9 Connection to the Multifunction Relay

6.9.1 Pin assignment MFR

Digital input	Pin	Assignment
	1	NO
	2	CO
	3	NC

6.9.2 Connect signal source to MFR

If there are several inverters in the system, the multifunction relay should be connected to the inverter that is configured as the System Manager.

Additionally required material (not included in the scope of delivery):

- ☐ 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- ☐ Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- ☐ 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)

Requirements:

- ☐ The technical requirements of the multifunction relay must be met Technical Data for Inverter.


⚠ DANGER**Danger to life due to electric shock**

When connecting signals with voltages above 30 V to the switch connection, there is a risk of life-threatening electric shock.


- Only connect signals with protective extra-low voltage (< 30 V).

Procedure:


1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Remove the filler plug from the enclosure opening for the connection of an energy meter via RS485 and the connection to the multifunction relay.
3. Guide the communication cable through the conduit into the inverter.




4. Attach the conduit to the conduit fitting.
5. Dismantle 20 mm (0.79 in) of the cable.
6. Strip the insulation off the conductor 6 mm (0.24 in).
7. Unlock the conductor inserts on the provided 3-pole connector.



8. Connect the conductors to the supplied 3-pole connector. To do so, plug the conductors into the conductor entries and close the conductor entries. Observe the connector assignment.



9. Plug the 3-pole connector into the socket **MFR** on the communication assembly. Observe the pin assignment.



10. Ensure that the connector is securely in place.
11. Ensure that all conductors are correctly connected.
12. Ensure that the conductors sit securely in the terminal points.
13. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- Requirements for signal cables for backup operation, MFR and rapid shutdown initiator ⇒ page 35

6.10 Connecting a Rapid Shutdown Initiator

6.10.1 Connection of Several Inverters to a Rapid Shutdown Initiator

Up to 3 inverters must be connected in parallel to the rapid shutdown initiator.




Figure 9: Connection of up to 3 inverters to the rapid shutdown initiator




Figure 10: Circuitry overview of up to 3 inverters to the rapid shutdown initiator

Also see:

- [Connecting a Rapid Shutdown Initiator to the Digital Input GSI ⇒ page 52](#)

6.10.2 Connecting a Rapid Shutdown Initiator to the Digital Input GSI

⚠ QUALIFIED PERSON

The DC disconnect switch of the inverter acts as the rapid shutdown initiator. To connect the SMA Rapid Shutdown Initiator (RSI-US-50) as an additional external rapid shutdown initiator, follow the instructions below. Following connection, both the DC load-break switch of the inverter and the external rapid shutdown initiator can be used. In systems with multiple inverters, the DC load-break switch of one inverter does not disconnect the other inverters in the system.

Requirements:

- ☐ The cable for connecting the external rapid shutdown initiator must be pre-assembled.
- ☐ The external rapid shutdown initiator must be mounted (see manual for the rapid shutdown initiator).


Additionally required material (not included in the scope of delivery):

- ☐ 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- ☐ Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- ☐ 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)


Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).


2. Unplug the 2-pole connector to which the DC load-break switch is connected from the **GSI** slot.




3. Insert the adapter included in the scope of delivery of the SMA Rapid Shutdown Initiator into the **GSI** connector.




4. Plug the 2-pole connector to which the DC load-break switch is connected into a slot on the adapter.




5. Remove the filler plug from the middle enclosure opening.
6. Insert a conduit fitting in the center enclosure opening and tighten with the counter nut from the inside.




7. Run the cable for connecting the external rapid shutdown initiator through the conduit into the inverter and attach the conduit to the conduit fitting.




8. Plug a 2-pole connector from the scope of delivery of the SMA Rapid Shutdown Initiator into the second slot on the adapter.



9. Attach the conductors for the rapid shutdown initiator to the 2-pole terminal block.



10. Tug lightly to ensure that the conductors are secured in the terminals.
11. If a weep hole has been added to the conduit, seal the conduit with sealing compound.
12. Switch on the rapid shutdown initiator.



13. Make further connections.
14. Commission the inverter.

Also see:

- Requirements for signal cables for backup operation, MFR and rapid shutdown initiator ⇒ page 35
- Connection of Several Inverters to a Rapid Shutdown Initiator ⇒ page 51
- Rapid Shutdown Equipment ⇒ page 22
- Rapid shutdown function ⇒ page 71

6.11 Mounting the WLAN Antenna


If the Wi-Fi range is insufficient, the signal can be enhanced with a Wi-Fi antenna.

Additionally required material:

- 1 passive Wi-Fi antenna with cable and SMB socket
- 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)

Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Remove the filler plug from the middle enclosure opening.
3. Insert a conduit fitting in the center enclosure opening and tighten with the counter nut from the inside.



4. Plug the SMB socket of the Wi-Fi antenna into the connector for the Wi-Fi antenna of the inverter.
5. Attach the conduit to the conduit fitting.
6. Ensure that the cable is secure by gently pulling on it.
7. If a weep hole has been added to the conduit, seal the conduit with sealing compound.
8. Install the antenna as far away as possible from the inverter in order to achieve a wide Wi-Fi range. Do not attach the antenna to the enclosure of the inverter.
9. **Information:** The appropriate Wi-Fi antenna is automatically selected depending on the connection quality. The currently active antenna is displayed via the instantaneous value **WiFi antenna type**.

6.12 Connecting the PV Array

⚠ QUALIFIED PERSON

NOTICE

Damage to the product due to ground fault on DC side during operation

Due to the transformerless topology of the product, the occurrence of ground faults on DC side during operation can lead to irreparable damage. Damages to the product due to a faulty or damaged DC installation are not covered by warranty. The product is equipped with a protective device that checks whether a ground fault is present during the starting sequence. The product is not protected during operation.


- Ensure that the DC installation is carried out correctly and no ground fault occurs during operation.

Additionally required material (not included in the scope of delivery):


- 1 conduit (trade size: 27 mm (1 in) or smaller with suitable reducer bush)
- Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 27 mm (1 in) or smaller with suitable reducing bush)
- If 3 or 4 strings are connected depending on the power class, additionally 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)
- If 3 or 4 strings are connected, depending on the power class, an additional rain-tight conduit fitting or conduit fitting for wet locations, complying with UL 514B, is required (trade size: 19.05 mm (0.75 in) or smaller, with a suitable reducing bush).

Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Remove the adhesive tape from the enclosure opening for connecting the PV modules to inputs A and B.




3. If more than 2 strings are connected, remove the filler plug from the second enclosure opening from the left.
4. Insert the conduit fitting into the opening and tighten from the inside using the counter nut.
5. Run the DC cables of the PV modules through the conduit into the inverter. Run the cables for **PVA** and **PVB** together through a conduit and the first enclosure opening into the inverter. If 3 or 4 strings are connected depending on the power class, run the cable for **PVC** and, if necessary, for **PVD** through a further conduit and the second enclosure opening into the inverter.




6. Attach the conduit to the conduit fitting.
7. Strip the DC cable insulation.

8. Connect the DC cables to the terminals according to the labels.



9. Connect the cable for grounding the PV modules to the busbar for grounding the DC connection (PZ2, minimum tightening torque 2.5 Nm). Verify that the stripped conductor does not protrude under the switch assembly. Otherwise, the inverter may report a ground fault.



10. Tug lightly to ensure that the cables are secured in the terminals.

11. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- Requirements for the PV Grounding Conductors ⇒ page 34
- Requirements for the PV cables ⇒ page 35
- Requirements for the PV modules per input ⇒ page 33

6.13 Connecting the power cable of the battery

⚠ QUALIFIED PERSON

If there are several inverters and only one battery in the system, the battery should be connected to the inverter that is to be configured as the System Manager.

Additionally required material (not included in the scope of delivery):

- 1 conduit (trade size: 19.05 mm (0.75 in) or smaller with suitable reducer bush)
- Sealing compound for sealing the join between the conduit and inverter if a weep hole has been added to the conduit
- 1 rain-tight conduit fitting or conduit fitting for wet locations complying with UL 514B (trade size: 19.05 mm (0.75 in) or smaller with suitable reducing bush)


Requirements:

- ☐ The battery power cables must be pre-assembled.


Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Ensure that the battery is switched off.
3. Remove the filler plug from the third enclosure opening from the left.


4. Insert the conduit fitting in the third enclosure opening from the left and tighten with the counter nut from the inside.



5. Run the battery power cables through the conduit into the inverter.



6. Attach the conduit to the conduit fitting.
7. Connect the battery power cables to the terminals for the battery connection according to the labels. To do so, insert a flathead screwdriver into the top opening of the terminal and insert the cable into the bottom opening. Then remove the screwdriver.



8. Tug lightly to ensure that the cables are secured in the terminals.
9. If a weep hole has been added to the conduit, seal the conduit with sealing compound.

Also see:

- [Requirements for the Battery Power Cables](#) ⇒ page 37

6.14 Connecting additional protective grounding

⚠ QUALIFIED PERSON


If additional protective grounding or equipotential bonding is required locally, you can connect additional protective grounding to the product. This prevents touch current if the grounding conductor at the terminal for the AC cable fails. The required M5x16 screw and washer assembly, the washer, and conical spring washer are included in the scope of delivery of the inverter.

Additionally required material:


- 1 ring terminal lug

Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).
2. Strip the grounding cable insulation.
3. Insert the stripped part of the grounding cable into the ring terminal lug and crimp using a crimping tool.



4. Insert the screw and washer assembly through the hole in the ring terminal lug and tighten the screw with a Torx screwdriver (TX25) (tightening torque: 2.5 Nm (22.2 in-lb)) at the connection point for additional grounding.

**Also see:**

- [Requirements for the grounding cable for additional protective grounding ⇒ page 37](#)

7 Commissioning

7.1 Commissioning Procedure of System with the SMA 360° App

The entire system can be configured with the SMA 360° app following the connection of the individual components. SMA Solar Technology AG recommends using the SMA 360° app to configure the system.

Procedure		See
1.	Connect and switch on all devices in the system (e.g. inverter, energy meter, battery).	Manuals for the devices Section 7.2, page 60
2.	Carry out the configuration using the commissioning wizard of the SMA 360° app.	Section 7.3, page 62
3.	Make further settings if necessary (e.g., configure multifunction relay, configure arc-fault circuit interrupter).	Section 8, page 65
4.	If the system is in a 208 V utility grid, make settings for the correct operation of the grid support functions on the System Manager user interface.	Section 7.4, page 63

Also see:

- [Settings for Grid Support Functions in 208 V Grids ⇒ page 63](#)

7.2 Switching the Inverter On


⚠ QUALIFIED PERSON

Requirements:


- ☐ The AC circuit breaker must be correctly rated and mounted.
- ☐ The inverter must be correctly mounted.
- ☐ All cables must be correctly connected.
- ☐ Unused enclosure openings must be sealed tightly with filler plugs.

Procedure:


1. Make sure that the communication cables do not touch the AC or DC cables.




2. Make sure that all EMC terminals are present and correctly attached to the enclosure. SBSE-3.8-US-50 / SBSE-4.8-US-50 / SBSE-5.8-US-50 / SBSE-7.7-US-50 have 19 EMV-terminals; SBSE9.6-US-50 / SBSE11.5-US-50 have 24 EMV terminals.



3. Make sure that cables do not protrude out of the enclosure, so that they could press against the cover when it is installed.
4. Align the cover with the enclosure and press in place with both hands.




5. Open the cover of the enclosure lock and use an Allen key to tighten the central screw until you hear an audible click. Note the direction of rotation printed on the cover.




6. Close the cover of the enclosure lock again.

☑ The enclosure cover is attached.


7. If the DC load-break switch was secured with a lock, open and remove the lock.



8. Hang the side covers on the hooks on the left and right of the mounting bracket and slide them downwards.




9. Press the side covers downwards until an audible click can be heard.



10. Make sure that the side covers are mounted correctly. Otherwise, the inverter is not protected against being prized out.
11. Switch on the battery (see battery manual).

12. Switch on the DC load-break switch of the inverter.



13. Switch on the AC circuit breaker.

14. Wait until the green LED lights up or pulses or the green and red LEDs flash simultaneously. This can take up to 5 minutes.

15. If the green and red LEDs flash simultaneously during initial commissioning, operation is stopped because no country data set has been set yet. For the inverter to begin operation, the configuration must be completed and a country data set must be set.

16. If the green LED is still flashing, the conditions for activating feed-in operation are not yet met. As soon as the conditions for feed-in operation are met, the inverter starts with feed-in operation and, depending on the available power, the green LED will light up continuously or it will pulse.

17. If the red LED lights up, an event has occurred. Find out which event has occurred and, if necessary, initiate countermeasures.

18. Ensure that the inverter feeds in correctly.

7.3 Configuring the System with the SMA 360° App

⚠ QUALIFIED PERSON

i A country data set must be set for feed-in operation

To ensure the inverter starts feed-in operation during initial commissioning, a country data set must be set (e.g., via the product commissioning wizard in the SMA 360 app or on the user interface of the product, or via a System Manager).

If no country data set is set, then feed-in operation will be stopped. This state is signaled by the green and red LEDs flashing simultaneously.

The inverter will automatically start feed-in operation only after the inverter configuration is completed.

i The country data set must be set correctly.

If you select a country data set which is not valid for your country and purpose, it can cause a disturbance in the PV system and lead to problems with the grid operator. When selecting the country data set, you must always observe the locally applicable standards and directives as well as the properties of the PV system (e.g. PV system size, grid-connection point).

- If you are not sure which standards and directives are valid for your country or purpose, contact the grid operator.

i The grid type must be set correctly

If you select the wrong grid type, it can cause a disturbance in the PV system and lead to problems with the grid operator.

Requirements:

- ☐ The inverter must be switched on.
- ☐ The latest firmware must be installed on all system components.
- ☐ An user account for Sunny Portal must already exist.

Procedure:

1. Download the SMA 360° App from the App Store or Play Store.
2. Open the SMA 360° App and login with the SMA ID.
3. For systems with multiple inverters using Wi-Fi, navigate to **Setup > Network setup** to connect subordinate inverters to the inverter's Wi-Fi network. Follow the instructions in the SMA 360° app and scan the QR code on the cover of the inverter when the app prompts you to do so. This needs to be performed for each subordinate inverter within the system.
4. To start the commissioning wizard, go to **Setup > Commissioning**.
5. Follow the SMA 360° app instructions and scan the QR code on the inverter's cover when prompted to configure it as the System Manager.
6. Select the **Inverter as System Manager** in the device settings, then continue with the app instructions.

Also see:

- [Switching the Inverter On ⇒ page 60](#)

7.4 Settings for Grid Support Functions in 208 V Grids

For the grid support functions to work correctly, the following parameters must be set to the specified values on the System Manager user interface.

Parameter	Name	Setting value for SBSE-3.8-US-50	Setting value for SBSE-4.8-US-50	Setting value for SBSE-5.8-US-50	Setting value for SBSE-7.7-US-50	Setting value for SBSE-9.6-US-50	Setting value for SBSE-11.5-US-50
Inverter.WMax	Set active power limit	3328 W	4160 W	4992 W	6656 W	8320 W	9984 W
Inverter.WMaxIn	Nominal active power WMaxIn	- 3328 W	- 4160 W	- 4992 W	- 6656 W	- 8320 W	- 9984 W
Inverter.VA-MaxOut	Nominal apparent power VA-MaxOut	3328 VA	4160 VA	4992 VA	6656 VA	8320 VA	9984 VA
Inverter.VA-MaxIn	Nominal apparent power VA-MaxIn	3328 VA	4160 VA	4992 VA	6656 VA	8320 VA	9984 VA
Inverter.VAr-MaxQ1	Nominal reactive power VAr-MaxQ1	1997 var	2496 var	2995 var	3994 var	4992 var	5990 var

Parameter	Name	Setting value for SBSE-3.8-US-50	Setting value for SBSE-4.8-US-50	Setting value for SBSE-5.8-US-50	Setting value for SBSE-7.7-US-50	Setting value for SBSE9.6-US-50	Setting value for SBSE11.5-US-50
In-verter.VAr-MaxQ2	Nominal reactive power VAr-MaxQ2	1997 var	2496 var	2995 var	3994 var	4992 var	5990 var
In-verter.VAr-MaxQ3	Nominal reactive power VAr-MaxQ3	- 1997 var	- 2496 var	- 2995 var	- 3994 var	-4992 var	-5990 var
In-verter.VAr-MaxQ4	Nominal reactive power VAr-MaxQ4	- 1997 var	- 2496 var	- 2995 var	- 3994 var	-4992 var	-5990 var

Also see:

- [Changing parameters](#) ⇒ page 70


7.5 Checking the Secure Power Supply Operation

Requirements:


- ☐ SMA Backup Start must be mounted.
- ☐ The socket and switch for the secure power supply operation must be connected.
- ☐ The inverter must be commissioned.
- ☐ **Emergency power mode** must be configured under **Configuration of the backup type**.
- ☐ If PV module switches are installed in the system that support the SunSpec communication signal for rapid shutdown systems, the rapid shutdown initiator must be configured as a digital input.
- ☐ A load must be connected to the socket for the secure power supply operation.

Procedure:

1. Switch off the AC miniature circuit breaker.
2. Turn on the switch for secure power supply operation.



3. Check whether the load connected to the socket for secure power supply operation is turning on. This can take up to 30 seconds.



4. If the load does not turn on, make sure that the socket and the switch for the secure power supply operation are correctly connected and that SMA Backup Start is properly installed. If the load still fails to turn on, contact Service.
5. Switch off the switch for secure power supply operation.
6. Switch on AC miniature circuit breaker.

Also see:

- [Setting backup operation](#) ⇒ page 72

8 Operation

8.1 Operation notes

NOTICE

High costs due to inappropriate Internet tariff

Depending on use, the data volume of the product transferred via the Internet may vary in size. The data volume depends, for example, on the number of devices in the system, the frequency of device updates, the frequency of data transfer to Sunny Portal or the use of FTP push. High costs for the Internet connection can be the result.

- SMA Solar Technology AG recommends using an Internet flat rate.
- If you do not use a flat rate, you can set the amount of data transmission in the Sunny Portal powered by EnnexOS.

The following sections describe how to control the system via the System Manager user interface. Settings made in the System Manager are transferred to other devices, e.g., lower-level inverters.

8.2 Establishing a Connection to the User Interface

8.2.1 Connection in the local network

8.2.1.1 Access addresses for the product in the local network

i DHCP Server is recommended

The DHCP server automatically assigns the appropriate network settings to your nodes in the local network. A manual network configuration is therefore not necessary. In a local network, the Internet router is usually the DHCP server. If the IP addresses in the local network are to be assigned dynamically, DHCP must be activated in the Internet router (see the Internet router manual). In order to receive the same IP address by the internet router after a restart, set the MAC address binding.

In networks where no DHCP server is active, proper IP addresses must be assigned from the free address pool of the network segment to all network participants to be integrated during commissioning.

i Communication disturbances in the local network

The IP address range 192.168.12.0 to 192.168.12.255 is occupied for communication amongst SMA products and for direct access to SMA products.

Communication problems might occur if this IP address range is used in the local network.

- Do not use the IP address range 192.168.12.0 to 192.168.12.255 in the local network.

If the product is connected to a local network (e.g. via an Internet router or Wi-Fi), the product will receive a new IP address. Depending on the type of configuration, the new IP address will be assigned automatically by the DHCP server (Internet router) or manually by you.

Upon completion of the configuration, the product can only be reached via the listed access addresses in the local network:

- Generally applicable access address: IP address manually assigned or assigned by the DHCP server (Internet router) (identification via network scanner software or network configuration of the Internet router).
- Access address: **https://SMA[serial number]** (e.g. https://SMA0123456789)

8.2.1.2 Establishing a Connection via Ethernet in the local network

Requirements:

- ☐ The product must be connected to the local network via a network cable (e.g. via a router).
- ☐ The product must be integrated into the local network. Tip: You can change the network configuration on the welcome page of the product.
- ☐ A smart device (e.g. laptop) must be available.
- ☐ The smart device must be in the same local network as the product.
- ☐ The respective latest version of one of the following web browsers must be installed on the smart device: Chrome, Edge, Firefox or Safari.

Procedure:

1. Open the web browser of your smart device.
2. Enter the access address of the product in the address bar of the web browser.

3. **i** Web browser displays warning

After the access address of the product has been entered, a message might appear indicating that the connection to the user interface of the product is not secure.

- Continue loading the user interface (scroll to bottom and click proceed/advance).
- ☒ When you connect to the user interface for the first time, the welcome page opens. The Commissioning Assistant for configuring the product can be started via the welcome page.
- ☒ The login page of the user interface opens if the product has already been configured.

Also see:

- [Access addresses for the product in the local network ⇒ page 65](#)


8.2.1.3 Establishing a Connection via WLAN in the Local Network

Requirements:

- ☐ The product must be commissioned.
- ☐ The product must be integrated into the local network. Tip: You can change the network configuration on the welcome page of the product.
- ☐ A smart device (e.g. laptop) must be available.
- ☐ The smart device must be in the same local network as the product.

- ☐ The respective latest version of one of the following web browsers must be installed on the smart device: Chrome, Edge, Firefox or Safari.

Procedure:

1. Open the web browser of your smart device.
 2. Enter the access address of the product in the address bar of the web browser.
 3.  **Web browser displays warning**
After the access address of the product has been entered, a message might appear indicating that the connection to the user interface of the product is not secure.
 - Continue loading the user interface (scroll to bottom and click proceed/advance).
- ☒ When you connect to the user interface for the first time, the welcome page opens. The Commissioning Assistant for configuring the product can be started via the welcome page.
 - ☒ The login page of the user interface opens if the product has already been configured.

Also see:

- [Access addresses for the product in the local network ⇒ page 65](#)

8.2.2 Direct connection via Wi-Fi

8.2.2.1 Connection options for Wi-Fi direct connection

You have several options to connect the product to a smart device. The procedure can be different depending on the devices. If the procedures described do not apply to your end device, establish the direct connection via Wi-Fi as described in the manual of your end device.

The following connection options are available:

- Direct Wi-Fi connection with 360° app (see Section 8.2.2.3, page 67)
- Direct Wi-Fi connection with WPS (see Section 8.2.2.4, page 68)
- Direct Wi-Fi connection with Wi-Fi network search (see Section 8.2.2.5, page 68)

Also see:

- [Establishing a direct Wi-Fi connection with the 360° app ⇒ page 67](#)

8.2.2.2 Access information for direct Wi-Fi connection

Access information for the direct WiFi connection can be found below:

- SSID: **SMA[serial number]** (e.g., SMA0123456789)
- Device-specific Wi-Fi password: WPA2-PSK (see type label of the product)
- Default access address: **https://smalogin.net** or **https://192.168.12.3**

8.2.2.3 Establishing a direct Wi-Fi connection with the 360° app

Requirements:

- ☐ A smart end device with camera must be available.
- ☐ The SMA 360° App must be installed on the smart device.
- ☐ An user account for Sunny Portal must already exist.

Procedure:

1. Open the SMA 360° App and login with the Sunny Portal account details.
2. Go to **Operation > User interface** to connect to the inverter's Wi-Fi.

3. Scan the QR Code on you product via the SMA 360° App.

- ☒ The smart device automatically connects to the product. The login page of the user interface is displayed in the 360° App.

4. If the login page of the user interface is not displayed, open the web browser and enter **https://smalogin.net** in the address bar.

Also see:

- [Access information for direct Wi-Fi connection ⇒ page 67](#)

8.2.2.4 Establishing a direct Wi-Fi connection with WPS

Requirements:

- ☐ A smart device (e.g., laptop) with WPS function must be available.

Procedure:

1. Enable the WPS function on the inverter. To do this, tap on the enclosure lid of the inverter twice.

- ☒ The blue LED flashes slowly for approx. 2 minutes. The WPS function is active during this time.

2. Ensure that the WPS function is enabled on your smart device.

3. Open the web browser of your smart end device and enter **https://smalogin.net** in the address bar.

- ☒ When you connect to the user interface for the first time, the welcome page opens. The Commissioning Assistant for configuring the product can be started via the welcome page.

- ☒ The login page of the user interface opens if the product has already been configured.

4. If the login page of the user interface does not open, enter the IP address **https://192.168.12.3** or, if your smart terminal supports mDNS services, **SMA[serial number].local** or **https://SMA[serial number]** in the address bar of the web browser.

Also see:

- [Access information for direct Wi-Fi connection ⇒ page 67](#)

8.2.2.5 Establishing direct Wi-Fi connection with Wi-Fi network search

1. Search for Wi-Fi networks with your smart device.

2. Select the SSID of the product **SMA[serial number]** in the list with the detected Wi-Fi networks.

3. Enter the device-specific Wi-Fi password (see WPA2-PSK on the type label).

4. Open the web browser of your smart end device and enter **https://smalogin.net** in the address bar.

- ☒ When you connect to the user interface for the first time, the welcome page opens. The Commissioning Assistant for configuring the product can be started via the welcome page.

- ☒ The login page of the user interface opens if the product has already been configured.

5. If the login page of the user interface does not open, enter the IP address **https://192.168.12.3** or, if your smart terminal supports mDNS services, **SMA[serial number].local** or **https://SMA[serial number]** in the address bar of the web browser.

Also see:

- [Access information for direct Wi-Fi connection ⇒ page 67](#)

8.3 WPS function

8.3.1 Connection options with WPS

You have several options to use the WPS function. Depending on the possible application of the WPS function, the procedure for activation will vary.

The following options are available:

- WPS for automatic connection to a network (e.g. via a router)
- WPS for direct connection between the product and a smart device

8.3.2 Activating WPS for automatic connection

Requirements:

- ☐ WLAN must be activated in the product.
- ☐ WPS must be activated on the router.
- ☐ The user interface is open and you are logged in.

Procedure:

1. Select the menu **Configuration**.
 2. Select **Network configuration** menu item.
 3. Click on the button **Use WPS** in the **Wi-Fi** section.
 4. Click on **[Save]**.
- ☒ The WPS function is activated and the automatic connection to the network can be established.

8.3.3 Activating WPS for direct connection to a smart device

- Tap on the enclosure lid of the product twice in direct succession.
- ☒ The WPS function is activated for about 2 minutes. Activation is indicated by a slow flashing blue LED.

8.4 Design of the User Interface




Figure 11: Design of the User Interface

Position	Designation	Description
A	Focus navigation	Enables the navigation between the following levels: <ul style="list-style-type: none">• System• Device

Position	Designation	Description
B	User settings	Provides the following functions: <ul style="list-style-type: none"> • Configuring personal data • Logout
C	System information	Displays the following information: <ul style="list-style-type: none"> • System • Device information • Licenses • eManual
D	Content Area	Displays the dashboard or content of the selected menu.
E	Configuration	Offers different views for configuration, depending on the selected level and user role.
F	Monitoring	Offers different views for monitoring, depending on the scope of the connected devices.
G	Dashboard	Displays information and instantaneous values of the device or system currently selected.
H	Home	Opens the user interface home page

8.5 Access rights to the user interface

During registration, 1 user with administrator rights is created. With administrator rights, you can add further system users who can configure user rights or delete users.

This gives users access to the system and to the devices recorded in the system.

You can assign the following roles for users:

- User
- Installer

In addition, administrator rights can be assigned for each role.

8.6 Changing parameters

The parameters of the product are set to certain values by default. You can change the parameters to optimize the performance of the product.

This section describes the basic procedure for changing parameters. Always change parameters as described in this section.

Requirements:

- ☐ The user interface of the inverter must be open and you must be logged in.
- ☐ Changes to grid-relevant parameters must be approved by the responsible grid operator, and can only be made as an **installer**.

Procedure:

1. Choose the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Parameters** menu item.
4. Call up the parameter via the search function or navigate to the parameter.

5. Change the parameter value.
6. Click on **[Save]**.

8.7 Arc-Fault Circuit Interrupter (AFCI)

⚠ QUALIFIED PERSON

You can set the arc-fault circuit interrupter using the following parameters.

Channel	Name	Settings
AfcilsOn	AFCI switched on	Yes No

You can use the following parameters to set the manual restart after an arc fault detection.

Channel	Name	Settings
Operation.ManRstr.IsOn	Manual restart activated	Yes No
Operation.ManRstr.ManRstrAFCI	Manual restart after arc detection	On Off Yes, after 5 electric arc detections within 24 hrs

Also see:

- [Arc-Fault Circuit Interrupter \(AFCI\) ⇒ page 21](#)
- [Changing parameters ⇒ page 70](#)
- [Manual restart after electric arc ⇒ page 115](#)

8.8 Rapid shutdown function

You can use the following parameters to set up the operating mode of the rapid shutdown function.

Channel	Name	Settings
Operation.RSSOpMode	Rapid Shutdown Mode	On Off SunSpec shutdown

You can use the following parameters to set which switch will act as the rapid shutdown initiator. When **Digital input** selected, a rapid shutdown initiator must be connected to the digital input **GSI**.

Channel	Name	Settings
Operation.RSSInitiator	Rapid Shutdown Initiator	AC disconnect PV system Digital input

Also see:

- [Rapid Shutdown Equipment ⇒ page 22](#)
- [Changing parameters ⇒ page 70](#)

8.9 Setting backup operation

You can use the following parameters on the user interface of the inverter to set the operating mode of the secure power supply function and battery-backup function.

Channel	Name	Settings
Operation.BckTyp	Configuration of the backup type	Off
		Emergency power mode

8.10 Setting of SMA ShadeFix

QUALIFIED PERSON

You can set the time interval in which the inverter has to determine the optimum operating point and to optimize the MPP of the PV system. The ideal time interval is usually six minutes. This value should only be increased if the shading situation changes extremely slowly.

Channel	Name	Settings
DcCfg.MPP-Shdw.CycTms	Cycle time of SMA ShadeFix	Time interval in seconds (180 s to 3600 s)

8.11 Control of external devices via Modbus

To control external devices, such as a battery, via Modbus using an additional system controller, activate the following parameter. The parameter is deactivated by default. If you activate the parameter, it is possible that SMA Energy Management will no longer function as expected because the settings via Modbus overwrite the settings from the SMA system.

Further information on control via Modbus can be found in the technical information "SMA GRID GUARD 10.0 - Grid Management Services via Inverter and System Controller" at www.SMA-Solar.com.

Channel	Name	Settings
Mb.ScclnEna	Modbus P-settings at input 2	On Off

8.12 Digital output (MFR)

8.12.1 Use of the digital output (MFR)

The digital output (MFR) can be switched depending on measured values or states.

You have several options to use the digital output.

Possible use	Category	Explanation
Notification in the event of an error	System state	System is in warning or error state.
Alarm in case of warning or error	System state	System is in error state.
Direct selling enabled	System state	The active power limitation of the direct seller is currently used for the point of interconnection.

Possible use	Category	Explanation
Battery state of charge ¹⁾	Monitoring	Balanced state of charge of all batteries in the system
System active power ¹⁾	Monitoring	Sum of the active power of all PV inverters in the system.
System reactive power ¹⁾	Monitoring	Balance of the reactive power of all selected PV inverters in the system.
Reactive power setpoint ¹⁾	Setpoints	Reactive power value to be set.
Setpoint of active power limitation ¹⁾	Setpoints	The active power value currently to be set.
Standardized measured voltage value for Q(V) ¹⁾	Grid connection point	Standardized measured voltage value from the point of interconnection. For this, you require a valid Q(V) configuration in the grid management services.
System active power (grid-supplied power) ¹⁾	Grid connection point	Currently drawn active power.
System active power (grid feed-in) ¹⁾	Grid connection point	Currently fed-in active power.
System reactive power at the grid connection point ¹⁾	Grid connection point	Current reactive power.

8.12.2 Configure the digital output (MFR)

QUALIFIED PERSON

Requirements:

- ☐ A signal source must be connected to the digital output (**MFR**).
- ☐ The inverter to which the signal source is connected, must be configured as System Manager.
- ☐ The user interface must be open and you must be logged in as **Installer**.

Procedure:

1. Select the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the menu item **I/O configurations**.
4. Select + **New I/O configuration** to add a new configuration.
5. Select the type of the I/O channel **Digital output**.
6. Select the use for the digital output.
7. If necessary, activate inversion of the signal. Observe the pin assignment of the terminal block.
8. Click on [**Save**].

¹⁾ Conditions for activating the outlet signal must be specified

8.13 Energy management

8.13.1 Predefined energy management profiles

The page of the user interface shows predefined energy management profiles that are stored in the product. These profiles form the basis for configuring the energy management.




Figure 12: Overview of predefined energy management profiles

Position	Energy management profile
A	Maximum Increased Self-Consumption
B	Peak Shaving
C	Sleep mode
D	Multiuse (combination of increased self-consumption and peak load shaving)

Also see:

- [Creating a new energy management profile ⇒ page 75](#)

8.13.2 Used energy management profiles




Figure 13: Overview of the used energy management profiles (example)

This overview shows all energy management profiles that were activated at least once before. The energy management profile currently active is highlighted.

When the energy management is started for the first time after commissioning, no energy management profiles are displayed on this page.

Also see:

- [Predefined energy management profiles ⇒ page 74](#)
- [Creating a new energy management profile ⇒ page 75](#)
- [Activating the energy management ⇒ page 76](#)
- [Deactivating the energy management ⇒ page 76](#)
- [Changing an energy management profile ⇒ page 75](#)

8.13.3 Creating a new energy management profile

QUALIFIED PERSON

When an energy management profile is created, energy management activates automatically.

Requirement:

- ☐ A suitable energy meter is installed and configured at the point of interconnection within the system.
- ☐ A battery is available in the system and has been put into operation.
- ☐ The user interface is open and you are logged in.

Procedure:

1. Select the menu item **Energy management** in the menu **Configuration**.
 - ☒ The overview of the used energy management profiles opens.
2. Select the **[Create new profile]** button.
 - ☒ The overview of the predefined energy management profiles opens.
3. Click on the profile you want.
 - ☒ In the energy management profiles **Maximum increased self-consumption** and **Sleep mode**, the selected energy management profile is activated automatically.
 - ☒ In the energy management profiles **Peak load shaving** and **Multiuse**, the page to set the parameters opens.
4. To use peak load shaving, set the parameters for the peak load shaving. Take the parameter description for peak load shaving into account.
5. To use the multiuse function, set the parameters for the multiuse function. Take the parameter description for the multiuse function into account.

Also see:

- [Predefined energy management profiles ⇒ page 74](#)
- [Used energy management profiles ⇒ page 74](#)
- [Setting options for peak load shaving ⇒ page 77](#)

8.13.4 Changing an energy management profile

QUALIFIED PERSON

A single energy management profile cannot be deactivated, only changed.

Requirements:

- ☐ At least 1 energy management profile has already been created.
- ☐ The user interface is open and you are logged in.

Procedure:

1. Log into the user interface of the product.
2. Select the menu item **Energy management** in the menu **Configuration**.
3. In the row of the required energy management profile, select the ... button.
4. Select **Activate profile**.

Also see:


- [Used energy management profiles ⇒ page 74](#)

8.13.5 Deactivating the energy management**⚠ QUALIFIED PERSON**

A single energy management profile cannot be deactivated, only changed. To deactivate the entire energy management, proceed as described in this section.

Procedure:

1. Log into the user interface of the product.
2. Select the menu item **Energy management** in the menu **Configuration**.
3. Select the slider **Activate energy management**.

**Also see:**


- [Used energy management profiles ⇒ page 74](#)

8.13.6 Activating the energy management**⚠ QUALIFIED PERSON****Requirements:**

- ☐ At least 1 energy management profile has already been created.
- ☐ The user interface is open and you are logged in.

Procedure:

1. Select the menu item **Energy management** in the menu **Configuration**.
2. Select the slider **Activate energy management**.



3. If the required energy management profile is not activated, in the row of the energy management profile, select the ... button.
4. Select **Activate profile**.

Also see:

- [Used energy management profiles ⇒ page 74](#)

8.13.7 Setting options for peak load shaving

Setting option	Explanation
Threshold value for peak load shaving	Limiting value for the grid supply from which the battery is to be used to reduce peak loads. Only whole numbers are accepted as an entry.
Billing interval in the tariff	Interval for billing the performance prices: If the tariff of your electric utility company does not specify an interval for billing the performance prices or if the interval for billing the performance prices is not known, select the Unknown option.
Adjustment	If no value is specified for the Billing interval in the tariff , the option Immediate adjustment is always active. In this case, peak load shaving is controlled according to the instantaneous value of the grid supply at the point of interconnection. If a value for the Averaging interval in the tariff is specified, the option Averaging interval can be selected. In this case, peak load shaving is controlled according to the averaging value of the grid supply at the point of interconnection. If a peak load that is too high cannot be curtailed, the resulting overload can be compensated for at another time in the averaging interval. It can happen that the inverter curtails the grid-supplied power even further than specified by the threshold for peak load shaving.
Automatic threshold adjustment	Only if a value for the Averaging interval in the tariff is specified, can the function Autom. threshold adjustment be used. If the option Adaptively increase threshold is activated and the threshold for peak load shaving could not be observed despite adjustment via the averaging interval, the threshold is automatically increased. Exceeding the original threshold specifies the measure for the adaptive increase. Optionally, the threshold for peak load shaving can be reset to the originally entered value at the end of the billing period.
Battery charge	The parameter Battery charge controls the charging behavior of the inverter during peak load shaving: If the state of charge of the battery should always be as high as possible, for example, activate or leave the option Recharge start voltage corresponds to threshold for peak load shaving activated for the parameter Battery state of charge . If recharging of the battery from the utility grid is to be avoided, for example, deactivate the option Recharge start voltage corresponds to threshold for peak load shaving and set the Recharge start voltage to 0 kW for the parameter Battery state of charge .

Also see:

- [Creating a new energy management profile ⇒ page 75](#)

8.13.8 Backup Configuration

The **Energy management** allows for detailed backup settings, including operating mode and battery reserve. Alternatively, these settings can be configured using the SMA 360° commissioning wizard.

Procedure:

1. Select **Configuration > Energy management**.
2. Select the **Configure** in the **Backup** area.
3. Make the desired settings.

8.14 Backup file

8.14.1 Function and content of the backup file

The backup file is used to transfer configuration information, e.g., when commissioning a replacement device or when restoring previously saved parameter settings.

The backup file includes the following system and device configuration data for your product:

- Grid Management Services
- Ethernet
- Energy meter
- Sunny Portal setting
- Self-defined Modbus profiles
- System password
- User interface login data
- List of connected devices

The following information is not included in the backup file:

- Notifications
- Wi-Fi data
- Historic energy and performance values

8.14.2 Creating a Backup File

Requirements:

- ☐ The user interface must be open and you must be logged in.

Procedure:

1. Select the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Update and backup** menu item.
4. Select the **[Create backup file]** button.
5. Enter a password to encrypt the backup file and confirm with **[Create and download backup file]**. Please note that the password will be needed later for importing the backup file.
 - ☒ An Ibd file with all parameter settings is downloaded.

Also see:

- [Function and content of the backup file ⇒ page 78](#)

8.14.3 Upload backup file

QUALIFIED PERSON

Requirement:

- ☐ The backup file and the corresponding password must be available.

Procedure:

1. Open the user interface.
2. Log into the user interface.
 - ☒ After you connect to the user interface of the inverter (e.g., a replacement device) for the first time, the commissioning wizard opens.
3. If the commissioning wizard does not open, reset the inverter to the default settings.
4. On the first page of the commissioning wizard in the row **Device function**, select the option [**Start restoration**].
5. Select the desired backup file and enter the backup file password.
6. Confirm with [**Upload backup file**].
 - ☒ The Ibd file with all parameter settings will be uploaded to the product. The product restarts automatically. This process can take several minutes.

Also see:

- [Resetting the product to default setting](#) ⇒ page 81
- [Function and content of the backup file](#) ⇒ page 78

8.15 Firmware Update

8.15.1 Automatically Updating the Firmware

By activating the automatic firmware update, the product searches and installs new firmware versions automatically provided an Internet connection exists. In the process, an available firmware update may take up to 48 hours.

Functional limitations during the update

While an update is being performed, the functions of the product may be limited. The product is performing a restart and may be without function at times. This process takes several minutes and cannot be canceled.

The automatic firmware update can be activated via the user interface during commissioning.

Requirements:

- ☐ The user interface must be open and you must be logged in as **Installer** or **Administrator**.

Procedure:

1. Select the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Parameters** menu item.
4. Select the value **Yes** for the parameter **Automatic updates activated**.
5. Click on [**Save**].

8.15.2 Carry out a manual firmware update

QUALIFIED PERSON

Functional limitations during the update

While an update is being performed, the functions of the product may be limited. The product is performing a restart and may be without function at times. This process takes several minutes and cannot be canceled.

Requirements:

- ☐ An update file with the desired firmware of the product must be available. You can download the update file, for example, from the product page under www.SMA-Solar.com.
- ☐ The user interface must be open and you must be logged in as **Installer**.

Procedure:

1. Select the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Update and backup** menu item.
4. In the **Manual update** area, click [**Select file**] and select the update file for the product.
 - ☒ The user interface confirms that the update file is compatible.
5. If the user interface does not confirm the compatibility of the update file, replace the update file.
6. Select [**Start update**].
7. Follow the instructions in the dialog.
 - ☒ The product is performing a restart after the firmware update.
8. Select the **Monitoring** menu.
9. Select the menu item **Event monitor**.
10. Check the events to see whether the firmware update has been completed successfully.

8.15.3 Performing the Firmware Update via SMA 360° App

QUALIFIED PERSON

A firmware update can be carried out for the Sunny Boy Smart Energy via the SMA 360° app. This is possible before configuration or during operation.

Functional limitations during the update

While an update is being performed, the functions of the product may be limited. The product is performing a restart and may be without function at times. This process takes several minutes and cannot be canceled.

Requirements:

- ☐ The inverter must be switched on (see Section 7.2, page 60).
- ☐ The SMA 360° app must be installed and open on your end device.

Procedure:

1. Select **Setup > Manual update**.
2. To download the firmware to the end device, scroll down the displayed page and select **Download firmware for SBSE**.

Tip: If you then want to update other Sunny Boy Smart Energy devices, you can skip this step as the file is already on your end device.

 - ☒ The firmware file is stored on your end device.
3. Select [**Activate scanner**] and scan the QR code on the cover of the inverter.
4. Log in with the access data for the inverter or create an administrator account.
 - ☒ The current firmware version of the inverter is displayed.
5. Click on [**Select file**] and select firmware file on your end device.
 - ☒ The new firmware version is shown.
6. Select [**Execute update**] to start update.

8.16 Device Administration

8.16.1 Register Devices

You can register new devices and add them to the system on system level. This is required, for example, if your system has been expanded.

Requirements:

- ☐ The user interface must be open and you must be logged in.

Procedure:

1. Select the system in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Device management** menu item.
4. Select the **+** button.
5. Follow the steps of the device registration wizard.

8.16.2 Delete devices

You can delete registered devices on system level.

Requirements:

- ☐ The user interface must be open and you must be logged in.

Procedure:

1. Select the system in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Device management** menu item.
4. In the row of the device to be deleted, click the **...** button.
5. Select **Delete device**.
6. Select **[Delete]** in the displayed message.

8.17 Restart the inverter via the user interface

Requirements:

- ☐ The user interface must be open and you must be logged in as **Installer**.

Procedure:

1. Choose the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Parameters** menu item.
4. Call up the parameter **Initiate device restart (Sys.DevRstr)** via the search function or navigate to the parameter.
5. Change the parameter value to **Execute**.
6. Click on **[Save]**.
 - ☒ The inverter is performing a restart.

8.18 Resetting the product to default setting

i Loss of data due to replacement or due to resetting to default settings

If the product is reset to the default settings or replaced, all data saved in the product and the admin account will be deleted. Some of the data saved in Sunny Portal can be transmitted to the product after calling up the Sunny Portal system again.

Requirements:

- ☐ The user interface must be open and you must be logged in.

Procedure:

1. Select the product in the focus navigation.
2. Select the menu **Configuration**.
3. Select the menu item **Device properties**.
4. Select the button [If you want to reset the device to the default settings, click here].
5. Select [**Reset**].

Also see:

- [Upload backup file](#) ⇒ page 78

8.19 Deleting the Admin Account

QUALIFIED PERSON

In case the password gets lost, the admin account can be reset and newly created. All system data will be retained.

Requirements:

- ☐ The Device Key on the password sheet enclosed in the documentation package must be included in the scope of delivery.
- ☐ The login page of the user interface must be open.

Procedure:

1. Select the [**Delete admin account?**] button.
2. Enter the Device Key on the password sheet enclosed in the documentation package.
3. Select [**Delete**].
- ☒ The product is performing a restart. Then a new admin account can be created.

8.20 Generating the I-V Characteristic Curve

QUALIFIED PERSON

Requirements:

- ☐ The user interface must be open and you must be logged in as **Installer**.

Procedure:

1. Select the product in the focus navigation.
2. Select the **Monitoring** menu.
3. Select the menu item **Diagnosis**.
4. Select the **I-V characteristic curve**.
5. Select [**New measurement**].
6. Use the measurement results to check whether there are any deviations or changes.
7. If necessary, carry out measures to correct the problems on the PV modules.
8. Export the results if necessary.

8.21 Enabling Speedwire Encryption

QUALIFIED PERSON

Requirements:

- ☐ All devices in the local network must be in operation and connected to the product via an Internet router.

- ☐ All devices must support the Speedwire encryption.
- ☐ The user interface must be open and you must be logged in.

Procedure:

1. Select the system in the focus navigation.
2. Select the menu **Configuration**.
3. Select the **Device management** menu item.
4. Select the **+** button.
5. Select **SMA Speedwire devices** and confirm with **[Next]**.
 - ☒ All SMA Speedwire devices in the systems are searched for and displayed.
6. Enable SMA Speedwire encryption and select **[Continue]**.
7. Assign a new system password and select **[Save]**.

8.22 Country standard

The product is not set to any country data set at the factory. While commissioning the product using the commissioning wizard, a country data set appropriate for the installation site and intended purpose must be selected for the product to start operating.

You can change the country standard via the user interface. First select the country data set and then the grid type suitable for your application.

i The country data set must be set correctly.

If you select a country data set which is not valid for your country and purpose, it can cause a disturbance in the PV system and lead to problems with the grid operator. When selecting the country data set, you must always observe the locally applicable standards and directives as well as the properties of the PV system (e.g. PV system size, grid-connection point).

- If you are not sure which standards and directives are valid for your country or purpose, contact the grid operator.

i The grid type must be set correctly

If you select the wrong grid type, it can cause a disturbance in the PV system and lead to problems with the grid operator.

Channel	Name	Settings
CntrySet	Set country standard	Selection of different country data sets
Inverter.GriTyp	Grid type	Selection of different grid types
Cntry	Country standard	Display of the currently set country data set
CntryBas	Underlying country standard	Display of the country data set on which the current settings are based
GridMs.GriTyp	Grid type	Display of the currently set grid type

8.23 Overview of Grid Types

Depending on the selected country data set, some of the listed grid types can be selected.


Designation	Explanation
GriTyp1P3W_240V_LL	Split phase and neutral conductor (1P3W) or 2 line conductors and neutral conductor (2P3W) on Stinger/High-Leg Delta transformer, nominal voltage: 240 V phase - phase
GriTyp2P2W_240V_LL	2 line conductors (2P2W), nominal voltage: 240 V line conductor - line conductor.
GriTyp2P2W_208V_LL	2 line conductors (2P2W), nominal voltage: 208 V line conductor - line conductor
GriTyp2P3W_208V_LL	2 line conductors and neutral conductor (2P3W), nominal voltage: 208 V line conductor - line conductor
GriTyp2P2W_230V_LL	2 line conductors (2P2W), nominal voltage: 230 V line conductor - line conductor

9 Disconnecting the Inverter from Voltage Sources


9.1 Remove enclosure lid

⚠ QUALIFIED PERSON

1. Ensure that the AC miniature circuit breaker is switched off and that it cannot be reconnected.
2. Ensure that the DC load-break switch of the inverter is in the **OFF** position.




3. If your country requires the DC load-break switch to be protected against reconnection, remove the side covers. To do so, release the side covers at the bottom of the inverter and slide them upward slightly to disengage from the hooks on the mounting bracket and the inverter.
4. If your country requires the DC load-break switch to be protected against reconnection, secure the DC load-break switch against reconnection with a padlock.




5. Switch off the battery or the load-break switch of the battery (see documentation of the battery manufacturer).


6. If the inverter is wet, ensure that the areas around all openings are dry and that no water can get into the inside of the inverter when it is opened.
7. Wait until the LEDs have gone out.
8. Wait 5 minutes until the capacitors inside the inverter have discharged.
9. If the enclosure cover is being opened for the first time: remove the adhesive tape from the first enclosure opening on the right.



10. Open the cover of the enclosure lock and loosen the screw in the middle with an Allen key until an audible click can be heard. Note the direction of rotation printed on the cover.



11. Remove the enclosure cover and place it to one side.



12. Check that the inverter is de-energized.

9.2 Check that the inverter is de-energized

⚠ QUALIFIED PERSON

Before carrying out any work on the inverter, always check that the inverter is de-energized as described in this section. Always adhere to the prescribed sequence.

⚠ WARNING

Danger to life due to electric shock from destruction of the measuring device due to overvoltage

Overvoltage can damage a measuring device and result in voltage being present in the enclosure of the measuring device. Touching the live enclosure of the measuring device results in death or lethal injuries due to electric shock.


- Only use measuring devices with a measurement ranges designed for the maximum AC and DC voltage of the inverter.
- Only use measuring devices with measurement ranges designed for the maximum DC voltage of the battery.

Requirement:


- ☐ The enclosure cover must be removed (see Section 9.1, page 84).

Procedure:

1. Use a current clamp to check that no current is present in the DC conductors for the PV modules.




2. Use a current clamp to ensure that no current is present in the DC conductors for the battery.




3. Note the positions of the DC conductors.


4. Disconnect 1 DC conductor from the terminals and immediately insulate it to prevent contact between the stripped conductors. Repeat the procedure for each DC conductor.




5. Verify the absence of voltage at all terminals between **PV+** and **PV-** using a suitable voltage detector.




6. Verify the absence of voltage between the **PVA+** and **PE** terminals, as well as between **PV-** and **PE**, on the busbar used for grounding the PV modules.



7. Use a suitable voltage detector to ensure that there is no voltage between the connection terminals **BAT+** and **BAT-**.
8. Verify the absence of voltage between the **BAT+** and **PE** terminals, and between the **BAT-** and **PE** terminals, on the busbar used for grounding PV modules, using an appropriate voltage detector.
9. Make sure there is no voltage at the **AC** terminals between **L1** and **N** as well as between **L2** and **N**.



10. Make sure there is no voltage between **L1** and **L2** on the **AC** terminals and **PE** on the busbar for grounding the AC connection.



10 Cleaning

System components exposed to soiling must be cleaned regularly to ensure that all products are free of dust, leaves, and other dirt.

NOTICE

Damage to the product due to cleaning agents

The use of cleaning agents may cause damage to the product and its components.

- Clean the product and all its components only with a cloth moistened with clear water.

NOTICE

Yield reduction due to dirty cooling fins

The power output of the inverter is reduced if the cooling fins are very dirty.

- Clean the cooling fins of the inverter.

11 Troubleshooting

11.1 Event messages

11.1.1 Event 101

⚠ QUALIFIED PERSON

Event message:

- **Grid incident**

Explanation:

The grid voltage or grid impedance at the connection point of the inverter is too high. The inverter has disconnected from the utility grid.

Corrective measures:

- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.2 Event 102

QUALIFIED PERSON

Event message:

- Grid incident

Explanation:

The grid voltage or grid impedance at the connection point of the inverter is too high. The inverter has disconnected from the utility grid.

Corrective measures:

- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.3 Event 103

QUALIFIED PERSON

Event message:

- Grid incident

Explanation:

The grid voltage or grid impedance at the connection point of the inverter is too high. The inverter has disconnected from the utility grid.

Corrective measures:

- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.4 Event 105

QUALIFIED PERSON

Event message:

- Grid incident

Explanation:

The grid voltage or grid impedance at the connection point of the inverter is too high. The inverter has disconnected from the utility grid.

Corrective measures:

- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.5 Event 202**⚠ QUALIFIED PERSON****Event message:**

- **Grid incident**

Explanation:

The utility grid has been disconnected, the AC cable is damaged or the grid voltage at the connection point of the inverter is too low. The inverter has disconnected from the utility grid.

Corrective measures:

- Ensure that the miniature circuit breaker is switched on.
- Ensure that the AC cable is not damaged and that it is connected correctly.
- Ensure that the country data set has been configured correctly.
- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.6 Event 203**⚠ QUALIFIED PERSON****Event message:**

- **Grid incident**

Explanation:

The utility grid has been disconnected, the AC cable is damaged or the grid voltage at the connection point of the inverter is too low. The inverter has disconnected from the utility grid.

Corrective measures:

- Ensure that the miniature circuit breaker is switched on.
- Ensure that the AC cable is not damaged and that it is connected correctly.
- Ensure that the country data set has been configured correctly.

- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.7 Event 206

QUALIFIED PERSON

Event message:

- **Grid incident**

Explanation:

The utility grid has been disconnected, the AC cable is damaged or the grid voltage at the connection point of the inverter is too low. The inverter has disconnected from the utility grid.

Corrective measures:

- Ensure that the miniature circuit breaker is switched on.
- Ensure that the AC cable is not damaged and that it is connected correctly.
- Ensure that the country data set has been configured correctly.
- Check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.8 Event 301

QUALIFIED PERSON

Event message:

- **Grid incident**

Explanation:

The ten-minute average value of the grid voltage is no longer within the permissible range. The grid voltage or grid impedance at the connection point is too high. The inverter disconnects from the utility grid to maintain power quality.

Corrective measures:

- During the feed-in operation, check whether the grid voltage at the connection point of the inverter is permanently in the permissible range.
If the grid voltage is outside the permissible range due to local grid conditions, contact the grid operator. The grid operator must agree with an adjustment of the voltage at the feed-in point or with a change of the monitored operating limits.
If the grid voltage is permanently within the permissible range and this message is still displayed, contact the Service.

11.1.9 Event 302

QUALIFIED PERSON

Event message:

- **Active power limited AC voltage**

Explanation:

The inverter has reduced its power due to a too-high grid voltage to ensure grid stability.

Corrective measures:

- If possible, check the grid voltage and observe how often fluctuations occur. If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter. If the grid operator gives approval, discuss any changes to the operating parameters with the Service.

11.1.10 Event 401

QUALIFIED PERSON

Event message:

- **Grid incident**

Explanation:

The inverter has disconnected from the utility grid. A stand-alone grid or a very large change in the grid frequency was detected.

Corrective measures:

- Make sure there is no power outage or work being done on the utility grid and contact a grid operator if necessary.
- Check the grid connection for significant short-term frequency fluctuations.

11.1.11 Event 404

QUALIFIED PERSON

Event message:

- **Grid incident**

Explanation:

The inverter has disconnected from the utility grid. A stand-alone grid or a very large change in the grid frequency was detected.

Corrective measures:

- Make sure there is no power outage or work being done on the utility grid and contact a grid operator if necessary.
- Check the grid connection for significant short-term frequency fluctuations.

11.1.12 Event 501

QUALIFIED PERSON

Event message:

- **Grid incident**

Explanation:

The grid frequency is not within the permissible range. The inverter has disconnected from the utility grid.

Corrective measures:

- If possible, check the grid frequency and observe how often fluctuations occur.
If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter.
If the grid operator gives approval, discuss any changes to the operating parameters with the Service.

11.1.13 Event 507**⚠ QUALIFIED PERSON****Event message:**

- **Active power limit AC frequency**

Explanation:

The inverter has reduced its power due to a too-high grid frequency to ensure grid stability.

Corrective measures:

- If possible, check the grid frequency and observe how often fluctuations occur. If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter. If the grid operator gives approval, discuss any changes to the operating parameters with the Service.

11.1.14 Event 601**⚠ QUALIFIED PERSON****Event message:**

- **Grid incident**

Explanation:

The inverter has detected an excessively high proportion of direct current in the grid current.

Corrective measures:

- Check the grid connection for direct current.
- If this message is displayed frequently, contact the grid operator and check whether the monitoring threshold on the inverter can be raised.

11.1.15 Event 701**⚠ QUALIFIED PERSON****Event message:**

- **Frequency not permitted**
- **Check parameter**

Explanation:

The grid frequency is not within the permissible range. The inverter has disconnected from the utility grid.

Corrective measures:

- Check the AC wiring from the inverter to the feed-in meter.

- If possible, check the grid frequency and observe how often fluctuations occur.
If fluctuations occur frequently and this message is displayed often, contact the grid operator and request approval to change the operating parameters of the inverter.
If the grid operator gives approval, discuss any changes to the operating parameters with the Service.

11.1.16 Event 901

QUALIFIED PERSON

Event message:

- **PE connection missing**
- **Check connection**

Explanation:

The grounding conductor is not correctly connected.

Corrective measures:

- Ensure that the grounding conductor is correctly connected.

11.1.17 Event 1001

QUALIFIED PERSON

Event message:

- **L / N swapped**

Explanation:

Incorrect installation of the L / N connection.

Corrective measures:

- Check the AC wiring from the inverter to the feed-in meter.
- Check the AC voltages on the inverter connection.
- If this message is still displayed, contact the Service.

11.1.18 Event 1101

QUALIFIED PERSON

Event message:

- **Installation error**
- **Check connection**

Explanation:

A second line conductor is connected to N.

Corrective measures:

- Connect the neutral conductor to N.

11.1.19 Event 1302

QUALIFIED PERSON

Event message:

- **Waiting for grid voltage**
- **Grid connection installation failure**
- **Check grid and fuses**

Explanation:

Either L or N is not connected, or the utility grid has failed.

Corrective measures:

- Ensure that there is no utility grid failure.
- Ensure that the line conductors are connected.
- Ensure that the miniature circuit breaker is switched on.
- Ensure that the AC cable is not damaged and that it is connected correctly.

11.1.20 Event 1501

QUALIFIED PERSON

Event message:

- **Reconnection fault grid**

Explanation:

The changed country standard or the value of a parameter you have set does not correspond to the local requirements. The inverter cannot connect to the utility grid.

Corrective measures:

- Ensure that the country data set has been configured correctly. To do this, select the parameter **Set country standard** and check the value.

11.1.21 Event 3302

QUALIFIED PERSON

Event message:

- **Unstable operation**

Explanation:

There is not enough power at the DC input of the inverter for stable operation. The inverter cannot connect to the utility grid.

Corrective measures:

- Ensure that the PV module is dimensioned correctly.
- Ensure that the PV module is not covered by snow or otherwise shaded.
- Ensure that the PV module is free of defects.
- Ensure that the battery is fault-free.

11.1.22 Event 3303

QUALIFIED PERSON

Event message:

- Unstable operation

Explanation:

There is not enough power at the DC input of the inverter for stable operation. The inverter cannot connect to the utility grid.

Corrective measures:

- Ensure that the PV module is dimensioned correctly.
- Ensure that the PV module is not covered by snow or otherwise shaded.
- Ensure that the PV module is free of defects.
- Ensure that the battery is fault-free.

11.1.23 Event 3401

QUALIFIED PERSON

Event message:

- DC overvoltage
- Disconnecting generator

Explanation:

Overvoltage at the DC input. This can destroy the inverter.

Corrective measures:

- **Immediately** disconnect the inverter from all voltage sources.
- Check whether the DC voltage is below the maximum input voltage of the inverter. If the DC voltage is below the maximum input voltage of the inverter, reconnect the DC cables to the inverter.
- If the DC voltage is above the maximum DC voltage of the inverter, ensure that the correct battery has been selected.
- If the DC voltage exceeds the maximum input voltage of the inverter, ensure that the PV array has been correctly rated or contact the installer of the PV array.
- If this message is repeated frequently, contact the Service.

11.1.24 Event 3402

QUALIFIED PERSON

Event message:

- DC overvoltage
- Disconnecting generator

Explanation:

Overvoltage at the DC input. This can destroy the inverter.

Corrective measures:

- **Immediately** disconnect the inverter from all voltage sources.

- Check whether the DC voltage is below the maximum input voltage of the inverter. If the DC voltage is below the maximum input voltage of the inverter, reconnect the DC cables to the inverter.
- If the DC voltage is above the maximum DC voltage of the inverter, ensure that the correct battery has been selected.
- If the DC voltage exceeds the maximum input voltage of the inverter, ensure that the PV array has been correctly rated or contact the installer of the PV array.
- If this message is repeated frequently, contact the Service.

11.1.25 Event 3407

QUALIFIED PERSON

Event message:

- **DC overvoltage**
- **Disconnect generator**

Explanation:

Overvoltage at the DC input. This can destroy the inverter.

This message is signalized additionally by rapid flashing of the LEDs.

Corrective measures:

- **Immediately** disconnect the inverter from voltage sources and secure it against being switched on again.
- Check whether the DC voltage is below the maximum input voltage of the inverter. If the DC voltage is below the maximum input voltage of the inverter, reconnect the DC cables to the inverter.
- If the DC voltage exceeds the maximum input voltage of the inverter, ensure that the PV array has been correctly rated or contact the installer of the PV array.
- If this message is repeated frequently, contact the Service.

11.1.26 Event 3410

QUALIFIED PERSON

Event message:

- **DC overvoltage**
- **Disconnect generator**

Explanation:

Overvoltage at the DC input. This can destroy the inverter.

This message is signalized additionally by rapid flashing of the LEDs.

Corrective measures:

- **Immediately** disconnect the inverter from voltage sources and secure it against being switched on again.
- Check whether the DC voltage is below the maximum input voltage of the inverter. If the DC voltage is below the maximum input voltage of the inverter, reconnect the DC cables to the inverter.
- If the DC voltage exceeds the maximum input voltage of the inverter, ensure that the PV array has been correctly rated or contact the installer of the PV array.
- If this message is repeated frequently, contact the Service.

11.1.27 Event 3411

QUALIFIED PERSON

Event message:

- DC overvoltage
- Disconnect generator

Explanation:

Overvoltage at the DC input. This can destroy the inverter.

This message is signaled additionally by rapid flashing of the LEDs.

Corrective measures:

- **Immediately** disconnect the inverter from voltage sources and secure it against being switched on again.
- Check whether the DC voltage is below the maximum input voltage of the inverter. If the DC voltage is below the maximum input voltage of the inverter, reconnect the DC cables to the inverter.
- If the DC voltage exceeds the maximum input voltage of the inverter, ensure that the PV array has been correctly rated or contact the installer of the PV array.
- If this message is repeated frequently, contact the Service.

11.1.28 Event 3501

QUALIFIED PERSON

Event message:

- Ground fault
- Check generator

Explanation:

The inverter has detected a ground fault on the DC side.

Corrective measures:

- Check the PV system for ground faults.
- Check the battery and DC cabling for ground faults.
- Perform a visual check to ensure that the DC cabling is free of faults.

11.1.29 Event 3523

Event message:

- Start of cyclic insulation test

Explanation:

During the cyclic insulation test, it is tested whether the electric strength of the battery and PV system is within the safe range. The inverter will be restarted once during an insulation test.

11.1.30 Event 3601

QUALIFIED PERSON

Event message:

- High leakage current
- Check generator

Explanation:

The leakage current of the inverter and the PV modules or the battery is too high. There is a ground fault, a residual current or a malfunction.

The inverter interrupts feed-in operation immediately after exceeding a threshold. When the fault is eliminated, the inverter automatically reconnects to the utility grid.

Corrective measures:

- Check the PV system for ground faults.
- Check the battery and DC cabling for ground faults.

11.1.31 Event 3701**⚠ QUALIFIED PERSON****Event message:**

- Residual current too high
- Check generator

Explanation:

The inverter detected a residual current due to brief grounding of the PV modules, the battery, or the DC wiring.

Corrective measures:

- Check the PV system for ground faults.
- Check the battery and DC cabling for ground faults.

11.1.32 Event 3901**⚠ QUALIFIED PERSON****Event message:**

- Waiting for DC start conditions
- Start conditions not met

Explanation:

The feed-in conditions for the utility grid are not yet fulfilled.

Corrective measures:

- Check whether a new firmware version is available for the inverter and the battery. If a newer version is available, perform the firmware update.
- Ensure that the PV module is not covered by snow or otherwise shaded.
- Wait for higher irradiation.
- If this message is displayed frequently in the morning, increase the voltage limit for starting grid feed-in. Change the parameter **Critical voltage to start feed-in**.
- If this message is displayed frequently with medium irradiation, ensure that the PV module is correctly rated.

11.1.33 Event 3902**⚠ QUALIFIED PERSON****Event message:**

- Waiting for DC start conditions

- Start conditions not met

Explanation:

The feed-in conditions for the utility grid are not yet fulfilled.

Corrective measures:

- Check whether a new firmware version is available for the inverter and the battery. If a newer version is available, perform the firmware update.
- Ensure that the PV module is not covered by snow or otherwise shaded.
- Wait for higher irradiation.
- If this message is displayed frequently in the morning, increase the voltage limit for starting grid feed-in. Change the parameter **Critical voltage to start feed-in**.
- If this message is displayed frequently with medium irradiation, ensure that the PV module is correctly rated.

11.1.34 Event 4013

QUALIFIED PERSON

Event message:

- Reverse currents or input X polarity reversed
- Check generator

Explanation:

The displayed input is in reverse polarity or reverse current has been detected in the input.

Corrective measures:

- Check the correct polarity of the connected PV modules.
- Ensure correct design and circuitry of the PV array.
- If solar irradiation is sufficient, check whether the same voltage is present at the DC inputs.
- Ensure that no PV module is defective.

11.1.35 Event 4014

QUALIFIED PERSON

Event message:

- Reverse currents or input X polarity reversed
- Check generator

Explanation:

The displayed input is in reverse polarity or reverse current has been detected in the input.

Corrective measures:

- Check the correct polarity of the connected PV modules.
- Ensure correct design and circuitry of the PV array.
- If solar irradiation is sufficient, check whether the same voltage is present at the DC inputs.
- Ensure that no PV module is defective.

11.1.36 Event 4015

QUALIFIED PERSON

Event message:

- Reverse currents or input X polarity reversed
- Check generator

Explanation:

The displayed input is in reverse polarity or reverse current has been detected in the input.

Corrective measures:

- Check the correct polarity of the connected PV modules.
- Ensure correct design and circuitry of the PV array.
- If solar irradiation is sufficient, check whether the same voltage is present at the DC inputs.
- Ensure that no PV module is defective.

11.1.37 Event 4016

QUALIFIED PERSON

Event message:

- Reverse currents or input X polarity reversed
- Check generator

Explanation:

The displayed input is in reverse polarity or reverse current has been detected in the input.

Corrective measures:

- Check the correct polarity of the connected PV modules.
- Ensure correct design and circuitry of the PV array.
- If solar irradiation is sufficient, check whether the same voltage is present at the DC inputs.
- Ensure that no PV module is defective.

11.1.38 Event 4017

QUALIFIED PERSON

Event message:

- Reverse currents or input X polarity reversed
- Check generator

Explanation:

The displayed input is in reverse polarity or reverse current has been detected in the input.

Corrective measures:

- Check the correct polarity of the connected PV modules.
- Ensure correct design and circuitry of the PV array.
- If solar irradiation is sufficient, check whether the same voltage is present at the DC inputs.
- Ensure that no PV module is defective.

11.1.39 Event 4301

QUALIFIED PERSON

Event message:

- Serial el.arc in String |s0| detected by AFCI mod.

Explanation:

The inverter has detected an electric arc in the displayed string. If "String N/A" is displayed, the string could not be uniquely assigned.

The inverter stops feeding into the utility grid.

Corrective measures:

- Disconnect the inverter from voltage sources and secure it against being switched on again.
- Check the PV modules and the cabling in the affected string or, if the string was not displayed, in all strings for damage.
- Ensure that the DC connection in the inverter is correct.
- Repair or replace defective PV modules, DC cables or the DC connection in the inverter.
- Start manual restart (if necessary).

11.1.40 Event 6001-6499

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Interference device

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.41 Event 6501

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Overtemperature

Explanation:

The inverter has switched off due to excessive temperature.

Corrective measures:

- Clean the cooling fins on the rear of the enclosure and the air ducts on the top using a soft brush.
- Ensure that the inverter has sufficient ventilation.
- Ensure the maximum ambient temperature is not exceeded.

11.1.42 Event 6502

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Overtemperature

Explanation:

The inverter has switched off due to excessive temperature.

Corrective measures:

- Clean the cooling fins on the rear of the enclosure and the air ducts on the top using a soft brush.
- Ensure that the inverter has sufficient ventilation.
- Ensure that the maximum permissible ambient temperature is complied with.

11.1.43 Event 6509

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Overtemperature

Explanation:

The inverter has switched off due to excessive temperature.

Corrective measures:

- Clean the cooling fins on the rear of the enclosure and the air ducts on the top using a soft brush.
- Ensure that the inverter has sufficient ventilation.
- Ensure the maximum ambient temperature is not exceeded.

11.1.44 Event 6511

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Overtemperature

Explanation:

An overtemperature has been detected in the choke area.

Corrective measures:

- Clean the cooling fins on the rear of the enclosure and the air ducts on the top using a soft brush.
- Ensure that the inverter has sufficient ventilation.

11.1.45 Event 6512

Event message:

- Minimum operating temperature not reached

Explanation:

The inverter will only recommence grid feed-in once the temperature has reached at least -25°C .

11.1.46 Event 6602**⚠ QUALIFIED PERSON****Event message:**

- Overvoltage grid (SW)

Explanation:

The effective value of the grid voltage is above the permitted voltage threshold values for a specified period of time (AF limit).

Corrective measures:

- Check the grid voltage and connection on the inverter.
If the grid voltage lies outside the permissible range due to local grid conditions, ask your grid operator if the voltage can be adjusted at the feed-in point or if it would be acceptable to change the monitored operating limits.

11.1.47 Event 6606**⚠ QUALIFIED PERSON****Event message:**

- Self-diagnosis
- Device fault

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.48 Event 6633**⚠ QUALIFIED PERSON****Event message:**

- Self-diagnosis
- Device fault

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact the Service.

11.1.49 Event 6801**⚠ QUALIFIED PERSON****Event message:**

- Self-diagnosis

- Input A defective

Explanation:

The inverter has detected an error at DC input A.

Corrective measures:

- Check whether a string is connected to input A.
- Contact Service.

11.1.50 Event 6901

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Input B defective

Explanation:

The inverter has detected an error at DC input B.

Corrective measures:

- Check whether a string is connected to input B.
- Contact Service.

11.1.51 Event 7001

QUALIFIED PERSON

Event message:

- Fault sensor interior temperature

Explanation:

A temperature sensor in the inverter is defective and the inverter interrupts the feed-in operation. The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.52 Event 7002

QUALIFIED PERSON

Event message:

- Fault sensor interior temperature

Explanation:

A temperature sensor in the inverter is defective and the inverter interrupts the feed-in operation. The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.53 Event 7014

QUALIFIED PERSON

Event message:

- Fault boost converter temperature sensor

Explanation:

Fan is always on.

Corrective measures:

- Contact Service.

11.1.54 Event 7015

QUALIFIED PERSON

Event message:

- Fault sensor interior temperature

Explanation:

A temperature sensor in the inverter is defective and the inverter interrupts the feed-in operation. The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.55 Event 7702

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Interference device

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.56 Event 7703

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Interference device

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.57 Event 8003

QUALIFIED PERSON

Event message:

- Temperature derating

Explanation:

The inverter has reduced its power output for more than 10 minutes due to excessive temperature.

Corrective measures:

- Clean the cooling fins on the rear of the enclosure and the air ducts on the top using a soft brush.
- Ensure that the inverter has sufficient ventilation.
- Ensure the maximum ambient temperature is not exceeded.
- Ensure that the inverter is not exposed to direct solar irradiation.

11.1.58 Event 8104

QUALIFIED PERSON

Event message:

- Communication impaired

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.59 Event 8205

QUALIFIED PERSON

Event message:

- AFCI self-test successful

Explanation:

The self-test of SMA ArcFix has been completed successfully.

11.1.60 Event 8503

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Input C defective

Explanation:

Polarity error on the inverter.

Corrective measures:

- Check whether a string is connected to input C. If a string that once was connected is not used anymore, the string-failure detection must be reset.

- Contact Service.

11.1.61 Event 8708

QUALIFIED PERSON

Event message:

- Timeout in communication for active power limitation

Explanation:

Communication to the system control absent. Depending on the fallback setting, either the last received values will be retained or the active power will be limited to the set percentage value of the inverter nominal power.

Corrective measures:

- Ensure that the connection to the System Manager is intact and that no cables are damaged or that no plugs have been pulled.

11.1.62 Event 8709

QUALIFIED PERSON

Event message:

- Timeout in communication for reactive power spec.

Explanation:

Communication to the system control absent. Depending on the fallback setting, either the last received values will be retained or the active power will be limited to the set percentage value of the inverter nominal power.

Corrective measures:

- Ensure that the connection to the System Manager is intact and that no cables are damaged or that no plugs have been pulled.

11.1.63 Event 8710

QUALIFIED PERSON

Event number:

- Timeout in communication for cos-Phi spec.

Explanation:

Communication to the system control absent.

Corrective measures:

- Ensure that the connection to the System Manager is intact and that no cables are damaged or that no plugs have been pulled.

11.1.64 Event 9007

QUALIFIED PERSON

Event message:

- Abort self-test

Explanation:

The self-test was terminated.

Corrective measures:

- Ensure that the AC connection is correct.
- Ensure that the country data set has been entered correctly.
- Restart the self-test.

11.1.65 Event 9033**⚠ QUALIFIED PERSON****Event message:**

- **Rapid shutdown has been triggered**

Explanation:

The inverter detected the triggering of a rapid shutdown. The AC side of the inverter has been disconnected or the external rapid shutdown initiator has been activated. The PV inputs are discharged and the battery is switched off.

11.1.66 Event 9034**⚠ QUALIFIED PERSON****Event message:**

- **Error in the rapid shutdown system**

Explanation:

This message can have the following causes:

- The rapid shutdown function was not correctly configured.
- The PV module could not be correctly disconnected. Voltage can be applied to the DC inputs of the inverter.
- The standby voltage of all PV module switches of a string is $> 30\text{ V}$.
- With DC lines laid in parallel, another inverter in the system has caused the Sunspec signal to be overwritten.

Corrective measures:

- Check the settings of the rapid shutdown function and ensure that the operating mode selected is selected according to the DC disconnection unit used.
- Check the functionality of the PV module switches.
- Check the standby voltage of the PV module switches used and ensure that the standby voltage of all PV module switches of a string $< 30\text{ V}$.

11.1.67 Event 9035**⚠ QUALIFIED PERSON****Event message:**

- **Rapid shutdown performed successfully**

Explanation:

The voltage at the DC inputs and at the AC output of the inverter was successfully discharged. The battery was switched off.

11.1.68 Event 9037

QUALIFIED PERSON

Event message:

- Generator not connected

Explanation:

The PV module switches did not connect the PV module.

Corrective measures:

- Check the functionality of the SunSpec-compliant PV module switches.

11.1.69 Event 9038

QUALIFIED PERSON

Event message:

- Redundant rapid shutdown discharge function not assured

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.70 Event 9101

QUALIFIED PERSON

Event message:

- AC voltage calibration failed.

Explanation:

An error has occurred during calibration. The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.71 Event 9107

QUALIFIED PERSON

Event message:

- Self-diagnosis
- Interference device

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact Service.

11.1.72 Event 9202

QUALIFIED PERSON

Event message:

- SPS AC overvoltage

Explanation:

The cause must be determined by the Service.

Corrective measures:

- Contact the Service.

11.1.73 Event 9203

QUALIFIED PERSON

Event message:

- Short circuit in the SPS power outlet

Explanation:

A short circuit occurred at the socket for manual secure power supply operation.

Corrective measures:

- Ensure that the socket is correctly wired.
- Ensure that the load connected to the socket is working correctly.
- Unplug the load from the socket and switch on secure power supply operation.

11.1.74 Event 9214

Event message:

- Black start battery voltage too low

Explanation:

The battery of the SMA Backup Start modules in the inverter is completely discharged. SMA Backup Start must be replaced.

Corrective measures:

- Remove the defective SMA Backup Start module from the inverter and install a new module.

11.1.75 Event 9342

QUALIFIED PERSON

Event message:

- DC connection, polarity reversed
- Check connection

Explanation:

The DC conductors are not assigned to the correct inputs in the inverter.

Corrective measures:

- Ensure that all DC conductors for PV and battery are connected to the correct terminals.

11.1.76 Event 9345

QUALIFIED PERSON

Event message:

- **Battery charge too low for start procedure**

Explanation:

The state of charge of the battery is too low for the start process. The inverter can no longer charge the battery by itself. The battery must be charged immediately by a qualified person.

Corrective measures:

- If a battery from SMA Solar Technology AG is used, contact Service and instruct them to manually charge the battery.
- If a battery from another manufacturer is used, contact the manufacturer.

11.1.77 Event 9350

QUALIFIED PERSON

Event message:

- Timeout for battery status change

Explanation:

A requested status change of the battery did not occur within the specified time.

Corrective measures:

- Ensure that the battery is switched on.
- Ensure that the battery is fault-free.
- Ensure that the battery communication cable is correctly assembled and connected.

11.1.78 Event 9394

Event message:

- Deep discharge protection activated

Explanation:

The battery management system has activated the deep discharge protection. For grid-connected systems, this message is an event message, not a warning message.

11.1.79 Event 9395

Event message:

- Battery separated externally

Explanation:

The DC power connection to the battery was disconnected.

11.1.80 Event 29252

Event message:

- **SPS mode not available**

Explanation:

SPS mode is not started because the connection to the utility grid is still active.

Corrective measures:

- Verify that the utility grid is down or that the AC power supply to the inverter has been disconnected using the AC circuit breaker.
- Ensure that the parameter settings for backup operation are properly configured.

11.1.81 Event 29254**Event message:**

- **Input power for SPS too low**

Explanation:

The battery and PV power are not sufficient to supply the SPS load.

Corrective measures:

- Ensure that sufficient PV power is available.
- Ensure that the battery is charged correctly.
- Reduce the SPS load.

11.2 Create Diagnostics Data

Download the diagnostic data of the device in case of failure. Diagnostic data makes it easier for SMA Service to analyze errors.

Requirements:

- ☐ The user interface must be open and you must be logged in.

Procedure:

1. Select the product in the focus navigation.
2. In the **Monitoring** menu, select **Diagnostics**.
3. Select **Diagnostic data**.
4. Select the required values and click **[Download]**.
5. Provide diagnostic data to the SMA Service.

11.3 Calculating the insulation resistance

The expected total resistance of the PV system or of an individual string can be calculated using the following formula:

The exact insulation resistance of a PV module can be obtained from the module manufacturer or the datasheet.

$$\frac{1}{R_{\text{total}}} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \dots$$

The exact insulation resistance of a PV module can be obtained from the module manufacturer or the datasheet.

For the resistance of a PV module an average value can be assumed: for thin-film PV modules approximately 40 MOhm and for polycrystalline and monocrystalline PV modules approximately 50 MOhm per PV module.

Also see:

- [Checking the PV System for Ground Faults](#) ⇒ page 114

11.4 Checking the PV System for Ground Faults

⚠ QUALIFIED PERSON

If the red LED is glowing and the event number 3501, 3601 or 3701 is being displayed in the **Results** menu on the inverter user interface, there may be a ground fault present. The electrical insulation from the PV system to ground is defective or insufficient.

⚠ DANGER

Danger to life due to electric shock when touching live system components in case of a ground fault

If a ground fault occurs, parts of the system may still be live. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Disconnect the product and battery from voltage sources and make sure it cannot be reconnected before working on the device.
- Only touch the cables of the PV modules on their insulation.
- Do not touch any parts of the substructure or frame of the PV array.
- Do not connect PV strings with ground faults to the inverter.
- Ensure that no voltage is present and wait 5 minutes before touching any parts of the PV system or the product.

⚠ WARNING

Danger to life due to electric shock from destruction of the measuring device due to overvoltage

Overvoltage can damage a measuring device and result in voltage being present in the enclosure of the measuring device. Touching the live enclosure of the measuring device results in death or lethal injuries due to electric shock.

- Only use measuring devices with a measurement ranges designed for the maximum AC and DC voltage of the inverter.
- Only use measuring devices with measurement ranges designed for the maximum DC voltage of the battery.




Figure 14: Schematic diagram of the measurement

Required equipment:

- ☐ Suitable device for safe disconnection and short-circuiting
- ☐ Measuring device for insulation resistance

i Device required for safe disconnection and short-circuiting of the PV modules

The insulation resistance can only be measured with a suitable device for safe disconnection and short-circuiting of the PV modules. If no suitable device is available, the insulation measurement must not be carried out.

Procedure:

1. Calculate the expected insulation resistance per string.
2. Disconnect the inverter from all voltage sources (see Section 9, page 84).
3. Install the short circuit device.
4. Connect the measuring device for insulation resistance.
5. Short-circuit the first string.
6. Set the test voltage. The test voltage should be as close as possible to the maximum system voltage of the PV modules but must not exceed it (see datasheet of the PV modules).
7. Measure the insulation resistance.
8. Eliminate the short circuit.
9. Measure the remaining strings in the same manner.
 - ☑ If the insulation resistance of a string deviates considerably from the theoretically calculated value, there is a ground fault present in that string.
10. Reconnect to the inverter only those strings from which the ground fault has been eliminated.
11. Reconnect all other strings to the inverter.
12. Recommission the inverter.
13. If the inverter still displays an insulation error, contact the Service. The PV modules might not be suitable for the inverter in the present quantity.

Also see:

- [Calculating the insulation resistance](#) ⇒ page 113

11.5 Manual restart after electric arc

⚠ QUALIFIED PERSON

If manual restart is configured and an electric arc is detected, the feed-in operation will automatically stop. You can use the following parameter to resume feed-in operation after an electric arc has been detected.

Channel	Name	Settings
Operation.OpMod	General operating mode	Start

Also see:

- [Arc-Fault Circuit Interrupter \(AFCI\)](#) ⇒ page 21
- [Arc-Fault Circuit Interrupter \(AFCI\)](#) ⇒ page 71

12 Decommissioning

12.1 Disconnecting the Terminals from the Inverter

QUALIFIED PERSON

To decommission the inverter completely upon completion of its service life, proceed as described in this Section.

CAUTION

Risk of injury due to weight of product

Injuries may result if the product is lifted incorrectly or dropped while being transported or mounted.

- Transport and lift the product carefully. Take the weight of the product into account.
- Wear suitable personal protective equipment for all work on the product.

Procedure:

1. Disconnect the inverter from all voltage sources (see Section 9, page 84).

2.  CAUTION

Risk of burns due to hot enclosure parts

- Wait 30 minutes for the enclosure to cool down.

3. Remove optional accessories (e.g., SMA Backup Start, Wi-Fi antenna).
4. Undo the screw for the additional grounding (TX25) and remove the grounding cable.
5. Unplug the 2-pole connector for the external rapid shutdown initiator from the adapter.
6. Unplug the 2-pole connector to which the DC load-break switch is connected from the adapter.
7. Unplug the adapter from the **GSI** slot.
8. Plug the 2-pole connector to which the DC load-break switch is connected into the **GSI** slot.
9. Remove the battery power cable from the terminals.
10. Remove the cable for grounding the PV modules. To do this, twist off the cable from the busbar for grounding the DC connection (PZ 2).
11. Unplug the network cable from the **BATTERY** network port.
12. Remove the network cable from the **LAN-1** and **LAN-2** network ports.
13. Unplug the connector from the **SPS** slot.
14. Remove the protective conductors of the AC cables from the busbar. To do this, first undo the screw (PZ2).
15. Remove the N and L conductors from the **SPS** terminals.
16. Remove N, L1, and L2 from the **AC** terminals.
17. Remove the ferrite. To do this, cut the cable tie.
18. Detach all conduits and remove all cables from the inverter.

12.2 Disassembling the Inverter

CAUTION

Risk of injury due to weight of product

Injuries may result if the product is lifted incorrectly or dropped while being transported or mounted.

- Transport and lift the product carefully. Take the weight of the product into account.
- Wear suitable personal protective equipment for all work on the product.

Requirements:

- The terminals must be disconnected from the inverter (see Section 12.1, page 116).

Procedure:

1. Remove the side covers. To do so, release the side covers at the bottom of the inverter and slide them upward slightly to disengage from the hooks on the mounting bracket and the inverter.
2. Lift the inverter by the top and bottom of the enclosure, then unhook it from the mounting bracket.
3. Remove the mounting bracket from the wall.
4. If the inverter is to be stored or shipped in packaging, pack the inverter and mounting bracket. Use the original packaging or packaging that is suitable for the weight and dimensions of the inverter.

13 Replacing the Product

QUALIFIED PERSON

Under fault conditions, an SMA product in the system may need to be replaced. If this is the case, you will receive a replacement device from SMA Solar Technology AG. If you received a replacement device, replace the defective product with the replacement device as described below.

1. Decommission the defective product.
2. Mount the replacement device and make the electrical connections.
3. Commission the replacement device.
4. If the defective product was registered by a System Manager (e.g., an inverter configured as a System Manager) or by a communication product, replace it with the new product in the System Manager or communication product (see the Communication Product or System Manager manual).
5. If the System Manager has been replaced, confirm the replaced device in Sunny Portal (see Sunny Portal manual).
6. Pack the defective product in the packaging of the replacement device and arrange with SMA Solar Technology AG for it to be picked up. If a wall mounting bracket is enclosed with the replacement device, pack it with the defective product.

14 Disposal

The product must be disposed of in accordance with the locally applicable disposal regulations for waste electrical and electronic equipment.

15 Technical Data

15.1 General Data

	SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50	SBSE9.6-US-50 / SBSE11.5-US-50
Width x height x depth	500 mm x 586 mm x 236 mm (19.7 in x 23.1 in x 9.3 in)	500 mm x 679 mm x 233 mm (19.7 in x 26.7 in x 9.2 in)
Weight	17.5 kg (38.6 lb)	22 kg (48.5 lb)
Length x width x height of the packaging	760 mm x 580 mm x 350 mm (29.9 in x 22.8 in x 13.8 in)	760 mm x 580 mm x 350 mm (29.9 in x 22.8 in x 13.8 in)
Transport weight (including pallet)	23 kg (50.7 lbs)	25.9 kg (57.1 lbs)

Operating temperature range	-25 °C to +60 °C (-13 °F to +140 °F)
Max. permissible value for relative humidity (condensing)	100 %
Maximum operating altitude above mean sea level (MSL)	3000 m (9843 ft)
Typical noise emission	35 dB(A)
Power loss in night mode	< 6 W
Topology	Transformerless (Non-isolated)
Cooling method	natural convection
Enclosure degree of protection according to UL 50	Type 3R
Degree of protection for electronics in accordance with IEC 60529	IP65
Protection class	I
Radio technology	WLAN 802.11 b/g/n
Radio spectrum	2.4 GHz
Maximum transmission power	100 mW
Wi-Fi range in free-field conditions	10 m (33 ft)
Quantity maximum detectable Wi-Fi networks	32
Grid configurations	240 V split-phase system, 208 V wye connection, 208 V delta connection, 240 V delta connection
National standards and approvals, as per 04/2025	UL 62109-1, UL 1741, UL 62109-1 CRD, UL 1699B

15.2 DC input of PV

	SBSE3.8-US-50	SBSE4.8-US-50	SBSE5.8-US-50	SBSE7.7-US-50	SBSE9.6-US-50	SBSE11.5-US-50
Maximum power of PV array	7680 Wp	9600 Wp	1160 Wp	15360 Wp	19200 Wp	23040 Wp
Maximum input voltage	600 V					
MPP voltage range	60 V to 480 V					

	SBSE3.8- US-50	SBSE4.8- US-50	SBSE5.8- US-50	SBSE7.7- US-50	SBSE9.6- US-50	SBSE11.5- US-50
Minimum input voltage	60 V					
Initial input voltage	66 V					
Maximum usable input current per input	15 A					
Maximum short-circuit current per input ²⁾	30 A					
Maximum short-circuit current for all inputs in total ²⁾	60 A					
Maximum reverse current into the PV modules	0 A					
Number of independent MPP inputs	3	3	3	3	4	4
Strings per MPP input	1					
Coupling capacity of all PV modules in case of PV modules with high capacity to ground	1.54 µF	1.54 µF	1.54 µF	1.54 µF	2.28 µF	2.28 µF
Overvoltage category in accordance with UL 62109-1	II					

15.3 Battery DC input

	SBSE3.8- US-50	SBSE4.8- US-50	SBSE5.8- US-50	SBSE7.7- US-50	SBSE9.6- US-50	SBSE11.5- US-50
Voltage range	90 V to 500 V					

²⁾ In accordance with UL 62109-1: $I_{SC\,PV}$

	SBSE3.8- US-50	SBSE4.8- US-50	SBSE5.8- US-50	SBSE7.7- US-50	SBSE9.6- US-50	SBSE11.5- US-50
Maximum charging current	30 A					
Maximum discharging current	30 A					
Maximum short-circuit current	55 A					
Maximum charging power	10000 W	10000 W	10000 W	10000 W	12000 W	12000 W
Maximum discharge power	4042 W	5053 W	6063 W	8084 W	10105 W	12000 W
Battery type ³⁾	Li-ion					
Number of independent inputs	1					
Overvoltage category UL 62109-1	II					

15.4 AC Output

	SBSE3.8- US-50	SBSE4.8- US-50	SBSE5.8- US-50	SBSE7.7- US-50	SBSE9.6- US-50	SBSE11.5- US-50
Rated power at 240 V, 60 Hz	3840 W	4800 W	5760 W	7680 W	9600 W	11520 W
Rated power at 208 V, 60 Hz	3328 W	4160 W	4992 W	6656 W	8320 W	9984 W
Maximum apparent power	3840 VA	4800 VA	5760 VA	7680 VA	9600 VA	11520 VA
Nominal grid voltage	240 V / 208 V					
Voltage range ⁴⁾	211 V to 264 V / 183 V to 229 V					

³⁾ Warning! Danger of fire due to use of non-approved batteries. Only use batteries approved by SMA Solar Technology AG (technical information with list of approved batteries at www.SMA-Solar.com).

⁴⁾ Depending on the configured country data set

	SBSE3.8- US-50	SBSE4.8- US-50	SBSE5.8- US-50	SBSE7.7- US-50	SBSE9.6- US-50	SBSE11.5- US-50
Rated current at 240 V	16 A	20 A	24 A	32 A	40 A	48 A
Maximum output current	16 A	20 A	24 A	32 A	40 A	48 A
Maximum output current under fault conditions	488 A					
Duration of the maximum output current in the case of failure	5 ms					
The total harmonic distortion of the output current and AC voltage must each be <2%. This condition applies when the AC power is > 50% of the rated power.	< 3 %					
Inrush current	< 10% of the nominal AC current for a maximum of 10 ms					
Rated grid frequency	60 Hz					
Grid frequency ⁴⁾	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
Operating range at grid frequency 60 Hz	55 Hz to 66 Hz					
Power factor at rated power	1					
Displacement power factor, adjustable	0.8 overexcited to 0.8 underexcited					
Feed-in phases	1					

	SBSE3.8- US-50	SBSE4.8- US-50	SBSE5.8- US-50	SBSE7.7- US-50	SBSE9.6- US-50	SBSE11.5- US-50
Connection phases	2-(N)-PE					
Overvoltage category in accordance with UL 62109-1	III					

15.5 Digital output (multifunction relay)

Quantity	1
Execution	Potential-free relay contacts
Maximum switching voltage	30 V DC
Maximum switching current	1 A
Minimum switching current	10 mA
Minimum electrical endurance when the maximum switching voltage and maximum switching current are complied with ⁵⁾	100000 switching cycles
Bounce time	5 ms
Reset time	5 ms
Maximum cable length	< 30 m (98 ft)

15.6 Communication

SMA devices	Max. 5 subordinate devices with SMA Speedwire (inverter and energy meter), 100 Mbit/s
I/O systems and meters	Ethernet, 10/100 Mbit/s, Modbus TCP

15.7 Data Storage Capacity

1-minute values	7 days
5-minute values	7 days
15-minute values	30 days
60-minute values	3 years
Event messages	1024 events

⁵⁾ Corresponds to 20 years at 12 switching operations per day

15.8 Efficiency

	SBSE3.8-US-50	SBSE4.8-US-50	SBSE5.8-US-50	SBSE7.7-US-50	SBSE9.6-US-50	SBSE11.5-US-50
Maximum efficiency, η_{\max}	98.15 %	98.15 %	98.15 %	98.15 %	98.00 %	98.00 %
CEC weighted efficiency at 240 V, $\eta_{\text{CEC}, 240 \text{ V}}$	96.5 %	97.0 %	97.5 %	97.5 %	97.5 %	97.5 %
CEC weighted efficiency at 208 V, $\eta_{\text{CEC}, 208 \text{ V}}$	97.0 %					

15.9 Protective Devices

	SBSE3.8-US-50 / SBSE4.8-US-50 / SBSE5.8-US-50 / SBSE7.7-US-50	SBSE9.6-US-50 / SBSE11.5-US-50
DC reverse polarity protection	Short-circuit diode	
Input-side disconnection point	DC load-break switch	
AC short-circuit current capability	Current control	
Grid monitoring	SMA Grid Guard 10.0	
Maximal output overcurrent protection	50 A	60 A
Ground fault monitoring	Insulation monitoring: $R_{\text{iso}} > 120 \text{ k}\Omega$	
All-pole sensitive residual-current monitoring unit	Available	
Residual-current device (RCD)	Compatible with Type A and Type B	
Arc fault detection AFCI, type 1, listed according to UL1699B Ed. 1	Available	
Rapid Shutdown Equipment	Present, listed according to UL 1741	
Active anti-islanding method	Frequency shift	

15.10 Climatic Conditions

Installation in accordance with IEC 60721-3-4, Class 4K26

Extended temperature range	-25°C to +60°C (-13°F to +140°F)
Extended humidity range	0% to 100%
Threshold for relative humidity, non-condensing	100 %
Extended air pressure range	79.5 kPa to 106 kPa

Transport in accordance with IEC 60721-3-4, Class 2K12

Temperature range	-40°C to +70°C (-40°F to +158°F)
-------------------	----------------------------------

15.11 Equipment

PV connection	Push-in terminal
Battery connection	Push-in terminal
AC connection	Push-in terminal
Multifunction relay	As standard

16 Compliance Information**FCC Compliance**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications made to this equipment not expressly approved by SMA Solar Technology AG may void the FCC authorization to operate this equipment.

17 Contact

If you have technical problems with our products, please contact the SMA Service Line. The following data is required in order to provide you with the necessary assistance:

- Type of device
- Serial number
- Firmware version
- Device configuration (System Manager or subordinate device)
- Special country-specific settings (if available)
- Event message
- Mounting location and mounting height
- Type and number of PV modules
- Optional equipment (e.g. accessories used)
- Use the name of the system in Sunny Portal (if available)

- Access data for Sunny Portal (if available)
- Operating mode of the multifunction relay (if used)
- Detailed description of the problem

You can find your country's contact information at:



<https://go.sma.de/service>

ENERGY
THAT
CHANGES



www.SMA-Solar.com

