


A detailed close-up photograph of solar mounting hardware. It shows a silver-colored metal rail with a square bracket attached via a bolt. Below the rail, a hexagonal nut is visible on a vertical post. The background shows a portion of a solar panel with a grid of cells and a textured, brownish mounting surface.

EJOT®
Solar Fastening
Systems
JA3 & JZ3
Installation Manual



EJOT Solar Fastening Systems JA3 & JZ3



Applications

Roofing

The EJOT Solar Fastening Systems JA3 & JZ3 are appropriate for fastening on metal and fiber cement profiles.

Substructure

- Wood
- Steel
- Concrete

Metal profiles (aluminium/steel)



Trapezoidal profiles



Corrugated profiles



Sandwich elements

Fiber cement profiles



Fiber cement corrugated profiles

Installation tools

- Power screwdriver
- Drill (according to application)
- Screwdriver bit (width across flats SW 5 (mm))
- Wrench (width across flats SW 17 (mm))
- Hexagon socket screw key (width across flats SW 5 (mm))

All drill bits must be metric!



EJOT® The Quality Connection

Installation process

EJOT Solar Fastening System

New installation:

Steps 1 to 3 are omitted. Start of the installation process with step 4.

Re-fitting:

If the EJOT Solar Fastening System is to be installed on an existing roof, the installation process will start with step 1.

1. Taking out existing fastener



2. Removing sealing washer



3. Cleaning from dust



Installation process

Metal profiles (aluminium/steel)

Fiber cement profiles

4. Pre-drilling

Steel profiles:

Pre-drill Ø in substructure
= Pre-drill Ø in steel profile

Fiber cement profiles:

Pre-drill Ø in fiber cement profile
> Pre-drill Ø in substructure!

Please refer to the pre-drill diameters
at the chart below



Pre-drilling diameter in mm for profiled metal sheets and substructure

Metric [mm]

Imperial [inch]

EJOT Solar Fastening System

JZ3-SB-8.0 x L

JA3-SB-8.0 x L

JA3-SB-10.0 x L

Thickness of the substructure:

Steel				Wood	
1.5 ...< 5.0	5.0...< 7.5	7.5 ...< 10	≥ 10	≥ 32	≥ 40
0.059" ...< 0.197"	0.197" ...< 0.295"	0.295" ...< 0.394"	≥ 0.394"	≥ 1.260"	≥ 1.575"
Recommended pre- drilling diameter in metal profiles:					
6.8 mm	7.0 mm	7.2 mm	7.4 mm	-	-
-	-	-	-	5.5 mm	5.5 mm
-	-	-	-	-	7.0 mm

Pre-drilling diameter in the profiled metal sheets = Pre-drilling diameter in the substructure

The pre-drilling diameter in roofings with fiber cement profiles always has to be bigger than the diameter of the EJOT Solar Fastening System!

The pre-drilling diameter in the substructure corresponds to the indications from the table above.

EJOT Solar Fastening System

JZ3-SB-8.0 x L

JA3-SB-8.0 x L

JA3-SB-10.0 x L

Pre-drilling diameter in fiber cement profiles

11.0 mm

11.0 mm

14.0 mm

Installation process

Metal profiles (aluminium/steel)

Fiber cement profiles


5. Cleaning of profile



6. Applying EJOT ORKAN Storm Washer



EJOT ORKAN Storm Washer for trapezoidal metal profiles



EJOT ORKAN Storm Washer for corrugated metal profiles

The sealing element FZD is pre-assembled to the EJOT Solar Fastening System. It is screwed-in directly.

Note:

The sealing element FZD can be used also for metal profiles, as an universal sealing solution.

7. Screwing-in EJOT Solar Fastening System



8. Screwing down EJOT Solar Fastening System

The EJOT Solar Fastening System will not be screwed down with torque!

The sealing element should be squeezed slightly and overlie with the entire surface.



From here on the installation on metal and fiber cement profiles is identical.

9. Adjusting nut

Adjust the nut to align the mounting profile regarding the necessary height.



10. Assembling the adapter

Apply plain washer to the nut. Apply adapter and assemble a further plain washer on the adapter. Assemble lock nut with wrench. Secure the EJOT Solar Fastening System using the hexagon socket key screw to avoid turning out of position.



11. Adjusting adapter and tightening it

Before tightening, adjust the adapter. Use the wrench to counter the nuts and fasten them tight.




12. The EJOT Solar Fastening System is ready installed



13. Attaching parts can be mounted

Attaching parts, such as mounting profiles, can now be assembled. The EJOT Solar Fastening System is not designed for a specific mounting system and thus is universally applicable.



Limited Warranty for function of the EJOT Solar Fastening Systems JA3 & JZ3

Limited Warranty:

The EJOT Group warrants and represents to the purchaser of EJOT Solar Fastening Systems that the products shall be free from defects in material and workmanship under normal and expected use and service for the express period of warranty set forth below.

Period of Warranty:

The period of warranty is 10 years and starts on the date of purchase by the initial purchaser.

Warranty terms:

This warranty is valid only within the express period of warranty. This warranty is limited to either the repair or replacement, at the EJOT Group's sole option, of any defective product. Repair or replacement will only be carried out for the benefit of the direct purchaser of EJOT products. The purchaser shall pay all shipping charges for return of a defective product. For a product returned within 1 year of the date of initial purchase, the EJOT Group shall pay all shipping charges for shipment of the repaired or replacement product, as the case may be, to the purchaser. For a product returned more than 1 year after the initial date of purchase, the purchaser shall pay all shipping charges for shipment of the repaired or replacement product, as the case may be, to the purchaser. A warranty claim can only be confirmed upon presentation of the defective product, the contract receipt and lot number.

Warranty exclusions:

This limited warranty does not apply if the product is improperly installed or assembled, misapplied, abused, altered or otherwise misused in any way, including, without limitation:

- Inappropriate and improper use
- Faulty or negligent treatment
- Failure of installation and assembly instructions
- Changes and self-repairs
- Improper use with chemical and physical resulting effects on the material surface
(e.g. damage caused by sharp objects)
- Use of third-party parts (i.e., non-EJOT parts or non-EJOT specified vendor parts)

Note that professional installation by an expert is required. The following assembly instruction indicates how the installation of the EJOT Solar Fastening is properly carried out and which points must be followed. Nevertheless, the following points must be guaranteed by the installer:

- It must be ensured that the use of EJOT solutions and other products are suitable for the application and installation environment.
- The project must be confirmed according to structural analysis.
- The installer must have sufficient knowledge and ability to carry out the assembly.
- Only EJOT products or EJOT specified vendor parts are allowed to be used. The use of third-party parts will void the warranty.

DISCLAIMER:

EXCEPT FOR THE WARRANTIES SET FORTH ABOVE, THE EJOT GROUP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE, CONCERNING ANY PRODUCT. ALL OTHER GUARANTEES, WARRANTIES, CONDITIONS AND REPRESENTATIONS, EITHER EXPRESS OR IMPLIED, WHETHER ARISING OUT OF ANY STATUTE, LAW, COMMERCIAL USAGE OR OTHERWISE, ARE HEREBY EXCLUDED.

WHILE THE EJOT GROUP AND ITS REPRESENTATIVES MAY, FROM TIME TO TIME, OFFER RECOMMENDATIONS AND ADVICE WITH RESPECT TO USE OF THE PRODUCTS, IT IS UNDERSTOOD THAT ANY SUCH RECOMMENDATIONS AND ADVICE ARE NOT WARRANTIES BY THE EJOT GROUP AND THE PURCHASER WILL ACT UPON ANY SUCH RECOMMENDATIONS AND ADVICE AT THE PURCHASER'S SOLE RISK.

Purchaser's Remedies:

The purchaser's exclusive and sole remedy on account of or in respect to the furnishing of a defective product shall be to secure repair or replacement thereof as described above. The EJOT Group shall not in any event be liable for the cost of any labor expended on any such product or for any special, direct, indirect, consequential or incidental damages (including, without limitation, loss of business or lost profits) to anyone by reason of a defective product. The EJOT Group shall not in any event be liable for damages of the purchaser relating to patent or trademark infringements.

Warranty Claim Process:

For complaints, please contact your supplier directly to present the defective product, the contract receipt and lot number.

Validity of general terms and conditions:

Overall the standard business conditions of the EJOT Group are valid. These terms and conditions can be reviewed on our website www.ejot.com under EJOT Group in the footer.



EJOT Fastening Systems LP
9900 58th Place, Suite 100,
Kenosha, Wisconsin 53144 USA.

phone: +1 262-612-3550
fax: +1 262-721-1245
e-mail: info@ejot-usa.com
internet: www.ejot-usa.com