

Schneider Home

System Planning and Wiring Guide

TME13782A

July 2025

Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Contact Information

For country-specific details, please contact your local Schneider Electric Sales Representative or visit the Schneider Electric website at: <https://www.se.com/>

Information About Your System

As soon as you open your product, inspect the contents and record the following information and be sure to keep your proof of purchase. If any damage is found, contact customer support.

Serial Number	_____	Purchased From	_____
Product Number	_____	Purchase Date	_____

Document Number: TME13782A

Date: July 2025

Information on Non-Inclusive or Insensitive Terminology

As a responsible, inclusive company, Schneider Electric is constantly updating its communications and products that contain non-inclusive or insensitive terminology. However, despite these efforts, our content may still contain terms that are deemed inappropriate by some customers.

Validity Note

This document is valid only for the Home Energy Management System.

If this manual is in any language other than English, although steps have been taken to maintain the accuracy of the translation, the accuracy cannot be guaranteed. Approved content is contained with the English language version which is posted at <https://www.se.com/>.

The characteristics of the products described in this document are intended to match the characteristics that are available on <https://www.se.com/>. As a part of our corporate strategy for constant improvement, we may revise the content over time to enhance clarity and accuracy. If you see a difference between the characteristics in this document and the characteristics on <https://www.se.com/>, consider <https://www.se.com/> to contain the latest information.

Audience

This manual is intended for use by qualified personnel installing a Schneider Electric Home Energy Management System involving any of the following components:

- [Schneider Inverter \(HY8K1NA1\)](#)
- [Schneider Boost \(BAT10K1\)](#)
- [Schneider Backup Controller \(BC200A1NAWM\)](#)
- [Schneider Pulse CSED \(CC18X18M200PCY\)](#)
- [Schneider Pulse CSED with Backup Controller \(CC18X18M200PCZ\)](#)
- [Schneider Energy Monitor \(SEMONITOR\)](#)

The qualified personnel have training, knowledge, and experience in:

- Installing electrical equipment.
- Applying all applicable installation codes.
- Analyzing and reducing the hazards involved in performing electrical work.
- Selecting and using Personal Protective Equipment (PPE).

The qualified personnel have also received specific training from the manufacturer on installing and operating the home energy management system.

Purpose

This manual provides safety guidelines and procedures for installing and operating the Home Energy Management System energy management system.

Related Documents

- *Schneider Inverter Installation Guide (TME12664)*
- *Schneider Boost Installation and Operation Guide (TME12665)*
- *Schneider Home System Planning and Wiring Guide (TME13782)*
- *Pulse Backup Controller: Installation and Operation Guide (TME13781)*
- *Schneider Pulse CSED with or without Backup Control Module (GEX79652)*
- *Schneider Energy Monitor Installation Guide (TME39049)*

Related Information

For more information about the energy management system and compatible equipment, go to: www.se.com/us/en/product-range/234852991-schneider-home-solar-and-energy-storage/#products

or <https://www.se.com/us/en/> > **Products** > **Solar & Energy Storage** > **Solar Off-Grid and Back-up**


Abbreviations and Acronyms

AC	Alternating Current, see also VAC
ANSI	American National Standards Institute
BMS	Battery Management System
Cat5e	Category 5 cable
CSED	Combination Service Entrance Device
CT	Current Transformer
DC	Direct Current, see also VDC
EMT	Electrical Metallic Tubing
HTTP	Hypertext Transfer Protocol
IP	Internet Protocol
LAN	Local Area Network, see also VLAN
LFP	Lithium Iron Phosphate
MID	Microgrid Interconnect Device
NEC	National Electrical Code
NFPA	National Fire Protection Association
PoE	Power over Ethernet
PPE	Personal Protective Equipment
PSI	Pounds per Square Inch
PV	Photovoltaic
PVC	Polyvinyl Chloride
PVRSS	Photovoltaic Rapid Shutdown System
RSD	PV Rapid Shutdown
VAC	Volts Alternating Current
VDC	Volts Direct Current
VLAN	Virtual Local Area Network
W	Watt

Safety Information

Important Information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Stored energy hazard and discharge time



Hot surface



Protective Earth (grounding) conductor terminal



Refer to the Installation or Operation instructions

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Product Safety Information

READ AND SAVE THESE INSTRUCTIONS - DO NOT DISCARD

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, ARC FLASH, AND FIRE

This document is in addition to, and incorporates by reference, the relevant product manuals for each component in this system. Before installing or operating any component in this system, read all instructions and cautionary markings on the unit, and all appropriate sections of the product-specific documentation (see "Related Documents" on page 3). Unless specified, information on safety, specifications, installation and operation is as shown in the primary documentation for each product. Ensure you are familiar with that information before proceeding.

Failure to follow these instructions will result in death or serious injury.

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, ARC FLASH, AND FIRE

The Schneider Home system is energized from multiple sources. Before installing or servicing any components in the system, identify, de-energize, lock-out, and tag-out all sources of energy in the system, and wait 5 minutes for circuits to discharge.

Failure to follow these instructions will result in death or serious injury.

WARNING

HAZARD OF ELECTRIC SHOCK AND FIRE

- Before powering on equipment, verify that all wiring is in good condition and that wire is not undersized. Do not operate any component in this system with damaged or substandard wiring.
- Do not operate any component in this system if it has been damaged in any way.
- Do not disassemble any component in this system except where noted for connecting wiring and cabling.
- Use only the accessories that are recommended by the manufacturer.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Contents

Legal Information	1
Contact Information	1
Information About Your System	1
Information on Non-Inclusive or Insensitive Terminology	2
Validity Note	2
Purpose	3
Related Documents	3
Related Information	3
Abbreviations and Acronyms	4
READ AND SAVE THESE INSTRUCTIONS - DO NOT DISCARD	7
Introduction and Components of the System	13
Schneider Inverter	13
Schneider Boost	14
Schneider Backup Controllers	15
Schneider Energy Monitor	16
Rapid Shutdown (PV Systems)	17
Installer Training	21
Commissioning Apps	24
Home Owner App	25
Installation Requirements	27
Order of Installation	27
Battery Spacing Requirements	28
Conduit Fittings	28
Mounting Surfaces	29
Alignment Requirements	33
Schneider Inverter and Schneider Boost	33
Schneider Home Mounting Measurements	34
Installation Configurations	36
Optimal Alignment of Schneider Inverter, Schneider Boost, and Pulse Backup Controller	36
Combined Systems	39
Overview	39
AC Coupling Sizing Guide	39
Schneider Energy Monitor Installation	40
Wiring Diagrams	40
Installing the CTs Correctly	42
About the Schneider Home Network	45

Cybersecurity Guidelines 47

Communication Between Devices 48

Wire Sizing and Torque Values 51

 Schneider Inverter 51

 Schneider Boost 51

 Pulse Backup Controller 52

 Schneider Pulse CSED (with and without Backup Controller) 53

 Guidelines for Routing Cables 53

Wire Routing Diagrams 54

Backup Control Module as Service Equipment with Solar and Storage (Whole Home Backup) 55

Backup Control Module in Main Lug Configuration with Solar and Storage (Partial Home Backup) 56

Pulse CSED as Service Equipment with Solar and Storage (Partial Home Backup) 57

Figures

Figure 1 Schneider Inverter	13
Figure 2 Schneider Boost	14
Figure 3 Pulse CSED	15
Figure 4 Pulse Backup Controller	16
Figure 5 Schneider Energy Monitor	16
Figure 6 Example Rapid Shutdown Initiator Switch	17
Figure 7 Rapid Shutdown Switch requirement	18
Figure 8 Spacing requirements for multiple batteries	28
Figure 9 Bracket placement for stacked inverter and battery configuration	33
Figure 10 Schneider Inverter bracket to device edge measurements	34
Figure 11 Schneider Boost bracket to device edge measurements	35
Figure 12 Pulse Backup Controller bracket to device edge measurements	35
Figure 13 The battery inverter stack to the left of the Pulse Backup Controller; the required bracket placement shown on the right	36
Figure 14 Other Solar Inverter Connected to the Backup Panel	40
Figure 15 Other Solar Inverter Connected to the Main and Backup Panels	41
Figure 16 Correct CT Orientation	42
Figure 17 Example of a Schneider Home network	46
Figure 18 System with Pulse Backup Controller as service entry device	55
Figure 19 System with Pulse Backup Controller in Main Lug Configuration	56
Figure 20 System with Schneider Pulse CSED (with and without Backup Controller) as service entry device	57

Tables

Table 1 Compatible RSD devices	18
Table 2 Schneider Boost Mounting surfaces	29
Table 3 Schneider Inverter Mounting surfaces	30
Table 4 Pulse Backup Controller Mounting surfaces	31
Table 5 Schneider Pulse CSED (with and without Backup Controller) Mounting surfaces	32
Table 7 Inverter cable specifications and torque	51
Table 8 Battery cable specifications and torque	51
Table 9 Required communication cable and connector	51
Table 10 Pulse Backup Controller cable specifications and torque	52
Table 11 Schneider Pulse CSED (with and without Backup Controller) cable specifications and torque	53

1 Introduction

What's in This Chapter?

Introduction and Components of the System	13
Schneider Inverter	13
Schneider Boost	14
Schneider Backup Controllers	15
Schneider Energy Monitor	16
Rapid Shutdown (PV Systems)	17

Introduction and Components of the System

The Schneider Home system supports power supplementing, energy monitoring, and energy storage technologies. This document can help you decide on the configuration that is most suitable for your needs, and provide high-level guidelines to help you plan and execute your installation.

Note: The information in this manual is supplementary and not intended to be a replacement for the product-specific instructions. For more information, see "Related Documents" on page 3.

Schneider Inverter

Figure 1 Schneider Inverter



The Schneider Inverter is the heart of a Schneider Home energy management system. As a hybrid inverter, the inverter connects to grid and solar power. If the Schneider Boost battery is installed, the inverter maintains battery charge using grid power. If grid and solar power are unavailable, and a backup control device is installed, energy stored in the battery can be used.

NOTICE
<p>RISK OF EQUIPMENT DAMAGE</p> <ul style="list-style-type: none">▪ A maximum of three Schneider Boost batteries can be installed per energy management system. See the <i>Schneider Boost Installation and Operation Guide (TME12665)</i> for details.▪ Use only the Schneider Boost battery with the Schneider Inverter. Other batteries are not compatible. <p>Failure to follow these instructions can result in equipment damage.</p>

For more information, see the [product page](#) on se.com.

Schneider Boost

Figure 2 Schneider Boost



The Schneider Boost is a high voltage, Lithium-Iron Phosphate (LFP) battery storage system. It includes an integrated Battery Management System (BMS), black start, and lockable battery disconnect switch. It can be used for residential and commercial battery-based off-grid, grid backup, and grid interactive applications. The Schneider Boost is designed to operate with the Schneider Inverter (HY8K1NA1). When installed together, the battery and inverter can be monitored remotely.

Batteries are available in the following configurations:

- Single battery
- Dual battery — one battery functions as the primary and the other as the secondary
- Triple battery — one battery functions as the primary and the other two as secondaries

The following accessories are available for front-to-back multi-battery installations:

- **Front-to-Back Mounting Kit - 2 Batteries:** BA10KNA2S
- **Front-to-Back Mounting Kit - 3 Batteries:** BA10KNA3S

For more information, see the [product page](#) on se.com.

Schneider Backup Controllers

For backup power capability, you must have a Backup Control Module in the system, along with the Schneider Inverter and Schneider Boost. The Backup Control Module is Schneider's Microgrid Interconnect Device (MID), and works exclusively with our inverter and battery. It provides a way to island a Schneider Electric solar, storage, or hybrid solution from the grid and is a required component for sites desiring backup power.

When the Backup Control Module detects a grid outage, it communicates with the inverter to enable backup power mode. When grid power is restored, the Backup Control Module detects the grid and communicates with the inverter to synchronize and reconnect.

The Backup Control Module is integrated into the Pulse Combination Service Entrance Device (CSED) or the Backup Control Module, as described below.

Pulse CSED

Figure 3 Pulse CSED



The CSED includes an integrated ring meter socket, main service disconnect, and split-bus load center to allow backed-up essential circuits to stay in the main service panel, eliminating the need for an essential loads sub panel. The factory-installed Schneider Energy Monitor turns this into a smart panel with home consumption monitoring and load control capabilities. Load control is optional on any branch circuit by installing our control relays.

The Pulse CSED is available in two variants:

- *Schneider Pulse CSED with Backup Control Module* - This version includes a factory-installed MID that works exclusively with Schneider Inverter and Schneider Boost.
- *Schneider Pulse CSED* - This version does not include a built-in MID, but can still be interconnected with almost any external third-party MID and solar/storage system.

For more information on the Pulse CSED, see the [product page](#) on se.com.

Pulse Backup Controller

Figure 4 Pulse Backup Controller



The primary function of this product is the MID, and this version of the Backup Controller is selected if you are not doing a panel upgrade with the Pulse CSED. It is a stand-alone, wall-mounted version of the Backup Controller. It also includes a 12-space integrated QO™ breaker panel that can be used for backup or non-backup loads. When configured for backup, it can also be upgraded for load control.

For more information on the Backup Controller, see the [product page](#) on se.com.

Schneider Energy Monitor


Figure 5 Schneider Energy Monitor



The Schneider Energy Monitor is a home energy monitoring device. It is used to measure the current and voltage in the service mains and renewable energy sources. The device monitors two phases of 120 VAC. For more information, see the [product page](#) on se.com.

Rapid Shutdown (PV Systems)


Figure 6 Example Rapid Shutdown Initiator Switch



A Rapid Shutdown (RSD) Initiator Switch and the devices listed in Table 1 on page 18 are required for systems equipped with Rapid Shutdown, with or without the Schneider Boost battery. When the RSD Initiator Switch is connected to the Pulse Backup Controller, the Backup Controller’s integrated RSD inputs must be daisy chained to the inverter RSD inputs.

Note: There are varying types of switches available. Schneider Electric Home Energy Management System uses a 2-wire system for RSD: check that the switch you select meets this requirement.

For more information, see the *Schneider Inverter Installation Guide (TME12664)*.

**WARNING**

HAZARD OF ELECTRIC SHOCK, EXPLOSION, ARC FLASH, AND FIRE


For systems equipped with Rapid Shutdown (RSD):

- A Rapid Shutdown Switch (E-Stop) is required (for systems with or without batteries) in order to provide emergency shutdown functionality.
- Do not use an AC Disconnect in place of a Rapid Shutdown Switch, as it will not initiate rapid shutdown on any Schneider Inverter system, with or without a battery..
- All installations must meet the requirements of the National Electrical Code (NEC), ANSI/NFPA 70 Section 690.12.
- This Photovoltaic Rapid Shutdown System (PVRSS) incorporates one or more pieces of equipment that exercise the rapid shutdown control of PV system conductors required by section 690.12 of the NEC (NFPA 70). Other equipment installed in or on this PV system may adversely affect the operation of this PVRSS. It is the responsibility of the installer to ensure that the completed PV system meets the applicable Rapid Shutdown functional requirements. This equipment must be installed according to the manufacturer’s installation instructions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

IMPORTANT: For systems that do not require the Rapid Shutdown function (per local codes), ensure that the factory-installed jumper is installed between the positive (pin 4) and negative (pin 6) terminals on the RSD terminal block. For more details, see Schneider Inverter Installation Guide (TME12664).

Figure 7 Rapid Shutdown Switch requirement



Required RSD Devices

The approved RSD devices are listed in Table 1.

Table 1 Compatible RSD devices

Name	Model	Description
APSmart RSD-S-PLC*	<ul style="list-style-type: none"> RSD-S-PLC-A RSD-S-PLC-B 	Single PV module Rapid Shutdown device (see Rapid Shutdown (PV Systems) on page 17)
APSmart RSD-D*	<ul style="list-style-type: none"> RSD-D-15-1000 RSD-D-20-1000 RSD-D-25-1000 RSD-D-15-1500 RSD-D-20-1500 RSD-D-25-1500 	Dual PV module Rapid Shutdown device (see Rapid Shutdown (PV Systems) on page 17)

* For the latest information and full installation information, go to <https://apsmartglobal.com/> or see the *Schneider Inverter Installation Guide* (TME12664).

Note: The RSD-D output voltage will be the sum of the two connected panels.

2 Required Training and Software


What's in This Chapter?

Installer Training	21
Commissioning Apps	24
Home Owner App	25

Installer Training

The following installer training is mandatory before installing the Schneider Inverter, Schneider Boost, and the Pulse Backup Controller. For all other Schneider Home products, this training is recommended, but not mandatory.

1. Go to [mySchneider](#).
2. Select **Register Here** and use your work e-mail to register.



3. Enter your company name and select **Search**. Verify that the name and address are correct. If your company is not registered with Schneider, select **Register your company** at the bottom of the page and then enter your company name and address.

Progress: 1 About you — 2 Company Name — 3 Business Type & Area of Focus — 4 Confirm

Search your company

Be sure to provide accurate information to ensure access to the right tools and services.

Buying directly from Schneider Electric?
Search by "Account ID" to ensure the most accurate order information.

☒ Company Name [?](#) ☐ Tax ID [?](#) ☐ Account ID [?](#)

Company Name	City(Optional)	State(Optional)	Zip code/Postal code(...)	
<input type="text" value="Enter Company name"/>	<input type="text" value="Enter City"/>	<input type="text" value="Enter State"/>	<input type="text" value="Zip code/Postal code"/>	<input type="button" value="Search"/>

If your company is not registered with Schneider Electric, please enter your Company Name to get started

4. For Business Type, select **Solar Installer**.

Progress: 1 About you — 2 Company Name — 3 Business Type & Area of Focus — 4 Confirm

What is your business type and area of focus?


Be sure to provide accurate information to ensure access to the right tools and services.

Tell us your business type(11)	Solar Installer A residential solar installer sells and installs home energy management products including solar, storage, smart panels, and EVSE to homeowners. They are passionate about technologies that help homeowners save on electricity costs, gain energy independence, and use cleaner energy sources. Solar installers typically design energy systems, procure materials, acquire customers, perform installations, and may offer O&M services.
B2B Distribution	
Contractor	
Design Firm	
Electrician	
End User	
Home Builder / Home Developer	
IT Channel Partner	
Original Equipment Manufacturer	
Panel Builder	
Solar Installer	
System Integrator	


What is your Area of Focus?
What represents you best as a Solar Installer?

☐ Residential Solar/PV Installer [?](#)

5. On your mySchneider homepage, go to **Programs > Schneider Home Installer > Requirements**. If the information provided during registration was complete, your status will be set to **Certification in Progress**. If you are missing information, contact your Company Administrator.



6. Expand **Certification in Progress** and select **Get Certified** to begin training.



7. Once you successfully complete the Schneider Home Certification training and your enrollment has been processed, your status will be updated to **Certified**. You can now commission the Schneider Home energy management system using the eSetup app.

Commissioning Apps

Depending on the products you are commissioning, you will need to download different apps. See the required apps in the table below.

	eSetup for Configuration app	Schneider Smart Panel Setup app
Products to Commission	<ul style="list-style-type: none"> ▪ Schneider Inverter ▪ Schneider Boost ▪ Pulse Backup Controller ▪ Pulse CSED 	<ul style="list-style-type: none"> ▪ Schneider Energy Monitor ▪ Square D Control Relays
Training and Certification	Schneider Home Certification training is required to enable the commissioning features in the eSetup app.	N/A
Required Apps	Download the eSetup app. Links: Apple App Store Google Play	Download the Smart Panel Setup™ app. Links: Apple App Store Google Play
Account Login	Log in to the eSetup app using your mySchneider account email ID and password.	N/A
Required Firmware	Download the latest firmware for the Schneider Inverter in the eSetup app. Tap Settings > Firmware Manager . ¹	N/A

eSetup™

Download eSetup to commission your energy management system.

IMPORTANT: If you have not completed the **Schneider Home Installer Certification**, complete the free online course by following the steps in "Installer Training" on page 21.

Note: Complete the [Schneider Home Certification training](#) before signing into the eSetup app. To log in to the app, use the email ID and password that was created for the training. Do not sign up with a new ID.

Schneider Electric Installer Portal

After commissioning, qualified personnel can use the web-based [Installer Portal](#) to monitor the Schneider Home energy management system with the owner's consent.

Note: You will need a [mySchneider](#) account in order to log in to Installer Portal.

¹Make sure to download the firmware before heading to the installation site in case of connectivity issues.

Home Owner App

Schneider Home

Schneider Home is a mobile app that provides an overall view of system performance for residential power monitoring systems. It allows home owners to monitor connected devices.









3 Mounting Guidelines

What's in This Chapter?

Installation Requirements	27
Order of Installation	27
Battery Spacing Requirements	28
Conduit Fittings	28
Mounting Surfaces	29
Alignment Requirements	33
Schneider Inverter and Schneider Boost	33
Schneider Home Mounting Measurements	34
Installation Configurations	36
Optimal Alignment of Schneider Inverter, Schneider Boost, and Pulse Backup Controller	36

Installation Requirements

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, ARC FLASH, AND FIRE

This document is in addition to, and incorporates by reference, the relevant product manuals for each component in this system. Before installing or operating any component in this system, read all instructions and cautionary markings on the unit, and all appropriate sections of the product-specific documentation (see "Related Documents" on page 3). Unless specified, information on safety, specifications, installation and operation is as shown in the primary documentation for each product. Ensure you are familiar with that information before proceeding.

Failure to follow these instructions will result in death or serious injury.

Each component in your system has specific installation guidelines and instructions in the product-specific documentation. This information describes:

- installation locations
- ventilation and clearances
- mounting
- grounding
- cable installation

It is important that you review and follow that information for all of the necessary details.

Order of Installation


The components in your Schneider Home energy management system are best installed in the following order:

1. Schneider Boost
2. Schneider Inverter
3. Schneider Backup Controller
4. Additional devices such as the Schneider Energy Monitor

Battery Spacing Requirements

For more information, see the *Schneider Boost Installation and Operation Guide* (TME12665).

Figure 8 Spacing requirements for multiple batteries



Conduit Fittings

When selecting conduit for the connection between components of the Schneider Home system, keep the following considerations in mind:

- Follow NEC or any local requirements for selecting conduit.
- Use non-flexible conduit such as EMT, schedule 40 PVC, or schedule 80 PVC.
- Where conduit bends are required, check NEC standards for guidance on acceptable bend radius.
- If installing outdoors, use rain tight connectors for device entry.
- If installing indoors, use set screw connectors for device entry.

Mounting Surfaces

Note: Additional space may be required when installing on wood studs, and planning must be done to ensure that each component can be properly mounted on the studs as described in the product-specific documentation. That may mean that although the bend radius spacing is adequate, more space must be left between the components to ensure that the mounting bracket for the component affixes to the stud.


Schneider Boost

Table 2 Schneider Boost Mounting surfaces

Wood Studs

Use the six supplied wood screws. Drill a pilot hole that is 3/16 in. by 3 in. deep.


IMPORTANT: Do not mount the Home Energy Management System on metal studs.



Concrete or Brick

Minimum strength must be 2500 PSI (concrete) or 1500 PSI (brick/masonry).

Use six 5/16 in. anchor bolts with washers. The fastener must be long enough so that at least 2 in. (51 mm) can be embedded into the mounting material. All fasteners must be at least 1 1/2 in. (38 mm) away from the edges of masonry blocks or bricks.




Schneider Inverter

Table 3 Schneider Inverter Mounting surfaces

Wood Studs


Use four 5/16 in. lag bolts with washers. The bolts must be long enough so that it can embed at least 3 in. into the studs.



Concrete or Brick

Minimum strength must be 2500 PSI (concrete) or 1500 PSI (brick/masonry).

Use four 5/16 in. fasteners with washers. The fastener must be long enough so that at least 1½ in. (38 mm) can be embedded into the mounting material. All fasteners must be at least 1½ in. (38 mm) away from the edges of masonry blocks or bricks.




Pulse Backup Controller

Note: In the diagrams below, the Backup Controller mounting bracket must attach at minimum through the holes marked in red. For stability, the additional mounting locations marked in blue may be used.

Table 4 Pulse Backup Controller Mounting surfaces

Wood Studs

Use the provided two ¼ in. lag bolts with washers. The screws must embed securely into the studs.




Concrete or Brick

Minimum strength must be 2500 PSI (concrete) or 1500 PSI (brick/masonry).

Use three ¼ in. fasteners with washers. The fastener must be long enough so that at least 1½ in. (38 mm) can be embedded into the mounting material.

All fasteners must be at least 1½ in. (38 mm) away from the edges of masonry blocks or bricks.




Schneider Pulse CSED (with and without Backup Controller)

Table 5 Schneider Pulse CSED (with and without Backup Controller) Mounting surfaces

Wood Studs

The Schneider Pulse CSED (with and without Backup Controller) includes factory installed mounting flanges designed to install the equipment to minimum 2 x 4 wall studs. Use nine wood screws to affix the device to the studs.




Alignment Requirements

Schneider Inverter and Schneider Boost

When installing a Schneider Inverter and Schneider Boost, in order for the conduit holes to align, the mounting brackets need to be installed relative to one another.

Use the Inverter alignment bracket provided with the Schneider Boost. For more details, see *Schneider Boost Installation and Operation Guide (TME12665)*.

Figure 9 Bracket placement for stacked inverter and battery configuration



Note: Heights shown are to mounting holes, not the top of the bracket or device.

Schneider Home Mounting Measurements

In order to ensure the devices are in the desired location when mounting, the following section provides information on distances between the device edges and the bracket mounting holes.

Figure 10 Schneider Inverter bracket to device edge measurements




Figure 11 Schneider Boost bracket to device edge measurements





Figure 12 Pulse Backup Controller bracket to device edge measurements



Installation Configurations

The configuration options are extensive: therefore, pre-installation planning with regards to mounting, spacing, wiring, and conduit routing must be done.


The following configurations are designed for straight conduits between system components.

Optimal Alignment of Schneider Inverter, Schneider Boost, and Pulse Backup Controller

The Pulse Backup Controller must be installed to the right of the Schneider Inverter for optimal alignment of their side conduit holes and tops. See Figure 13 below showing that this optimal alignment requires the top mounting holes on the Pulse Backup Controller's wall mounting bracket to be 1/4 in. (6 mm) higher than the top mounting holes on the Inverter's wall mounting bracket.

IMPORTANT: Install all mounting brackets first before mounting equipment.

Figure 13 The battery inverter stack to the left of the Pulse Backup Controller; the required bracket placement shown on the right



Note: Measurements in this diagram show minimum distance between devices. Larger spacing can be accommodated where required.

4 Combined Systems

What's in This Chapter?

Combined Systems	39
Overview	39
AC Coupling Sizing Guide	39
Schneider Energy Monitor Installation	40
Wiring Diagrams	40
Installing the CTs Correctly	42

Combined Systems

Overview

The Schneider Inverter and Schneider Boost battery can be paired with solar using third-party inverters or micro-inverters.

During grid-tied operation, the Schneider Boost system uses all monitored solar production in its *Time of Use* and *Self Consumption* energy management controls.

Paired solar inverters can be connected to the backup panel of the Schneider Home system, referred to as AC Coupling. During grid outages, AC-coupled solar helps power the loads. Solar production that exceeds the loads is used to charge the Schneider Boost.

Notes:

- The Schneider Energy Monitor is required for monitoring solar energy production from other inverters.
- Systems with Schneider Boost do not work with third-party energy storage systems.

AC Coupling Sizing Guide

For systems with backup, the following table outlines the maximum rating for AC-coupled solar connected to the backup panel.

Schneider Inverter Rating	7.68 kW AC (32 A)
Max AC-coupled Inverter Rating	11.52 kW AC (48 A)

Table 6: AC-coupled PV inverter maximum ratings

Note: Systems with AC-coupled solar can be combined with DC-coupled solar connected directly to the Schneider Inverter.


Schneider Energy Monitor Installation

The Schneider Energy Monitor (SEMONITOR) is required in any AC-coupled system. When installing the monitor:

- The mains or grid CTs must always be installed, even if another device — the Pulse Backup Controller for example — is measuring the grid import-export.
- The outputs of all inverters must pass through the Auxiliary CTs of the Schneider Energy Monitor. Refer to the following diagrams for more information.
- The Schneider Energy Monitor must be connected to the Schneider Inverter or Pulse Backup Controller using a Cat5e Ethernet cable. For details, see the *Schneider Energy Monitor Installation Guide (TME39049)*.


Wiring Diagrams

Figure 14 Other Solar Inverter Connected to the Backup Panel



1	Other solar inverter
2	The Schneider Energy Monitor (SEM)
3	SEM Auxiliary (solar) CTs clamped over all inverter wires. Phase labels (L1/L2) face the Inverters.
4	Optional backup panel
5	Main service panel
6	SEM Grid CTs. Phase labels (L1/L2) face the grid.

Figure 15 Other Solar Inverter Connected to the Main and Backup Panels



1	Other solar inverter
2	The Schneider Energy Monitor (SEM).
3	SEM Auxiliary (solar) CTs clamped over all inverter wires. Phase labels (L1/L2) face the Inverters.
4	Optional backup panel
5	Main service panel
6	SEM Grid CTs. Phase labels (L1/L2) face the grid.

The correct installation of the Schneider Energy Monitor and Auxiliary CTs is important for all features to function correctly when the system includes solar paired with other inverters. This includes site monitoring, load detection, consumption monitoring, frequency shifting, and system energy management.

Notes:


- If solar inverters are connected to different panels, ensure all inverter output wires (Schneider Inverter and third-party inverters, wired to backup and non-backup panels) are routed through the Schneider Energy Monitor Auxiliary CTs (as shown in Figure 15).
- If you have an inverter that cannot be monitored by the Schneider Energy Monitor, do not commission it as an AC coupled PV system. Please note that in this configuration, your load monitoring will be the net of your AC solar output, and your battery energy modes will not take into account any solar production from the other inverter.

Installing the CTs Correctly

The phase label L1/L2 on the CT must face the power source. The nameplate label on the back of the CT should face away from the power source (see Figure 16).

Note: CT L1/ L2 phases must be consistent with the Schneider Energy Monitor AC power wire's L1/L2 phases for correct operation. If the CT installation is correct and the power flow is reversed, it may be caused by reversed phases of the AC power supply wires. See the Schneider Energy Monitor Installation Guide (TME39049) for more information on CTs.

Figure 16 Correct CT Orientation



1	Phase label (faces the power source)
2	Nameplate label (faces away from the power source)

5 Network

What's in This Chapter?

About the Schneider Home Network	45
Cybersecurity Guidelines	47
Communication Between Devices	48

About the Schneider Home Network

The energy management system uses Ethernet to communicate with other devices in the system.

Communication Requirements

The Schneider Inverter and Schneider Energy Monitor (if installed) require an internet connection for monitoring and to complete the system configuration and control in the Schneider Home app. Ethernet (preferred) or Wi-Fi are supported.

Ethernet

The Schneider Inverter and Schneider Energy Monitor (if installed) each require their own Ethernet connection to the home's router.

Wi-Fi

- We recommend connecting to a 2.4 GHz network when available to maximize signal.
- Wi-Fi signal strength will depend on many factors, such as home construction, distance from the Wi-Fi router, and obstructions. It is recommended to plan for Wi-Fi Extenders in the event that they are needed.


Required Ethernet Connections Between Devices

The energy management system uses Power over Ethernet (PoE) to connect and provide auxiliary power to other devices in the system.

IMPORTANT:

- All devices communicate over Ethernet, and an Ethernet cable is required to connect them.
- PoE is supported with the battery or grid.
- A PoE output port should always connect to a PoE input port. Do not connect output to output, or input to input.


Figure 17 Example of a Schneider Home network



Note: The Schneider Energy Monitor can alternatively be connected directly to the inverter, such as in a configuration without a Backup Control Module.

Cybersecurity Guidelines

This section includes information on how to help secure your system.

 **WARNING**

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

Follow the cybersecurity best practices in the Installation Guidethis document to help prevent unauthorized access to the system software.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

To find out about the latest cybersecurity news, sign up for security notifications, or to report a vulnerability, visit the [Schneider Electric Cybersecurity Support Portal](#).

Recommended Actions

Note: The list of recommended actions below is not a complete list of possible cybersecurity measures. It is meant to be a starting point to improve the security of your system.

Upgrades

- Always use the latest firmware for your Schneider Electric devices in order to get new features, cybersecurity fixes and improvements.

IMPORTANT: Always keep the system connected to the internet to allow updates.

- Keep your devices up to date (check for new firmware, or accept firmware update prompts)

Passwords

- Passwords should include upper case, lower case, number, and special characters
- The password must have 8 characters minimum
- The password should not be easily found in the dictionary and a phrase is preferred.
- Passwords should be changed frequently, at least once a year
- A default password must be changed immediately when first received and after a factory reset
- Never reuse passwords
- Never share passwords with unauthorized personnel

Network

- Schneider Electric devices should only be used in your personal home network
- Schneider Electric devices should not have a publicly accessible IP address
- Do NOT use port forwarding to access a Schneider Electric device from the public internet
- Schneider Electric devices should be on their own network segment. If your router supports a guest network or VLAN, it is preferable to locate the devices there
- Use the strongest Wi-Fi encryption available
- Use HTTPs in local network

Physical Site Security

To help prevent physical attacks:

- Install the system on private property, away from public passageways.
- Properly reinstall and close all covers.
- Route all cables through conduits.

Decommissioning

Before a device is permanently removed from your network, perform a full factory reset to erase all data

Communication Between Devices

The Inverter requires a Cat5e cable with RJ45 connectors to communicate with the Schneider Boost battery, Backup Controller, and Schneider Energy Monitor (if installed).



- Install the Cat5e cables between installed devices, as shown in Figure 17 on page 46, using the symbols to identify the correct ports on the equipment.
- Use only 600 V rated Cat5e cable, 4 twisted pair.

Notes:

- The equipment will vary per site. If the Backup Controller is not installed, the Schneider Energy Monitor can be connected directly to the PoE port of the inverter.
- It is strongly recommended to use a cable tester to check the Cat5e cables being used during installation to ensure proper crimping and cable continuity.

PoE Ports

The inverter uses Power over Ethernet (PoE) to connect to the Backup Controller and Schneider Energy Monitor (if installed). The PoE connections provide communication and auxiliary power supply using Cat5e cables and RJ45 connectors. The PoE ports can be identified on the equipment as follows:

	PoE Output (power supply)
	PoE Input

For information about the PoE pin-out, see the *Schneider Inverter Installation Guide (TME12664)*.

6 Wiring

What's in This Chapter?

Wire Sizing and Torque Values	51
Schneider Inverter	51
Schneider Boost	51
Pulse Backup Controller	52
Schneider Pulse CSED (with and without Backup Controller)	53
Guidelines for Routing Cables	53
Wire Routing Diagrams	54
Backup Control Module as Service Equipment with Solar and Storage (Whole Home Backup)	55
Backup Control Module in Main Lug Configuration with Solar and Storage (Partial Home Backup)	56
Pulse CSED as Service Equipment with Solar and Storage (Partial Home Backup)	57

Wire Sizing and Torque Values

Schneider Inverter

Table 7 Inverter cable specifications and torque

Cable name	Cable size	Connector	Rating	Strip length	Torque
AC cables	8-4 AWG	Terminal Strip	600 V Copper (Cu) wire, rated for 194°F (90°C)	5/8 in. (15 mm)	N/A
PV cables	12-6 AWG	Terminal Strip	600 V	5/8 in. (15 mm)	N/A
Battery and BMS cables	Battery: 8 AWG BMS: CAT5e	Terminal Strip	600 V	5/8 in. (15 mm)	N/A
		RJ45	600 V	N/A	
Ground cables	10 AWG	Ring terminal	600 V	5/8 in. (15 mm)	35 in-lb (4.0 Nm)
Aux relay	18 AWG	N/A	600 V	3/8 in. (10 mm)	N/A
RSD cables	18 AWG	N/A	600 V	3/8 in. (10 mm)	N/A
Ethernet cables	CAT5e	RJ45	600 V	N/A	N/A
PoE cables	CAT5e	RJ45	600 V	N/A	N/A

Schneider Boost

Table 8 Battery cable specifications and torque

Cable name	Cable size	Connector type	Rating	Torque
Power cables	8 AWG	Amphenol Amphe-PV H4 Plus™ connectors and pins	600 V	N/A
Ground	10 AWG	M6 screw with flat washer and ring terminal	600 V	44.3 in-lb (5.0 Nm)

Table 9 Required communication cable and connector

Type	Required specifications
Communication cable	<ul style="list-style-type: none"> 600 V Shielded Cat 5e Multi-conductor, 4-twisted pair cable

Pulse Backup Controller

Table 10 Pulse Backup Controller cable specifications and torque

Cable name	Cable size	Connector type	Rating	Torque
Grid AC	4 AWG to 250 kcmil	Box lug	300 V Copper (Cu) wire, rated for 194°F (90°C)	See torque value on circuit breaker
L1/L2 backup/non- backup connections	4/0 AWG	Box lug	300 V	22.8 ft-lb (31 Nm)
External panels AC	6 AWG to 250 kcmil	Box lug	300 V	23 in-lb (2.6 Nm)
Earth ground	6 AWG to 250 kcmil	Box lug	300 V	23 in-lb (2.6 Nm)
Grid neutral	6 AWG to 250 kcmil	Box lug	300 V	23 in-lb (2.6 Nm)
Inverter and house loads neutral	14 AWG to 4 AWG (copper) 12 AWG to 4 AWG (aluminum)	Neutral bar	300 V	<ul style="list-style-type: none"> ▪ #14-10 Cu, #12-10 Al: 20 in-lb (2.3 Nm) ▪ #8 Cu/Al - 25 in-lb (2.3 Nm) ▪ #6-4 Cu/Al - 35 in-lb (4.0)
Ground connection to terminal strip	14 AWG to 4 AWG (copper) 12 AWG to 4 AWG (aluminum)	Ground bar	300 V	<ul style="list-style-type: none"> ▪ #14-10 Cu, #12-10 Al: 20 in-lb (2.3 Nm) ▪ #8 Cu/Al - 25 in-lb (2.3 Nm) ▪ #6-4 Cu/Al - 35 in-lb (4.0)
Ethernet cables	CAT5e (shielded)	RJ45	600 V	N/A

Schneider Pulse CSED (with and without Backup Controller)

Table 11 Schneider Pulse CSED (with and without Backup Controller) cable specifications and torque

Cable name	Cable size	Connector type	Rating	Torque
Grid AC	4 AWG to 300 kcmil	Box Lug	300 V	20.83 ft-lb (28.25 Nm)
Inverter and house loads neutral	14 AWG to 4 AWG (copper) 12 AWG to 4 AWG (aluminum)	Ground/Neutral bar	300 V	<ul style="list-style-type: none"> ▪ #14-10 Cu, #12-10 Al: 20 in-lb (2.3 Nm) ▪ #8 Cu/Al - 25 in-lb (2.3 Nm) ▪ #6-4 Cu/Al - 35 in-lb (4.0)
Ground connection to terminal strip	14 AWG to 4 AWG (copper) 12 AWG to 4 AWG (aluminum)	Ground/Neutral bar	300 V	<ul style="list-style-type: none"> ▪ #14-10 Cu, #12-10 Al: 20 in-lb (2.3 Nm) ▪ #8 Cu/Al - 25 in-lb (2.3 Nm) ▪ #6-4 Cu/Al - 35 in-lb (4.0)
Ethernet cables	CAT5e (shielded)	RJ45	600 V	N/A
RSD Cables	18 AWG	Terminal Strip	600 V	N/A

Guidelines for Routing Cables

Follow these guidelines when routing the cables:


- Use enclosed conduits for routing any cables outside of the enclosure.
- Route the cables away from sharp edges that might damage the insulation. Avoid sharp bends in the cable—no less than a 4 in. (100 mm) radius.
- Allow for some slack in the cable tension.
- Keep the alignment of wire pairs inside the sheath as straight as possible.
- If possible, allow separation between data cables and power cables/busbars.
- Use appropriate hardware fasteners to avoid damage to the cable.

Wire Routing Diagrams

- Backup Control Module as Service Equipment with Solar and Storage (Whole Home Backup) on page 55
- Backup Control Module in Main Lug Configuration with Solar and Storage (Partial Home Backup) on page 1
- Pulse CSED as Service Equipment with Solar and Storage (Partial Home Backup) on page 57

Backup Control Module as Service Equipment with Solar and Storage (Whole Home Backup)

Figure 18 System with Pulse Backup Controller as service entry device




*For systems equipped with Rapid Shutdown, a Rapid Shutdown (RSD) Initiator Switch and the RSD devices shown in the Schneider Inverter Installation and Operation Guide (TME12664C) are required.

Important: In this configuration, ensure that the Schneider Inverter is connected to a backed-up load center i.e. not connected to the non-backup lugs.

Backup Control Module in Main Lug Configuration with Solar and Storage (Partial Home Backup)

Figure 19 System with Pulse Backup Controller in Main Lug Configuration




*For systems equipped with Rapid Shutdown, a Rapid Shutdown (RSD) Initiator Switch and the RSD devices shown in the *Schneider Inverter Installation and Operation Guide (TME12664C)* are required.

Important: In this configuration, ensure that the Schneider Inverter is connected to a backed-up load center i.e. not connected to the non-backup lugs.

Pulse CSED as Service Equipment with Solar and Storage (Partial Home Backup)

Figure 20 System with Schneider Pulse CSED (with and without Backup Controller) as service entry device



*For systems equipped with Rapid Shutdown, a Rapid Shutdown (RSD) Initiator Switch and the RSD devices shown in the Schneider Inverter Installation and Operation Guide (TME12664C) are required.

Schneider Electric

201 Washington St, Suite 2700, One Boston Place
Boston, Massachusetts 02108
United States
<https://www.se.com/>

As standards, specifications, and designs change from time to time,
please ask for confirmation of the information given in this
publication.

For other country details please contact your local Schneider
Electric Sales Representative or visit the Schneider Electric website
at: <https://www.se.com/>

© 2025 Schneider Electric. All Rights Reserved.